

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Wisdomlit](#) /

› [Wisdomlit 3-in-1 Fog Bubble Machine \(Model QB-807ARF\) Instruction Manual](#)

## Wisdomlit QB-807ARF

# Wisdomlit 3-in-1 Fog Bubble Machine Instruction Manual

Model: QB-807ARF

Brand: Wisdomlit

## 1. INTRODUCTION

---

The Wisdomlit 3-in-1 Fog Bubble Machine (Model QB-807ARF) is designed to create various atmospheric effects, including colorful bubbles, magical fog bubbles, and continuous fog. This versatile machine is suitable for enhancing the ambiance of stages, weddings, photography sessions, holiday parties, and other events.



Image 1.1: The Wisdomlit 3-in-1 Fog Bubble Machine in operation, producing bubbles in an event setting.

## 2. PACKAGE CONTENTS

---

Verify that all items listed below are included in your package:

- 1 x Fog Bubble Machine
- 1 x Gift Box (Packaging)
- 1 x Replacement Fuse (125V, 5A)
- 1 x Remote Control (CR2032 Button Cell Battery included)
- 1 x Measuring Cup (16.9 Fl Oz / 500ml)
- 1 x Bottle Concentrated Bubble Liquid (100ml/bottle)
- 1 x Bottle Concentrated Fog Liquid (100ml/bottle)
- 1 x User Manual

# WHAT'S IN THE BOX ?



1 x Fog Bubble Machine



1 x Gift Box

1 x Replacement Fuse  
(125V, 5A)



1 x Remote Control  
(CR2032 Button Cell Battery)



1 x Measuring Cup  
(16.9 Fl Oz / 500ml)



1-Bottle  
Concentrated Bubble Liquid  
(100ml/bottle)



NOTE: Please dilute concentrated bubble liquid with water before use

1-Bottle  
Concentrated Fog Liquid  
(100ml/bottle)



NOTE: Please dilute concentrated fog liquid with water before use

1 x User Manual



Image 2.1: Contents of the product package.

## 3. SAFETY INFORMATION

Read all safety instructions before operating the machine to prevent injury or damage.

- **Electrical Safety:** Ensure the power supply matches the machine's requirements. Do not operate with damaged cords or plugs.
- **Liquid Usage:** Use only commercial and professional bubble solution and medium-density fog fluid recommended by the manufacturer. Homemade soap water may not produce bubbles effectively and could damage the machine.
- **Placement:** Place the machine on a stable, level surface. Ensure adequate ventilation around the unit. Do not block air vents.
- **Heating Element:** The machine contains a heating element. Allow sufficient cool-down time after use before handling or storing. Avoid touching the nozzle during operation.
- **Indoor Use:** While suitable for indoor events, be mindful of fog density in small, enclosed spaces.
- **Children and Pets:** Keep the machine out of reach of children and pets.



Image 3.1: Warning regarding bubble liquid.



Image 3.2: Warning regarding fog liquid.

## 4. SETUP INSTRUCTIONS

---

Follow these steps to set up your fog bubble machine:

1. **Install the Handle:** Attach the carrying handle to the top of the fog bubble machine using the provided knobs and washers. Ensure it is securely fastened.
2. **Fill Liquid Tanks:**
  - **Bubble Liquid Tank:** Open the bubble liquid tank cover (18.6 Fl Oz / 550 mL capacity) and carefully pour in the recommended bubble solution.
  - **Fog Liquid Tank:** Open the fog liquid tank cover (10.5 Fl Oz / 310 mL capacity) and pour in the recommended medium-density fog fluid.
3. **Connect Power:** Plug the power cord into a suitable electrical outlet. Ensure the power switch on the machine is in the OFF position before plugging in.
4. **Power On and Preheat:** Turn the power switch to the ON position. The red LED light will illuminate, indicating the machine is preheating. Preheating typically takes 3-5 minutes. The machine is ready for operation when the red LED light turns off.

# EASY TO USE & CLEAN




Image 4.1: Visual guide for setup and cleaning.

## 5. OPERATION

Once the machine has preheated, you can activate its functions using either the buttons on the unit or the wireless remote control.

### 5.1. Functions

The machine offers three distinct effects:

- **Bubbles:** Produces a continuous stream of colorful bubbles.
- **Fog Bubbles:** Creates bubbles filled with fog, offering a unique visual effect.
- **Fog:** Generates continuous smoke for atmospheric effects.



*Image 5.1: The three atmospheric effects produced by the machine.*

## 5.2. Using the Remote Control

The wireless remote control allows you to manage the machine's functions from up to 40 feet (12 meters) away without obstructions. Ensure the CR2032 battery is installed and the plastic tab is removed before first use.



*Image 5.2: Operating the machine with the wireless remote control.*

The remote control features buttons for each effect (Bubble, Fog Bubble, Fog) and timer settings:

- **Effect Buttons:** Press the corresponding button to activate Bubbles, Fog Bubbles, or Fog.
- **Duration Settings:** Set the operating time for the effects to 30s, 60s, 180s, or 300s.
- **Interval Settings:** Set the pause between operations to 10s, 30s, 60s, or 90s.
- **ON/OFF:** Power the machine on or off.



Image 5.3: Remote control functions and settings.

## 6. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your machine.

### 6.1. Cleaning After Use

After each use, especially if storing the machine, it is important to drain and clean the liquid tanks:

1. **Drain Residual Liquid:** The machine features individual drainage outlets for both the bubble and fog liquid tanks. Place a container beneath the drainage outlets and open them to discharge any remaining liquid.
2. **Clean Tanks:** Rinse the tanks with clean water. For thorough cleaning, you may use a mild, non-abrasive cleaning solution if necessary, followed by a complete rinse with clean water.
3. **Dry Thoroughly:** Ensure both tanks are completely dry before closing the drainage outlets and storing the machine.

### 6.2. Storage

Store the machine in a cool, dry place away from direct sunlight and extreme temperatures. Ensure all liquids are drained and the machine is clean before storage.

## 7. TROUBLESHOOTING

If you encounter issues with your machine, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No fog or weak fog output	<ul style="list-style-type: none"> <li>• Insufficient preheating time</li> <li>• Low fog liquid level</li> <li>• Incorrect type of fog liquid</li> <li>• Nozzle blockage</li> </ul>	<ul style="list-style-type: none"> <li>• Allow 3-5 minutes for preheating until the red LED light turns off.</li> <li>• Refill the fog liquid tank.</li> <li>• Ensure you are using water-based, medium-density fog fluid.</li> <li>• Clean the nozzle if visible blockage is present.</li> </ul>

Problem	Possible Cause	Solution
No bubbles or inconsistent bubbles	<ul style="list-style-type: none"> <li>• Low bubble liquid level</li> <li>• Incorrect type of bubble liquid (e.g., homemade soap water)</li> <li>• Bubble wand mechanism obstruction</li> </ul>	<ul style="list-style-type: none"> <li>• Refill the bubble liquid tank.</li> <li>• Use commercial, professional bubble solution.</li> <li>• Check for any debris obstructing the bubble wands.</li> </ul>
Remote control not working	<ul style="list-style-type: none"> <li>• Battery depleted or incorrectly installed</li> <li>• Obstruction between remote and machine</li> </ul>	<ul style="list-style-type: none"> <li>• Replace the CR2032 battery and ensure correct polarity.</li> <li>• Remove any objects blocking the line of sight between the remote and the machine.</li> </ul>
Machine does not power on	<ul style="list-style-type: none"> <li>• Power cord not securely plugged in</li> <li>• Power outlet issue</li> <li>• Blown fuse</li> </ul>	<ul style="list-style-type: none"> <li>• Check power cord connection to both the machine and the outlet.</li> <li>• Test the outlet with another device.</li> <li>• Replace the fuse with the provided spare (125V, 5A).</li> </ul>

## 8. SPECIFICATIONS

<b>Model Number</b>	QB-807ARF
<b>Power</b>	450W
<b>Item Weight</b>	8.58 pounds (3.89 kg)
<b>Product Dimensions</b>	13.54 x 7.6 x 9.09 inches (34.4 x 19.3 x 23.1 cm)
<b>Bubble Liquid Tank Capacity</b>	18.6 Fl Oz / 550 mL
<b>Fog Liquid Tank Capacity</b>	10.5 Fl Oz / 310 mL
<b>Continuous Use Time</b>	Up to approximately 60 minutes (with full tanks)
<b>Preheating Time</b>	3-5 minutes
<b>Remote Control Range</b>	Up to 40 feet (12 meters) without obstructions
<b>Remote Control Battery</b>	1 x CR2032 (included)
<b>Housing Material</b>	Durable Metal Housing

## 9. WARRANTY AND SUPPORT

For warranty information or technical support, please contact Wisdomlit customer service. Refer to the product packaging or the official Wisdomlit website for contact details.

