

STAIGIS ST-36018-L

STAIGIS 18 Bottle Wine Cooler Refrigerator ST-36018-L Instruction Manual

Model: ST-36018-L

1. INTRODUCTION

Thank you for choosing the STAIGIS 18 Bottle Wine Cooler Refrigerator. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read these instructions thoroughly before use and retain them for future reference.

This freestanding wine cooler is designed to store red, white, rosé, and sparkling wines at optimal temperatures, ensuring their quality and flavor are preserved. It features advanced compressor refrigeration and a digital temperature control system for precise climate management.

2. SAFETY INFORMATION

WARNING: To reduce the risk of fire, electric shock, or injury, follow these basic precautions:

- Read all instructions before using the appliance.
- Do not touch cold surfaces immediately after the unit has been plugged in.
- Ensure the appliance is properly grounded. Connect only to properly grounded outlets.
- Do not use extension cords or ungrounded (two-prong) adapters.
- Unplug the appliance before cleaning or making any repairs.
- Keep ventilation openings clear of obstruction.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

3. PRODUCT OVERVIEW

The STAIGIS 18 Bottle Wine Cooler (Model ST-36018-L) is a compact, freestanding unit designed for efficient wine storage. It features a sleek black finish, a double-layer glass door, and interior LED lighting.



Image 1: STAIGIS 18 Bottle Wine Cooler with key dimensions highlighted.

Key Components:

- **Digital Touch Control Panel:** Located on the top of the door for temperature adjustment and light control.
- **Double-Layer Glass Door:** Provides insulation and UV protection for your wine.
- **Removable Metal Shelves:** Five shelves designed to hold standard wine bottles, offering flexible storage.
- **Interior LED Lighting:** Illuminates the cabinet for easy viewing of your collection.
- **Adjustable Feet:** For leveling the unit on uneven surfaces.
- **Compressor Cooling System:** Ensures consistent and efficient temperature maintenance.

PRODUCT DETAILS



Image 2: Detailed view of the wine cooler's features including LED lights and adjustable feet.

4. SETUP INSTRUCTIONS

4.1 Unpacking

1. Remove all packaging materials, including the foam base and adhesive tape.
2. Inspect the appliance for any damage during transit. If damage is found, contact customer support immediately.
3. Clean the interior of the unit with a damp cloth before use.

4.2 Placement

- Place the wine cooler on a flat, stable surface strong enough to support the unit when fully loaded.
- Ensure adequate air circulation around the unit. Maintain at least 5 inches (12.7 cm) of space at the back and sides, and 10 inches (25.4 cm) at the top.
- Avoid placing the unit in direct sunlight or near heat sources (e.g., ovens, radiators).

- Do not install in areas with extreme temperature fluctuations.
- **Important:** After delivery, allow the wine cooler to stand upright for at least 24 hours before plugging it in. This allows the refrigerant to settle.

Suitable For Various Places





Image 3: Examples of suitable placement locations for the wine cooler.

4.3 Leveling

The unit must be level for proper operation. Adjust the leveling feet at the bottom of the appliance by turning them clockwise or counter-clockwise until the unit is stable and level.

4.4 Power Connection

- Plug the appliance into a dedicated, grounded 110V AC outlet (Type A - 2 pin North American plug).
- Do not overload the circuit.

5. OPERATING INSTRUCTIONS

5.1 Control Panel

The control panel is located on the top of the wine cooler door and features a digital display and touch buttons for temperature adjustment and lighting.



Image 4: Digital touch control panel for temperature and light.

5.2 Temperature Adjustment

- The temperature range for this unit is 40°F to 66°F (approximately 4°C to 19°C).
- Press the **UP arrow (▲)** to increase the desired temperature.
- Press the **DOWN arrow (▼)** to decrease the desired temperature.
- The display will flash while setting and then show the current internal temperature.
- To switch between Fahrenheit (°F) and Celsius (°C), press and hold the lock button (padlock icon) for approximately 3 seconds.

5.3 Interior LED Light

- Press the **light bulb icon** to turn the interior LED light on or off.

5.4 Loading Wine Bottles

- The cooler can hold up to 18 standard 750ml wine bottles.
- The shelves are removable to accommodate larger or irregularly shaped bottles. Gently pull the shelf forward until it stops, then lift and remove.
- Ensure bottles are placed securely to prevent rolling or damage.

6. MAINTENANCE

6.1 Cleaning

- Always unplug the appliance before cleaning.
- Clean the interior with a mild detergent and warm water. Avoid abrasive cleaners or solvents.
- Wipe down the exterior with a soft, damp cloth.
- Clean the door gasket regularly to ensure a proper seal.

6.2 Defrosting

This appliance features an automatic defrost system. Frost will melt and drain into a tray at the back of the unit, where it evaporates. No manual defrosting is typically required.

6.3 Power Outage

In case of a power outage, the wine cooler will generally maintain its temperature for several hours. Avoid opening the door unnecessarily to preserve the internal temperature.

7. TROUBLESHOOTING

If you experience issues with your wine cooler, please consult the table below before contacting customer support.

Problem	Possible Cause	Solution
Appliance does not operate.	Not plugged in; circuit breaker tripped; power switch off.	Ensure plug is secure; check circuit breaker; turn power switch on.
Temperature is not cold enough.	Door not closed properly; excessive door openings; warm items added; poor ventilation; unit in direct sunlight.	Check door seal; reduce door openings; allow time for new items to cool; ensure proper clearance; relocate unit.
Unit is making unusual noises.	Unit not level; loose parts; normal compressor operation.	Adjust leveling feet; check for loose components; some noise from compressor is normal.
Vibration.	Unit not level; unit touching a wall or other object.	Adjust leveling feet; move unit away from contact points.
Moisture buildup inside.	High humidity; door left open; frequent door openings.	Ensure door is closed tightly; reduce frequency of door openings.

8. SPECIFICATIONS

Feature	Specification
Model Name	ST-36018-L
Product Dimensions (D x W x H)	17.5"D x 13.6"W x 30.6"H
Capacity	1.8 Cubic Feet (18 Bottles)
Color	Black
Temperature Range	40°F to 66°F (4°C to 19°C)
Cooling Method	Compressor
Defrost System	Automatic
Voltage	110 Volts
Power Plug Type	Type A - 2 pin (North American)
Number of Shelves	5 (Removable)
Door Material Type	Glass
Item Weight	54.3 Pounds
Annual Energy Consumption	186 Kilowatt Hours Per Year
Refrigerant	R-600A
Certification	ETL

9. WARRANTY AND SUPPORT

9.1 Warranty Information

This STAIGIS wine cooler comes with a **Limited One Year Replacement Parts Warranty**. Please retain your proof of purchase for warranty claims. The warranty covers defects in materials and workmanship under normal use. It does not cover damage resulting from misuse, accident, alteration, neglect, or unauthorized repair.

9.2 Customer Support

For technical assistance, warranty inquiries, or to order replacement parts, please contact STAIGIS customer support. Refer to the contact information provided with your purchase or visit the official STAIGIS website.

Online Resources: For additional information and FAQs, please visit the [STAIGIS Brand Store on Amazon](#).

