

VCK TF009A

VCK Tower Fan TF009A

USER MANUAL

1. Important Safety Instructions

Please read all instructions carefully before using this appliance and retain them for future reference. Failure to follow these instructions may result in electric shock, fire, or serious personal injury.

- Always ensure the voltage indicated on the rating label corresponds to your mains voltage.
- Do not immerse the fan, plug, or cord in water or other liquids.
- Unplug the fan from the power outlet when not in use, when moving it from one location to another, and before cleaning.
- Do not operate the fan with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- Keep the fan out of reach of children and pets. This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Do not insert fingers or foreign objects into the grille or any openings of the fan.
- Place the fan on a stable, flat surface to prevent it from tipping over.
- Do not use the fan near windows, where rain may come into contact with it.
- Do not use the fan in areas where flammable liquids or gases are stored.
- Ensure the power cord is not placed under carpets or covered with throw rugs, runners, or similar coverings. Arrange the cord away from traffic areas where it will not be tripped over.

2. Package Contents

Verify that all items are present and in good condition upon opening the package.

- VCK Tower Fan (Model TF009A)
- Remote Control (with CR2025 battery)
- User Manual





Image: VCK Tower Fan TF009A and its remote control. The fan is black, cylindrical, with a vertical grille, and a touch control panel on top. The remote is small and black with several buttons.

3. Product Overview

Familiarize yourself with the components of your VCK Tower Fan.



Upgraded Powerful Motor

Long-distance cooling and accelerated air circulation

AC 120V/60Hz 30W

Image: An exploded diagram of the VCK Tower Fan, illustrating its internal components including the powerful motor and impeller, designed for efficient air circulation.

Key Features:

- **Touch Control Panel:** Located on the top of the fan for direct operation.
- **Remote Control:** Allows convenient operation from a distance of up to 27 feet.
- **Air Outlet:** Vertical grille for air distribution.
- **Base:** Provides stability for the tower fan.
- **Integrated Handle:** For easy portability.



Image: A close-up view of the fan's top control panel, featuring touch-sensitive buttons for various functions.



Image: A hand demonstrating the portability of the VCK Tower Fan by holding its integrated handle at the top.

4. Setup

The VCK Tower Fan TF009A typically comes pre-assembled or requires minimal assembly, primarily for the base.

1. **Unpack:** Carefully remove all components from the packaging.
2. **Base Assembly (if required):** If the base is separate, align the two semi-circle parts and snap them together to form a round base. Insert the tower fan into the slots on the base and turn it to lock it securely in place. No tools are required for this step.
3. **Placement:** Place the fan on a firm, level surface. Ensure there is adequate space around the fan for optimal airflow and oscillation.
4. **Power Connection:** Plug the power cord into a standard electrical outlet.

5. Operating Instructions

Your VCK Tower Fan can be operated using the touch control panel on top of the unit or the included remote control.

Control Panel & Remote Functions:



Image: Detailed view of the fan's touch control panel, showing icons for power, speed, mode, oscillation, and timer settings.






Image: The VCK Tower Fan alongside its remote control, which features buttons for power, speed, oscillation, mode, and timer.

- **Power Button ():** Press to turn the fan ON or OFF.
- **Speed Button (↗):** Cycles through 3 speed settings: Low, Medium, High.
- **Mode Button (☀):** Selects between 3 wind modes:
 - **Normal Mode:** Provides a constant airflow at the selected speed.
 - **Natural Mode:** Simulates natural breeze by varying fan speed intermittently.
 - **Sleep Mode:** Operates quietly with gradually decreasing fan speed and dims the display for undisturbed sleep.
- **Oscillation Button (↻):** Activates or deactivates the 90° oscillation feature, distributing air across a wider area.
- **Timer Button ():** Sets the automatic shut-off timer from 1 to 8 hours. Each press increases the timer by one hour.

3-Speed, 3-Mode Setting

Meet your every cooling needs

3 Wind Modes



Normal



Natural



Sleep

3 Speed



Low

Medium

High



Image: A person relaxing on a couch while the VCK Tower Fan provides cooling airflow, highlighting the fan's 3 wind modes (Normal, Natural, Sleep) and 3 speed settings (Low, Medium, High).

Whisper-Quiet Sleep Mode

Providing a comfort and cool sleep environment



7H Timer



Sleep Mode



20 dB
Falling Leaves

20 dB
Falling Leaves

20 dB
Falling Leaves

<30dB

Image: A child sleeping soundly in a bedroom, with the VCK Tower Fan operating in a quiet Sleep Mode, indicated by a low noise level of less than 30dB.

70° Widespread Oscillation

Keeps Every Square Inch of Your Room Cool and Refreshing



Image: The VCK Tower Fan positioned on a small table, demonstrating its 70° widespread oscillation feature, effectively circulating air across a living space.



Image: A hand holding the remote control, demonstrating its ability to operate the VCK Tower Fan from a distance of up to 27 feet, providing convenient control.

6. Maintenance

Regular cleaning and proper storage will ensure the longevity and optimal performance of your VCK Tower Fan.

Cleaning:

1. **Disconnect Power:** Always unplug the fan from the power outlet before cleaning.
2. **Exterior Cleaning:** Use a soft, damp cloth to wipe the exterior surfaces of the fan. Do not use abrasive cleaners or solvents, as these may damage the finish.
3. **Air Inlet/Outlet:** Use a soft brush or a vacuum cleaner with a brush attachment to gently remove dust from the air inlet and outlet grilles. Do not attempt to open the fan housing for internal cleaning.

Storage:

When not in use for extended periods, store the fan in a cool, dry place, preferably in its original packaging, to protect it from dust and damage.

7. Troubleshooting

If you encounter issues with your VCK Tower Fan, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Fan does not turn on.	No power supply.	Ensure the power cord is securely plugged into a working electrical outlet. Check the circuit breaker.
Weak or no airflow.	Air inlets/outlets are blocked or dusty.	Unplug the fan and clean the air inlets and outlets as described in the Maintenance section.
Fan makes unusual noise.	Fan is not on a stable surface; internal obstruction.	Place the fan on a flat, stable surface. Unplug and check for any visible obstructions in the grilles. If the noise persists, discontinue use and contact customer support.
Remote control not working.	Battery depleted; remote out of range; obstruction.	Replace the CR2025 battery in the remote. Ensure you are within the 27-foot operating range and there are no obstructions between the remote and the fan.
Oscillation not working.	Oscillation function not activated.	Press the oscillation button on the control panel or remote to activate the feature.

8. Specifications

Lightweight & Compact



Image: The VCK Tower Fan displaying its compact dimensions: 4.4 inches in depth, 4.4 inches in width, and 12.9 inches in height, suitable for various spaces.

Feature	Detail
Model Name	TF009A
Brand	VCK
Color	Black
Product Dimensions	4.4"D x 4.4"W x 12.9"H
Item Weight	3.08 pounds
Power Source	Electric
Control Method	Remote, Digital Touch
Special Feature	Bladeless Design, 90° Oscillation, 3 Modes, 3 Speeds, 1-8H Timer

Feature	Detail
Noise Level	As low as 26dB (Sleep Mode)
Air Velocity	Up to 27ft/s
Recommended Use	Bedroom, Home, Office, Indoor

9. Warranty and Support

For warranty information and customer support, please refer to the documentation provided at the time of purchase or contact VCK customer service through the retailer where the product was purchased. Keep your purchase receipt as proof of purchase for any warranty claims.

For further assistance, please visit the official VCK Store: [VCK Store on Amazon](#)