

## PHORUS B0FC1SY1B2

# PHORUS 48-inch Tropical Palm Leaf Ceiling Fan User Manual

Model: B0FC1SY1B2

## 1. INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your PHORUS 48-inch Tropical Palm Leaf Ceiling Fan. Please read this manual thoroughly before installation and retain it for future reference. This ceiling fan is designed for both indoor and outdoor covered areas, offering a unique tropical aesthetic with modern functionality.



*Image 1.1: PHORUS 48-inch Tropical Palm Leaf Ceiling Fan.*

## 2. SAFETY INFORMATION

---

- Ensure the main power supply is disconnected before installation, maintenance, or cleaning.
- All electrical connections must comply with local codes and ordinances, as well as national electrical codes. If you are unfamiliar with electrical wiring, consult a qualified electrician.
- The mounting structure must be capable of supporting the weight of the fan (approximately 12.58 pounds) plus the dynamic load during operation.
- Do not bend the blade holders during installation or cleaning.
- Ensure there is adequate clearance between the fan blades and any obstacles.
- This fan is suitable for use in damp locations but should not be directly exposed to water.

## 3. PACKAGE CONTENTS

---

Verify that all components listed below are included in your package. If any parts are missing or damaged, please contact customer support.



Image 3.1: Overview of included components and fan dimensions.

- Fan Body Assembly
- 5 Palm Leaf Blades
- Canopy
- Downrods (4-inch and 8-inch options)
- Lamp Shade
- Remote Control
- Remote Receiver
- Mounting Bracket
- Hardware Pack (screws, wire nuts, etc.)
- Instruction Manual

## 4. SETUP AND INSTALLATION

Follow these steps carefully for proper installation. For a visual guide, please refer to the installation video provided below.

## 4.1. Installation Video Guide

Your browser does not support the video tag.

*Video 4.1: Detailed installation guide for the PHORUS 48-inch Palm Leaf Ceiling Fan with lights.*

## 4.2. Step-by-Step Installation

1. **Prepare the Fan Body:** Attach the LED light board to the fan body assembly using the provided screws.
2. **Attach Fan Blades:** Secure each of the five palm leaf blades to the fan body. Ensure the correct side of the blade is facing upwards as indicated in the video.
3. **Assemble Downrod:** Insert the downrod through the canopy and secure it to the fan body. Feed the electrical wires through the downrod.
4. **Install Mounting Bracket:** Secure the mounting bracket to your ceiling junction box. Ensure it is firmly attached and can support the fan's weight.
5. **Wiring Connections:** Connect the fan's electrical wires to your household wiring. Typically, this involves connecting the black live wire, white neutral wire, and yellow ground wire. Refer to the wiring diagram in the installation video for precise connections.
6. **Hang the Fan:** Carefully lift the fan assembly and hang it onto the mounting bracket.
7. **Install Remote Receiver:** Place the remote receiver within the canopy, ensuring wires are not pinched. Connect the receiver to the fan and household wiring as per the diagram.
8. **Secure Canopy:** Slide the canopy up to the ceiling and secure it to the mounting bracket with screws.
9. **Install Lamp Shade:** Attach the lamp shade to the bottom of the fan body.

The fan is equipped with 4-inch and 8-inch downrods to accommodate various ceiling heights. It can also be used with sloped ceilings up to 15 degrees.

## 5. OPERATING INSTRUCTIONS

---

Your PHORUS ceiling fan can be controlled via the included remote control or a smart application on your mobile device.

### 5.1. Remote Control Operation





*Image 5.1: Remote control layout with function descriptions.*

The remote control allows you to adjust the following settings:

- **Power On/Off:** Turn the fan and light on or off.
- **Fan Speed:** Select from 6 wind speeds (1-6).
- **Light On/Off:** Control the integrated LED light independently.
- **Color Temperature:** Adjust between 3 light colors: 3000K (Warm Light), 4500K (Natural Light), and 6000K (White Light).
- **Brightness Adjustment:** Dim or brighten the light from 10% to 100%.
- **Reverse Function:** Change the direction of the fan blades for summer (downdraft) or winter (updraft) modes. Press the F/R key and wait 5-8 seconds for the fan to stop completely and then automatically reverse.
- **Timer:** Set a 2-hour timer for automatic shutdown.

### Remote Code Pairing:

If your remote control is not responding, you may need to pair it with the fan. Follow these steps:

1. Turn off the main power supply to the fan for one minute.

2. Turn on the main power supply and simultaneously long-press the code key on the remote control for 3-5 seconds.
3. The fan light will blink 2-3 times to indicate successful code matching.

Your browser does not support the video tag.

*Video 5.2: Instructions for remote code pairing.*

## 5.2. Smart App Control

The fan supports control via a smart application. Scan the QR code in Image 5.1 or visit <https://www.jasonghost.com/fanlamppro/> to download the "Fan Lamp Pro" app.

Your browser does not support the video tag.

*Video 5.3: Guide for setting up and using the smart app control.*

The app provides comprehensive control over fan speeds, light settings (color temperature and brightness), and the reverse function, similar to the remote control. All settings will be remembered after power cycling.




*Image 5.4: Customizable light effects and dimming range.*






### 6 Wind Speeds Adjustable




**1-2 Speeds**

**Comfortable Wind**  
suitable for sleep



**3-4 Speeds**

**Natural Wind**  
suitable for daily life



**5-6 Speeds**

**Strong Wind**  
suitable for hot summer

Image 5.5: Fan airflow modes (summer/winter) and 6-speed settings.

## 6. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:** Periodically clean the fan blades and light cover with a soft, damp cloth. Do not use abrasive cleaners or solvents that could damage the finish.
- **Tighten Fasteners:** Check all screws and fasteners on the fan body and mounting bracket annually. Tighten any loose connections to prevent wobbling or noise.
- **Dusting:** Dust the fan motor housing and canopy regularly to prevent dust buildup, which can affect performance.

## 7. TROUBLESHOOTING

If you encounter issues with your fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Fan does not start	No power supply; Loose wire connections; Remote not paired.	Check circuit breaker/wall switch; Verify all wire connections are secure; Perform remote code pairing (refer to Section 5.1).
Light does not work	Loose wire connection; LED driver issue.	Check light wiring connections; Contact customer support if LED driver is suspected.
Fan wobbles	Loose blades or mounting hardware; Unbalanced blades.	Ensure all blade screws and mounting bracket screws are tight; Use a balancing kit (not included) if necessary.
Remote control not responding	Low battery; Remote not paired.	Replace AAA batteries (2 required, included); Perform remote code pairing (refer to Section 5.1).
Excessive noise	Loose screws; Motor issue.	Check and tighten all screws; Ensure blades are securely attached. If noise persists, contact customer support.

## 8. SPECIFICATIONS

- **Brand:** PHORUS
- **Model:** B0FC1SY1B2
- **Color:** 48" Dark Brown
- **Material:** Acrylic, Plastic
- **Style:** Tropical
- **Room Type:** Bedroom, Dining Room, Garage, Kids Room, Kitchen
- **Indoor/Outdoor Usage:** Indoor (suitable for damp locations)
- **Power Source:** DC
- **Special Features:** App Operable, LED Light, Quiet Operation, Remote Controlled, Timer
- **Control Method:** App, Remote
- **Number of Light Sources:** 1
- **Included Components:** Light Kit, Remote Control
- **Item Weight:** 12.58 pounds
- **Number of Items:** 1
- **Wattage:** 60 watts
- **Controller Type:** App Control, Remote Control
- **Unit Count:** 1.0 Count
- **Mounting Type:** Ceiling Mount
- **Assembly Required:** Yes
- **Size:** Medium (48 inches)
- **Recommended Uses For Product:** Air Circulation
- **Product Dimensions:** 48 x 48 x 15.15 inches
- **Batteries:** 2 AAA batteries required (included)



## 9. WARRANTY AND SUPPORT

---

PHORUS provides a one-year quality warranty for this product. We also offer free replacement service for any damage and quality problems encountered during the warranty period. If you have any questions or require assistance, please contact PHORUS customer support for a satisfactory answer within 24 hours.

Documents - PHORUS – B0FC1SY1B2

no relevant documents