

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [OSRAM](#) /

› [OSRAM LEDSTIXX LED Flashlight User Manual](#)

OSRAM LEDSTIXX

OSRAM LEDSTIXX LED Flashlight User Manual

Model: LEDSTIXX (Reference: 4099854497575)

1. INTRODUCTION

Thank you for choosing the OSRAM LEDSTIXX LED Flashlight. This manual provides essential information for the safe and efficient use of your new device. Please read these instructions carefully before use and retain them for future reference.

The OSRAM LEDSTIXX is a modern, battery-operated LED stick light featuring a robust aluminum casing. It provides 25 lumens of cool white light (6500K) and can be used flexibly without wires. The integrated LED has a lifespan of up to 10,000 hours. It is rated IP20 for indoor use and includes 3 AAA batteries.



An image showing the OSRAM LEDSTIXX LED flashlight. It is a slender, silver-colored bar made of aluminum, with multiple small LED light sources visible along its length. The light is positioned on a white, curved base, suggesting its compact and portable design.

2. SAFETY INFORMATION

- **Indoor Use Only:** This product has an IP20 rating, meaning it is protected against solid objects larger than 12.5mm but has no protection against water. Do not use in wet or damp environments.
- **Battery Safety:**
 - Use only AAA batteries of the specified type.
 - Ensure batteries are inserted with correct polarity (+/-).

- Do not mix old and new batteries, or different types of batteries.
- Remove exhausted batteries promptly to prevent leakage.
- If the device is not used for an extended period, remove the batteries.
- Keep batteries out of reach of children.
- **Light Source:** The LED light source is not replaceable. Do not attempt to disassemble the light fixture.
- **Cleaning:** Clean only with a dry, soft cloth. Do not use abrasive cleaners or solvents.
- **Disposal:** Dispose of the product and batteries according to local regulations.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x OSRAM LEDSTIXX LED Flashlight (Silver Metallic)
- 3 x AAA Batteries
- Mounting accessories (adhesive surface or screws, as applicable for your model)

4. SETUP AND INSTALLATION

4.1. Battery Installation

1. Locate the battery compartment cover on the flashlight.
2. Open the cover by sliding or twisting it according to the markings.
3. Insert 3 AAA batteries, ensuring the correct polarity (+ and -) as indicated inside the compartment.
4. Close the battery compartment cover securely.

4.2. Mounting Options

The OSRAM LEDSTIXX offers flexible mounting options for various indoor applications. It can be mounted horizontally or vertically.

- **Adhesive Mounting:**
 - Clean the desired mounting surface thoroughly to ensure it is free of dust and grease.
 - Peel off the protective film from the adhesive surface on the back of the flashlight or its mounting bracket.
 - Press the flashlight firmly onto the cleaned surface for at least 30 seconds.
 - Allow the adhesive to set for a few hours before regular use for optimal adhesion.
- **Screw Mounting:**
 - Identify the screw holes on the mounting bracket (if applicable) or the flashlight itself.
 - Mark the desired drilling points on the mounting surface.
 - Drill pilot holes if necessary, suitable for the provided screws.
 - Secure the flashlight or its bracket to the surface using the appropriate screws.

5. OPERATING INSTRUCTIONS

The OSRAM LEDSTIXX is designed for simple operation.

- **Turning On/Off:** Locate the power button or switch on the device. Press or slide it to turn the light on or off.
- **Light Output:** The flashlight provides a fixed cool white light output of 25 lumens. There are no adjustable brightness settings.
- **Placement:** Position the flashlight to illuminate the desired area. Its compact design makes it suitable for accent or decorative lighting in various indoor settings, such as under cabinets, in closets, or on shelves.

6. MAINTENANCE

- **Cleaning:** To clean the flashlight, gently wipe the aluminum casing and LED surface with a dry, soft, lint-free cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the finish or electronic components.
- **Battery Replacement:** When the light output diminishes or the flashlight stops working, it is time to replace the batteries. Follow the "Battery Installation" steps in Section 4.1 to replace the 3 AAA batteries. Always replace all batteries at the same time with new ones.
- **Storage:** If the flashlight will not be used for an extended period, remove the batteries to prevent potential leakage and damage to the device. Store in a cool, dry place.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Flashlight does not turn on.	Batteries are exhausted. Batteries are inserted incorrectly. Battery compartment cover is not closed properly.	Replace all 3 AAA batteries with new ones. Check battery polarity and reinsert correctly. Ensure the battery compartment cover is securely closed.
Light output is dim.	Batteries are low.	Replace all 3 AAA batteries with new ones.
Flashlight falls off mounting surface.	Adhesive surface was not clean. Adhesive has lost its strength. Screws were not tightened sufficiently.	Re-mount using a fresh adhesive strip on a clean surface, or use screw mounting. Re-mount using a fresh adhesive strip or use screw mounting. Tighten screws or use appropriate wall anchors for better support.

8. SPECIFICATIONS

Brand	OSRAM
Model Number	4099854497575
Manufacturer	LEDVANCE
Product Dimensions (L x W x H)	22.2 x 1.62 x 2.2 cm

Item Weight	94 grams
Color	Silver Metallic
Material	Aluminum
Number of Bulbs	1 (Integrated LED)
Voltage	5 Volts
Special Feature	Energy Efficient
Power Source	Battery Powered
Batteries Required	Yes (3 x AAA, included)
Bulb Type	LED
Luminous Flux	25 lumens
Color Temperature	6500 Kelvin (Cool White)
Lifespan	Up to 10,000 hours
IP Rating	IP20 (Indoor Use Only)

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided with your purchase or visit the official OSRAM website. Please have your model number (4099854497575) and purchase date available when contacting support.

Information regarding spare parts availability and software updates is not provided for this product.
