

RCB R17

Generic RCB R17 Electric Scooter Charger

USER MANUAL

1. Introduction

This manual provides essential instructions for the safe and efficient use of your Generic RCB R17 Electric Scooter Charger. Please read this manual thoroughly before operating the charger to ensure proper function and to prevent damage to the charger or your electric scooter. Keep this manual for future reference.

2. Safety Information

Your safety is paramount. Observe the following precautions:

- **Compatibility:** Use this charger exclusively with the RCB R17 electric scooter or other compatible devices as specified by the manufacturer. Using an incompatible charger may cause damage or fire.
- **Voltage:** Ensure the input voltage of the charger (220 Volts AC) matches your local power supply.
- **Protection Features:** This charger is equipped with advanced safety features including over-voltage, over-current, short-circuit, and temperature protection. Do not attempt to bypass or modify these features.
- **Environment:** Operate the charger in a dry, well-ventilated area. Avoid exposure to water, moisture, direct sunlight, or extreme temperatures.
- **Handling:** Do not drop, disassemble, or attempt to repair the charger. If the charger is damaged, discontinue use immediately and contact support.
- **Children and Pets:** Keep the charger and charging scooter out of reach of children and pets.

3. Package Contents

Verify that all items are present in the package:

- 1 x Generic RCB R17 Electric Scooter Charger



Image: The Generic RCB R17 Electric Scooter Charger, black in color, with its power cord and connector.

4. Setup

Follow these steps to prepare your charger for use:

1. **Unpack:** Carefully remove the charger from its packaging.
2. **Inspect:** Check the charger and cables for any visible damage. Do not use if damaged.
3. **Placement:** Place the charger on a stable, flat, and non-flammable surface, away from heat sources and flammable materials.

5. Operating Instructions

To charge your RCB R17 electric scooter:

1. **Connect to Scooter:** Plug the charger's output connector into the charging port of your RCB R17 electric scooter. Ensure a secure connection.
2. **Connect to Power:** Plug the charger's input power cord into a compatible 220V AC wall outlet.
3. **Charging Indicator:** The charger typically features an indicator light. A red light usually indicates charging in progress, while a green light indicates a full charge or standby mode. Refer to your

scooter's manual for specific charging light behavior.

4. **Charging Time:** Charging time will vary depending on the scooter's battery level. Disconnect the charger once the scooter's battery is fully charged. The charger provides fast and stable charging.
5. **Disconnect:** First, unplug the charger from the wall outlet, then disconnect the charger from the scooter.

6. Maintenance

Proper maintenance ensures the longevity of your charger:

- **Cleaning:** Disconnect the charger from all power sources before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** Store the charger in a cool, dry place when not in use. Avoid wrapping the cable too tightly around the charger.
- **Cable Care:** Regularly inspect the power cord and connectors for any signs of wear, cuts, or damage. Replace if necessary.

7. Troubleshooting

If you encounter issues with your charger, refer to the following common problems and solutions:

- **Charger Indicator Light Not On:**
 - Ensure the charger is securely plugged into both the wall outlet and the scooter.
 - Check if the wall outlet is functional by plugging in another device.
 - Inspect the charger cable for damage.
- **Scooter Not Charging:**
 - Verify that the charger is compatible with your specific RCB R17 scooter model.
 - Ensure the charging port on the scooter is clean and free of debris.
 - If the battery is completely depleted, it might take a few minutes for the charging indicator to activate.
- **Charger Overheating:**
 - Disconnect the charger immediately.
 - Ensure the charger is in a well-ventilated area and not covered.
 - If overheating persists, discontinue use and contact support.

If these steps do not resolve the issue, contact customer support for further assistance.

8. Specifications

Feature	Detail
Model	RCB R17 Electric Scooter Charger
Brand	Generic
Input Voltage	220 Volts (AC)
Output Voltage	42 Volts (DC)

Color	Black
Product Dimensions	4 x 3 x 3 inches (approx.)
Manufacturer	Power Fix
First Available	June 11, 2025

9. Warranty and Support

For warranty information, please refer to the documentation provided at the time of purchase or contact your retailer. For technical support or inquiries, please reach out to the manufacturer or your point of purchase.

© 2025 Generic. All rights reserved.