

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [GREYOLK](#) /

› [GREYOLK V5 Swimming Headphones User Manual](#)

GREYOLK V5

GREYOLK V5 Swimming Headphones User Manual

Model: V5

1. INTRODUCTION

The GREYOLK V5 Swimming Headphones are designed for active individuals, offering bone conduction audio technology, IP68 waterproofing, and a built-in 32GB MP3 player. These open-ear headphones provide a secure and comfortable fit for various activities, including swimming, running, cycling, and general exercise. The open-ear design allows users to remain aware of their surroundings while enjoying audio.



Image 1.1: GREYOLK V5 Swimming Headphones, showcasing the sleek black design and waterproof capabilities.

2. WHAT'S IN THE BOX

- GREYOLK V5 Swimming Headphones
- Magnetic Charging Cable
- User Manual

3. SETUP INSTRUCTIONS

3.1 Charging the Headphones

Before initial use, fully charge the headphones. Connect the magnetic charging cable to the charging port on the headphones and to a USB power source. A full charge takes approximately 1.5 hours, providing up to 8 hours of playback or talk time.



Image 3.1: The magnetic charging cable connected to the headphones and a computer, illustrating the charging and

data transfer process.

3.2 Bluetooth Pairing

1. Press and hold the power button on the headphones until the LED indicator flashes, indicating pairing mode.
2. On your smartphone, tablet, or other Bluetooth-enabled device, navigate to the Bluetooth settings.
3. Select "V5" from the list of available devices to connect. A voice prompt will confirm successful pairing.

3.3 Loading Music (MP3 Mode)

The headphones feature 32GB of built-in memory, capable of storing up to 6,000 songs. This is essential for underwater use, as Bluetooth connectivity is not supported underwater.

1. Connect the headphones to your computer using the magnetic charging cable.
2. The headphones will appear as a removable disk drive on your computer.
3. Drag and drop your desired audio files (MP3, WMA, WAV, APE, FLAC formats are supported) into the headphone's storage.
4. Safely eject the device from your computer once files are transferred.

4. OPERATING INSTRUCTIONS

4.1 Controls

The headphones are equipped with intuitive button controls located on the side:

- **Power Button:** Press and hold to power on/off. Double-click to switch between Bluetooth and MP3 modes.
- **Volume Up/Next Track:** Short press for volume up. Long press for next track.
- **Volume Down/Previous Track:** Short press for volume down. Long press for previous track.
- **Play/Pause/Call Answer:** Single press to play/pause music or answer/end calls.

4.2 Switching Between Bluetooth and MP3 Modes

To switch between Bluetooth streaming and the built-in MP3 player, double-click the power button. A voice prompt will indicate the current mode.



MP3 Mode

With 32GB of MP3 mode memory, store up to 9,000 of your favorite songs and enjoy music on the go.
Note: Switch to MP3 mode when swimming; Bluetooth does not function underwater.



Bluetooth Mode

Featuring Bluetooth mode and supporting Bluetooth 5.3 connectivity for enhanced stability and faster connections, ideal for activities like running, cycling, and workouts.

Image 4.1: Visual representation of the headphones supporting both Bluetooth and MP3 modes, ideal for various

activities including swimming and running.

5. USAGE SCENARIOS

5.1 Swimming and Water Activities

The IP68 waterproof rating makes these headphones suitable for swimming, snorkeling, fishing, and boating. For optimal performance underwater, switch to MP3 mode as Bluetooth signals do not transmit effectively through water.

Video 5.1: A demonstration of the IP68 waterproof headphones being used during swimming, highlighting their functionality in aquatic environments.

5.2 Running, Cycling, and Outdoor Sports

The open-ear design ensures you can hear your surroundings, enhancing safety during outdoor activities like running and cycling. The lightweight design (32 grams) and secure fit prevent discomfort during intense workouts.




Image 5.1: A person running outdoors while wearing the GREYOLK V5 headphones, illustrating the open-ear design that allows for environmental awareness.

6. MAINTENANCE

6.1 Cleaning and Drying

After use, especially after swimming or heavy sweating, rinse the headphones with fresh water and dry them thoroughly with a soft cloth. Ensure the charging contacts are clean and dry before charging.

6.2 Battery Care

To prolong battery life, avoid fully discharging the headphones frequently. Store them in a cool, dry place when not in use.

7. TROUBLESHOOTING

- **No Sound Underwater:** Ensure the headphones are in MP3 mode. Bluetooth does not function underwater.
- **Cannot Pair via Bluetooth:** Make sure the headphones are charged and in pairing mode (flashing LED). Check your device's Bluetooth settings and try reconnecting.
- **Low Volume/Poor Sound Quality:** Adjust the volume on both the headphones and your connected device. Ensure the bone conduction transducers are positioned correctly on your cheekbones.
- **Headphones Not Recognized by Computer:** Ensure the magnetic charging cable is securely connected and try a different USB port or computer.

8. SPECIFICATIONS

Model Name	V5
Connectivity Technology	Wireless (Bluetooth 5.4)
Water Resistance Level	IP68 Waterproof
Built-in Memory	32GB (supports MP3, WMA, WAV, APE, FLAC)
Battery Life	Up to 8 Hours
Charging Time	1.5 Hours
Item Weight	32 Grams (1.2 ounces)
Ear Placement	Open Ear
Audio Driver Type	Bone Conduction Driver
Bluetooth Range	10 Meters
Compatible Devices	Cellphones, Laptops, Tablets (iOS, Android)

9. WARRANTY AND SUPPORT

The GREYOLK service team offers a 2-year after-sales service. If you have any questions or require assistance, please do not hesitate to contact us.