

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [YESIMOM](#) /

> [YESIMOM Baby Monitor Indoor WiFi Camera 8SM User Manual](#)

YESIMOM 8SM

YESIMOM Baby Monitor Indoor WiFi Camera 8SM User Manual

Model: 8SM | Brand: YESIMOM

1. INTRODUCTION

Thank you for choosing the YESIMOM Baby Monitor Indoor WiFi Camera 8SM. This device is designed to provide reliable monitoring of your baby or indoor space with advanced features such as 360° pan-tilt-zoom, two-way audio, and app control. This manual will guide you through the setup, operation, and maintenance of your camera to ensure optimal performance and safety.

2. PACKAGE CONTENTS

Please check the package contents upon unboxing. If any items are missing or damaged, contact customer support.

- 1 × YESIMOM Baby Monitor Camera
- 1 × Power Adapter
- 1 × Power Cable
- 3 × Screws
- 3 × Wall Plugs
- 1 × Reset Pin
- 1 × Multilingual Instruction Manual (this document)
- 1 × Video Guide Card

3. PRODUCT OVERVIEW AND FEATURES

The YESIMOM 8SM camera offers a range of features for comprehensive indoor monitoring.

3.1 Key Features

- **Full HD 1080p Resolution:** Provides clear and detailed video footage.
- **360° Pan-Tilt-Zoom (PTZ):** Horizontal 355° and vertical 60° rotation for complete room coverage.

- **Two-Way Audio:** Communicate with your baby or family members through the camera.
- **Motion and Sound Detection:** Receive instant notifications on your smartphone for detected activity.
- **Invisible Night Vision:** Monitor in low-light conditions without disturbing sleep.
- **Flexible Storage:** Supports local TF card storage (up to 256GB, not included) and cloud storage options.
- **App Control:** Manage and view live feed from your iOS or Android device.
- **One-Click Call Function:** Initiate a call directly from the camera.

3.2 Camera Components

Familiarize yourself with the camera's physical components.



Image: Front view of the YESIMOM Baby Monitor Camera. This image displays the camera's lens, microphone, and speaker, along with its distinctive rabbit ear design.



Image: Illustration of the camera's 360-degree pan and tilt capabilities. The image shows arrows indicating 355 degrees horizontal rotation and 60 degrees vertical tilt, demonstrating the camera's wide coverage.

Captura lo inesperado

Comparte Cada Logro

Yesimom

Almacenamiento Flexible

Registro 24/7

Reproducción del Evento

Compartición Múltiple

Image: Depiction of the camera's flexible storage options, including a visible TF card slot. This image highlights the ability to record and store footage locally or via cloud services.

Ampliación Zoom 4X

Captura Cada Momento con Claridad



Image: Visual representation of the camera's 4X digital zoom capability. The image shows a zoomed-in section of a larger scene, illustrating the clarity maintained even when magnified.

4. SETUP GUIDE

Follow these steps to set up your YESIMOM Baby Monitor.

4.1 Physical Installation

1. **Choose a Location:** Place the camera on a flat surface like a table or shelf, or mount it to a wall using the provided screws and wall plugs. Ensure it has a clear view of the area you wish to monitor.
2. **Power Connection:** Connect the power cable to the camera's power port and plug the adapter into a power outlet. The camera will power on and initiate its startup sequence.

3. **Insert TF Card (Optional):** If you plan to use local storage, gently insert a TF card (up to 256GB, not included) into the designated slot on the camera.

4.2 App Download and Account Registration

1. **Download the App:** Search for the official YESIMOM app in the Apple App Store (for iOS devices) or Google Play Store (for Android devices).
2. **Register/Log In:** Open the app and follow the on-screen instructions to register a new account or log in if you already have one.

4.3 Wi-Fi Connection

The camera supports **2.4GHz Wi-Fi networks only**. It is not compatible with 5GHz Wi-Fi networks. Ensure your router is configured to use 2.4GHz or has a mixed mode enabled.

1. **Add Device:** In the app, tap the "+" icon or "Add Device" to begin the pairing process.
2. **Select Camera Type:** Choose the appropriate camera model from the list.
3. **Bluetooth Pairing:** The camera uses Bluetooth for initial setup. Ensure Bluetooth is enabled on your smartphone. The app will guide you through connecting to the camera via Bluetooth.
4. **Wi-Fi Configuration:** Once connected via Bluetooth, the app will prompt you to select your 2.4GHz Wi-Fi network and enter the password.
5. **Confirmation:** Follow any further on-screen instructions to complete the connection. The camera will indicate a successful connection (e.g., a specific LED light pattern or voice prompt).

5. OPERATING INSTRUCTIONS

Once set up, you can utilize the camera's features through the YESIMOM app.

5.1 Live View and PTZ Control

- **Access Live Feed:** Open the app and select your camera from the device list to view the live video stream.
- **Pan and Tilt:** Use the directional controls within the app to remotely rotate the camera horizontally (355°) and vertically (60°) to adjust the viewing angle.
- **Digital Zoom:** Pinch to zoom in or out on the live feed to get a closer look (up to 4X digital zoom).

5.2 Two-Way Audio

- **Listen:** The camera's microphone captures audio from the monitored area, which you can hear through the app.
- **Speak:** Tap the microphone icon in the app to speak. Your voice will be transmitted through the camera's speaker, allowing you to communicate with your baby or anyone near the camera.

5.3 Motion and Sound Detection

- **Enable Alerts:** In the app settings, navigate to "Detection Settings" to enable motion and sound detection.
- **Sensitivity:** Adjust the detection sensitivity to minimize false alarms.
- **Notifications:** When motion or sound is detected, you will receive instant push notifications on your smartphone.
- **Automatic Tracking:** The camera can automatically track detected movement within its field of view.

5.4 Recording and Storage

- **TF Card Recording:** If a TF card is inserted, the camera will automatically record events or continuous footage based on your settings. You can review recordings directly from the app.
- **Cloud Storage:** The app offers optional cloud storage services (subscription may be required). Refer to the app for details on plans and activation.
- **Event Playback:** Access recorded events and playback history through the app's timeline or event list.

5.5 One-Click Call

The camera features a physical button that can be configured for a one-click call function. This allows a person near the camera to initiate a call to a pre-set contact via the app.

1. **Configuration:** In the app settings, locate the "One-Click Call" or similar option.
2. **Set Contact:** Assign a contact from your app's contact list to the one-click call button.
3. **Usage:** Press the button on the camera to initiate a call to the configured contact.



Image: Illustration of the camera's one-click call button and its interaction with a smartphone app. The image shows a finger pressing the button on the camera and a phone screen displaying an incoming call, demonstrating the ease of communication.

6. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your camera.

- **Cleaning:** Use a soft, dry cloth to clean the camera lens and body. Avoid using harsh chemicals or abrasive materials.
- **Software Updates:** Regularly check the app for firmware updates for your camera. Updates often include performance improvements and security enhancements.
- **Placement:** Ensure the camera is placed in a stable environment, away from direct sunlight, extreme temperatures, and moisture.

7. TROUBLESHOOTING

If you encounter issues, refer to the following common solutions.

Problem	Possible Solution
Camera not connecting to Wi-Fi	<ul style="list-style-type: none">◦ Ensure your Wi-Fi network is 2.4GHz. The camera does not support 5GHz networks.◦ Check your Wi-Fi password for accuracy.◦ Move the camera closer to your Wi-Fi router.◦ Restart your router and the camera.◦ Ensure Bluetooth is enabled on your phone for initial pairing.
No live video feed	<ul style="list-style-type: none">◦ Verify the camera is powered on and connected to Wi-Fi.◦ Check your internet connection on your smartphone.◦ Restart the app and the camera.
Motion/Sound detection not working	<ul style="list-style-type: none">◦ Ensure detection alerts are enabled in the app settings.◦ Adjust the sensitivity settings.◦ Check app notification permissions on your smartphone.
Two-way audio issues	<ul style="list-style-type: none">◦ Ensure your phone's microphone is not muted in the app.◦ Check the volume settings on your phone and within the app.◦ Ensure there are no obstructions blocking the camera's microphone or speaker.

8. SPECIFICATIONS

Feature	Detail
Model Name	8SM
Brand	YESIMOM
Connectivity Technology	Wired (Power), Bluetooth & 2.4G WiFi (Data)

Feature	Detail
Video Capture Resolution	1080p
Video Capture Format	MPEG-4
Special Features	Two-way audio, Motion Detection, Sound Detection, Automatic Tracking, Invisible Night Vision, 360° PTZ, App Control, One-Click Call
Indoor/Outdoor Use	Indoor
Mounting Type	Tabletop (with wall mounting option)
Batteries Required	No
Item Dimensions	16.2 x 8 x 8 cm
Storage Options	TF Card (up to 256GB), Cloud Storage
UPC	658215565984

9. WARRANTY AND SUPPORT

The YESIMOM Baby Monitor Indoor WiFi Camera 8SM comes with a standard manufacturer's warranty. For detailed warranty information, please refer to the warranty card included in your package or visit the official YESIMOM website.

If you require technical assistance, have questions about your product, or need to report an issue, please contact YESIMOM customer support through the contact information provided on the official website or within the app. Please have your model number (8SM) and purchase details ready when contacting support.