

COCOMILA V10

COCOMILA V10 Electric Scooter Instruction Manual

Model: V10

1. INTRODUCTION

Thank you for choosing the COCOMILA V10 Electric Scooter. This manual provides essential information for the safe operation, assembly, maintenance, and troubleshooting of your scooter. Please read it thoroughly before your first ride to ensure optimal performance and safety.

The COCOMILA V10 is designed for adult use, featuring a powerful 500W motor, 10-inch pneumatic tires, and a dual braking system for a smooth and secure riding experience. It is foldable for easy transport and storage, and includes smart app control capabilities.

2. SAFETY INFORMATION

Your safety is paramount. Always adhere to local laws and regulations regarding electric scooter usage. This scooter has passed UL2272 certification tests, ensuring a high standard of electrical safety.

- **Wear a Helmet:** Always wear a certified helmet and other protective gear (knee pads, elbow pads) when riding.
- **Check Before Ride:** Before each use, inspect the brakes, tire pressure, and ensure all quick releases and fasteners are secure.
- **Road Conditions:** Ride on smooth, dry surfaces. Avoid riding in heavy rain, snow, or on slippery terrain.
- **Weight Limit:** Do not exceed the maximum weight limit of 265 pounds (120 kg).
- **Age Range:** This scooter is intended for adult use.
- **Visibility:** Utilize the bright front headlight and rear taillight, especially during low-light conditions, to enhance visibility.
- **Braking:** Familiarize yourself with the dual braking system (EABS and rear drum brake) for effective and controlled stopping.
- **Awareness:** Be aware of your surroundings, pedestrians, and other vehicles.

3. PACKAGE CONTENTS

The COCOMILA V10 Electric Scooter arrives 95% pre-assembled. The package typically includes:

- COCOMILA V10 Electric Scooter (partially assembled)
- Battery (integrated)
- Charger
- Necessary screws for final assembly
- User Manual

4. SETUP

The COCOMILA V10 Electric Scooter requires minimal assembly. Follow these steps to prepare your scooter for its first ride:

1. **Unpack:** Carefully remove all components from the packaging.
2. **Unfold the Scooter:** Lift the handlebar stem until it locks into the upright position. Ensure the folding mechanism is securely latched.
3. **Attach Handlebar:** Align the handlebar with the stem and secure it using the provided four screws. Ensure they are tightened firmly.
4. **Initial Charge:** Before first use, fully charge the scooter's battery. Connect the charger to the charging port and then to a power outlet. The indicator light on the charger will typically change from red to green when fully charged (approximately 4-5 hours).



Portable and 3S Folding Design



The scooter features a portable and 3-second folding design for easy transport and storage.

Long Press Turn on and off the machine



The 3-second folding system allows the scooter to be compactly stored in various spaces.

5. OPERATING INSTRUCTIONS

Power On/Off and Basic Controls

- **Power On/Off:** Long press the power button on the digital display to turn the scooter on or off.
- **Shift Gears:** Press the power button once (x1) to cycle through different speed modes.
- **Headlights:** Press the power button twice (x2) to turn the headlights on or off.
- **Start Mode:** Press the power button five times (x5) to switch between 0-start (kick-off required) and non-0 start (immediate acceleration).




Control functions are easily accessible from the handlebar display.

Riding

- **Acceleration:** Use the throttle lever to accelerate. The 500W motor provides speeds up to 25 MPH.
- **Braking:** The scooter is equipped with a dual braking system (EABS and rear drum brake). Apply the brake levers gently and progressively to slow down or stop.
- **Tires:** The 10-inch pneumatic tires offer shock absorption and a smooth ride on various urban terrains.
- **Lighting:** Bright front and rear lights ensure safety and visibility during night rides.



Bright lights enhance safety during nighttime operation.



The integrated lighting system illuminates your path and makes you visible.

3-SECOND FOLDING SYSTEM

After folded, the electric scooter is dramatically smaller and can easily fit into the trunk of a car, a subway rack, or an office locker



The dual braking system provides reliable stopping power.

6. SMART APP AND DIGITAL DISPLAY

The COCOMILA V10 features an integrated LED display and can connect to a smartphone app for enhanced control and monitoring.

- **LED Display:** The handlebar-mounted LED display shows real-time information such as current speed, remaining range, battery level, and cruise control status.
- **Smartphone App:** Connect your scooter to the dedicated smartphone app to access additional features:
 - Shift gears and adjust speed settings.
 - Switch lights on and off.
 - Lock or unlock the scooter for security.
 - Monitor riding status and personalized settings.
 - Receive automatic fault checks and battery health reports.
 - Access firmware updates and tutorials.

Bright Lights Make Your Ride Safer!



The digital display and smartphone app provide comprehensive control and information.

500W Powerful Motor

The 500W motor can provide sufficient power, making the electric scooter perform well when climbing and accelerating, suitable for various road conditions



The smartphone app offers advanced control and monitoring features.

7. MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your COCOMILA V10 Electric Scooter.

- **Battery Care:** Charge the 36V/10.5AH battery fully after each use. Avoid completely draining the battery. Store the scooter in a cool, dry place when not in use for extended periods.
- **Tire Pressure:** Periodically check the pressure of the 10-inch pneumatic tires. Maintain recommended pressure for optimal ride quality and range.
- **Brake Inspection:** Regularly inspect the brake levers, cables, and pads for wear and proper function. Adjust or replace components as needed.
- **Cleaning:** Clean the scooter with a damp cloth. Avoid using high-pressure water jets directly on electrical components.
- **Fasteners:** Check all screws and bolts periodically to ensure they are tight.



35 LBS Lightweight

Compact and lightweight volume makes the electric scooter in the crowd shuttle more flexible, especially in the traffic congestion in the city, to avoid the traffic jam trouble!

The 36V 10.5AH battery provides a long range and charges quickly.



Dual Braking System

Tested More than a few thousand times to stop progressively and safely.

The high-capacity battery allows for extended travel distances.

8. TROUBLESHOOTING

If you encounter issues with your COCOMILA V10 Electric Scooter, consider the following general troubleshooting steps. For more specific problems, refer to the smartphone app's fault check feature or contact customer support.

- **Scooter Not Turning On:** Ensure the battery is charged. Check that the power button is pressed and held sufficiently.
- **Reduced Range/Power:** Verify the battery is fully charged. Check tire pressure. Riding uphill or carrying heavy loads can reduce range.
- **Brakes Not Responsive:** Inspect brake cables for tension and wear. Ensure brake pads are not excessively worn.
- **Unusual Noises:** Check for loose components, debris in wheels, or issues with the motor.
- **App Connectivity Issues:** Ensure Bluetooth is enabled on your smartphone and the scooter is powered on and within range.

9. SPECIFICATIONS

Feature	Specification
Brand	COCOMILA
Model Name	V10
Motor Power	500W
Battery Capacity	36V/10.5AH
Maximum Speed	Up to 25 MPH
Maximum Range	Up to 22 Miles
Charging Time	4-5 Hours
Weight Limit	265 Pounds (120 kg)
Item Weight	31 Pounds (14 kg)
Wheel Size	10 Inches
Wheel Type	Pneumatic
Brake Style	Front Braking (EABS), Rear Braking (Drum)
Frame Material	Aluminum
Product Dimensions (LxWxH)	45.3" x 18" x 44.5"
Special Features	Digital Display, Dual Braking System, Foldable, Lightweight, Rechargeable

Commute



Family Scooters



Travelling



Gifts

The 500W motor provides strong performance for various road conditions.

POWERFUL BATTERY


36V/10.5AH
High-Capacity


16-22Miles
Max Range



4 Hours
Fast Charging


Over Charge
Protection



10-inch pneumatic tires offer a comfortable and stable ride.

10 Inch Air Tires


Water-resistant and anti-slip


Shock-absorbing


Durable material



The lightweight design (31 lbs / 14 kg) makes the scooter easy to carry.

10. WARRANTY AND SUPPORT

COCOMILA provides the following warranty for your V10 Electric Scooter:

- **Product Replacement:** Free replacement of the entire product within one month of purchase.
- **Battery and Charger:** Free replacement of batteries and chargers within six months of purchase.
- **Other Repair Parts:** Free replacement of other repair parts within one year of purchase.

If you have any questions, require assistance, or need to claim warranty service, please contact COCOMILA customer support. We are committed to providing timely and helpful support.