

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

> [ICEVOKE](#) /

> ICEVOKE 3-in-1 Water Cooler Dispenser with Ice Maker (Model BYCZ565B-0701) User Manual

ICEVOKE BYCZ565B-0701

ICEVOKE 3-in-1 Water Cooler Dispenser with Ice Maker (Model BYCZ565B-0701) User Manual

Your comprehensive guide to installation, operation, and maintenance.

1. INTRODUCTION

Thank you for choosing the ICEVOKE 3-in-1 Water Cooler Dispenser with Ice Maker. This appliance provides convenient access to hot, cold, and room-temperature water, along with a built-in ice maker. Please read this manual thoroughly before operation to ensure safe and efficient use.

2. SAFETY INSTRUCTIONS

WARNING: To reduce the risk of fire, electric shock, or injury, always follow basic safety precautions.

- Ensure the appliance is plugged into a grounded outlet.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Keep children away from the hot water dispenser. This unit features a child safety lock for hot water.
- Do not operate the appliance with a damaged cord or plug.
- Place the appliance on a flat, stable surface.
- Allow adequate ventilation around the unit. Do not block air vents.
- Use only 3 or 5-gallon water bottles designed for top-loading dispensers.
- Unplug the appliance before cleaning or maintenance.
- All materials in contact with water are food-grade certified.

3. PRODUCT OVERVIEW

The ICEVOKE 3-in-1 Water Cooler Dispenser combines a water dispenser with an integrated ice maker, offering versatility and convenience.

Key Features:

- **3 Temperature Settings:** Hot (>194°F), Cold (<50°F), and Room Temperature water.

- **Built-in Ice Maker:** Produces 9 bullet-shaped ice cubes in 7-15 minutes, up to 27 lbs per day.
- **Child Safety Lock:** Prevents accidental hot water dispensing.
- **Nightlight:** Illuminates the dispensing area for visibility in low light.
- **Easy-to-Use Control Panel:** Intuitive buttons for water dispensing and ice making.
- **Removable Drip Tray:** For easy cleaning.
- **Top-Loading Design:** Compatible with 3 or 5-gallon water bottles.
- **ETL, FCC, UL Certified:** Ensures safety and quality standards.

Components:




Figure 3.1: Front view of the ICEVOKE Water Cooler Dispenser, highlighting the control panel, water spouts, and the ice maker compartment with its door open, revealing bullet-shaped ice cubes.



Late Night Dispensing

No more refill misses. Softly lit night light makes dispensing in the dark easy and spill-free.


 Low Noise

Figure 3.2: Close-up of the control panel, showing buttons for Cold Water Dispense, Child Lock, Hot Water Dispense, Power, Add Water indicator, Heating, Cooling, and Ice-Making indicators.



Easy to Clean

Food-grade 304 Stainless Steel

Removable Drip Tray

Figure 3.3: Internal components for hygiene and convenience: Easy-to-clean water bottle receptacle, food-grade 304 stainless steel ice maker, and a removable drip tray.

4. SETUP

No installation is required for this water dispenser. It is a plug-and-play unit. Follow these steps to prepare your dispenser for first use:

1. **Unpacking:** Carefully remove the dispenser from its packaging. Place it upright on a flat, stable surface.
2. **Positioning:** Ensure there is adequate space around the unit for ventilation (at least 4 inches from walls).
3. **Water Bottle Installation:**
 - Remove the cap from a 3 or 5-gallon water bottle.
 - Carefully lift the water bottle and place it upside down onto the top-loading receptacle of the dispenser. Ensure it is seated firmly.
 - The dispenser will automatically begin filling its internal reservoirs.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet.
5. **Initial Priming:** Before dispensing, allow the unit to sit for at least 30 minutes to allow the water to fill the internal tanks and the compressor to settle.
6. **Activate Functions:** Turn on the heating, cooling, and ice-making functions using the respective buttons on the control panel. Allow sufficient time for water to reach desired temperatures and for ice production to begin (approx. 7-15 minutes for first ice batch).



Figure 4.1: The ICEVOKE Water Cooler Dispenser with a 5-gallon water bottle correctly installed on the top-loading receptacle.

Fast Ice Making

Only Need **7** Minutes

Product **9** Ice Cubes per Cycle

Auto-stop When Ice Basket is Full

Produces **27** lbs of Ice per Day

Bullet-shaped Ice to Prevent Sticking

Figure 4.2: Illustration of water input methods: Manually adding water to the ice maker compartment or using a top-loaded barreled water supply.

5. OPERATING INSTRUCTIONS

5.1 Dispensing Water

Place your cup on the drip tray. Select your desired water temperature by pressing the corresponding button on the control panel.

- **Cold Water:** Press the "Cold Water Dispense" button. The water will flow until the button is released.
- **Room Temperature Water:** Press the "Fresh Water" button. The water will flow until the button is released.
- **Hot Water:** This function has a child safety lock. To dispense hot water, first press and hold the "Child Lock" button, then press the "Hot Water Dispense" button. Release both buttons once the desired amount is dispensed.




Figure 5.1: The control panel showing the Child Lock feature, which must be engaged before dispensing hot water to prevent accidental burns.

5.2 Ice Making

The built-in ice maker automatically produces bullet-shaped ice cubes. The "Ice-Making" indicator light will be on when the unit is actively making ice.

- **Accessing Ice:** Open the lower compartment door to access the ice bin. A scoop is provided for convenience.
- **Automatic Shut-off:** The ice maker will automatically stop producing ice when the ice bin is full, indicated by sensors. Production will resume once ice is removed.

Two Ways to Add Water



Manually Adding Water
Making ice at your will.



Barreled Water Supply
Easy to observe water consumption.

Figure 5.2: The ice maker compartment, demonstrating the storage of bullet-shaped ice cubes and the included ice scoop.

5.3 Nightlight Function

The integrated nightlight illuminates the dispensing area, making it easy to use the dispenser in low-light conditions and preventing spills.



Figure 5.3: The water dispenser operating in a low-light environment, with its nightlight providing illumination for easy use.

5.4 Energy Saving Mode

Activate the ECO mode (if available on your model) to optimize energy consumption. Refer to the control panel for the ECO indicator.

5.5 Add Water Indicator

The "Add Water" indicator light will illuminate when the water bottle is empty and needs to be replaced.

5.6 Official Product Videos

Video 5.1: An overview of the ICEPURE 3-in-1 Water Cooler Dispenser with Ice Maker, demonstrating its features and functionality. This video is provided by the seller.

Video 5.2: A brief demonstration of the BYCZ623 water cooler with ice maker, showcasing its operation. This video is provided by the seller.

Video 5.3: An overview of the 3-in-1 LYCZ628W model, highlighting its features and design. This video is provided by the seller.



Video 5.4: A short video demonstrating the ice making process of the water cooler dispenser. This video is provided by the seller.

6. MAINTENANCE

Regular cleaning and maintenance will ensure the longevity and optimal performance of your dispenser.

- **Cleaning the Exterior:** Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners.
- **Drip Tray:** Regularly remove and empty the drip tray. Wash it with mild soap and water, then rinse and dry thoroughly before reinserting.
- **Ice Bin:** Periodically remove any remaining ice and clean the ice bin with a mild detergent solution. Rinse thoroughly to remove all soap residue.
- **Descaling (Recommended Annually):**
 - Unplug the unit and remove the water bottle.
 - Drain all water from the hot and cold tanks using the drain plugs at the back of the unit.
 - Prepare a descaling solution (e.g., a mixture of white vinegar and water, or a commercial descaling agent).
 - Pour the solution into the water reservoir and allow it to sit for 30-60 minutes.
 - Drain the solution completely and rinse the tanks multiple times with fresh water until no odor remains.
- **Air Vents:** Keep the air vents at the back of the unit clear of dust and debris to ensure proper cooling.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
No water dispensing.	Water bottle empty or not properly seated. Unit not plugged in or powered on.	Replace water bottle. Ensure unit is plugged in and power is on.
Water not hot/cold enough.	Heating/Cooling function not activated. Insufficient time for temperature change.	Ensure Heating/Cooling buttons are illuminated. Allow 15-30 minutes for water to reach desired temperature.
Ice maker not producing ice.	Ice-making function not activated. Water reservoir empty. Ice bin full.	Ensure Ice-Making button is illuminated. Check water bottle level. Empty ice bin if full.
Hot water child lock engaged.	Safety feature is active.	Press and hold the "Child Lock" button, then press the "Hot Water Dispense" button simultaneously.

Problem	Possible Cause	Solution
Unit is noisy.	Normal compressor operation. Unit not level.	Ensure unit is on a level surface. Some noise during cooling/ice-making is normal.

8. SPECIFICATIONS

Feature	Detail
Brand	ICEVOKE
Model Number	BYCZ565B-0701
Product Dimensions	14.4"D x 12.2"W x 40.8"H
Material	Acrylonitrile Butadiene Styrene (ABS), Stainless Steel
Water Capacity	Supports 3 or 5 Gallon Bottles
Ice Production	Up to 27 lbs per 24 hours (9 cubes in 7-15 mins)
Water Temperatures	Hot (>194°F), Cold (<50°F), Room Temperature
Certifications	ETL, FCC, UL
Color	Black

9. WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries, please refer to the product packaging or contact ICEVOKE customer service directly. Keep your purchase receipt as proof of purchase.