

FOHERE Ice Maker

FOHERE Countertop Ice Maker User Manual

Model: Ice Maker

Brand: FOHERE

1. PRODUCT OVERVIEW

The FOHERE Countertop Ice Maker is a portable and efficient appliance designed to produce bullet-shaped ice cubes quickly for various uses, from beverages to keeping food fresh. Its compact design makes it suitable for home, office, or portable use.



Figure 1: FOHERE Countertop Ice Maker. This image shows the sleek silver design of the ice maker with its transparent lid, indicating its compact and modern appearance suitable for any countertop.

Key Features:

- **Fast Ice Making:** Produces 9 bullet-shaped ice cubes in approximately 6 minutes.
- **High Capacity:** Capable of making up to 28 pounds of ice in 24 hours with a 1.2L water tank.
- **Two Ice Sizes:** Offers small and large bullet ice options for different needs.
- **Self-Cleaning Function:** Easy maintenance with an automatic self-cleaning cycle.
- **Portable Design:** Lightweight and compact, ideal for various settings.
- **User-Friendly Operation:** Simple control panel with indicator lights for water level and ice basket full.
- **Quiet Operation:** Operates at a low noise level, under 35dB.

2. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using the appliance to ensure safe and optimal performance. Keep this manual for future reference.

- Always connect the ice maker to a grounded power outlet.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Ensure the ice maker is placed on a stable, level surface, away from direct sunlight or heat sources.
- Do not block ventilation openings. Allow adequate space around the unit for proper air circulation.
- Use only potable water in the water reservoir.
- Unplug the appliance before cleaning or when not in use for extended periods.
- Keep children away from the ice maker during operation.
- Do not operate the appliance with a damaged cord or plug. Contact customer support for assistance.

3. WHAT'S IN THE BOX

Upon unpacking, please ensure all items are present and in good condition:

- FOHERE Countertop Ice Maker Unit
- Ice Scoop
- Removable Ice Basket
- User Manual (this document)

4. SETUP AND FIRST USE

4.1 Unpacking

Carefully remove the ice maker from its packaging. Remove all packing materials, tape, and labels. It is recommended to keep the original packaging for future storage or transport.

4.2 Placement

Place the ice maker on a flat, stable, and heat-resistant surface. Ensure there is at least 6 inches (15 cm) of space around the unit for proper ventilation. Avoid placing it near heat sources or in direct sunlight.

4.3 Initial Cleaning

Before first use, clean the interior of the ice maker. Follow these steps:

1. Remove the ice basket.
2. Clean the interior with a soft cloth and warm water with a mild detergent.
3. Rinse thoroughly and drain any remaining water.
4. Wipe the exterior with a damp cloth.

4.4 First Ice Making Cycle

For the first few cycles, the ice may be smaller or irregular. This is normal. Discard the first 3-5 batches of ice to ensure the system is fully purged and clean.

5. OPERATING INSTRUCTIONS

5.1 Adding Water

Open the lid and fill the water reservoir with potable water up to the MAX fill line. Do not overfill.

5.2 Powering On and Selecting Ice Size

Plug the ice maker into a grounded electrical outlet. The indicator lights will illuminate.

6 MINS FAST ICE MAKING



Figure 2: Fast Ice Making. This diagram illustrates the rapid ice production capability of the FOHERE ice maker, showing ice cubes forming within a 6-minute timeframe.

Press the "ON/OFF" button to start the ice making process. The default ice size is usually small. To change the ice size:

- Press the "SELECT" button (or corresponding button for size selection) to toggle between small and large ice cubes.
- The selected size indicator light will illuminate.

2 SIZES - MORE FUN

Small ice for juice/soda
Large ice for whisky/seafood



Figure 3: Two Sizes of Bullet Ice. This image displays the two available ice cube sizes, small and large, along with their approximate dimensions, highlighting their suitability for different beverages and uses.

5.3 Ice Production

The ice maker will begin producing ice. The first batch typically takes 6-10 minutes, with subsequent batches being faster.

The transparent window allows you to observe the ice-making process.

5.4 Indicator Lights

- **ADD WATER:** This light illuminates when the water reservoir is low. Add more water to continue ice production.
- **ICE FULL:** This light illuminates when the ice basket is full. Remove ice from the basket to resume production.

5.5 Stopping Operation

Press the "ON/OFF" button to stop the ice making process at any time. Unplug the unit when not in use.

6. MAINTENANCE AND CLEANING

6.1 Self-Cleaning Function

The FOHERE ice maker features a convenient self-cleaning function:

1. Ensure the water reservoir is filled with clean water.
2. Press and hold the "ON/OFF" button for approximately 5 seconds until the self-cleaning indicator light (if available) or a specific sound indicates the start of the cycle.
3. The self-cleaning cycle typically runs for about 15 minutes.
4. Once complete, drain the water from the unit by removing the drain plug (usually located at the bottom or side).
5. Wipe the interior dry with a clean cloth.

SELF-CLEANING HELPS A LOT



Figure 4: Self-Cleaning Function. This image illustrates the self-cleaning process, showing water circulating within the unit, activated by a single press and taking approximately 15 minutes.

6.2 Regular Cleaning

For optimal performance and hygiene, regular manual cleaning is recommended:

- Unplug the ice maker before cleaning.
- Remove the ice basket and clean it with warm, soapy water. Rinse and dry.
- Clean the interior water tank and ice collection area with a soft cloth and a solution of water and white vinegar (1:1 ratio) to prevent mineral buildup.
- Rinse thoroughly with clean water and drain completely.
- Wipe the exterior with a damp cloth. Do not use abrasive cleaners or solvents.
- Ensure all parts are dry before reassembling and storing or using the unit.

7. TROUBLESHOOTING

Before contacting customer support, please refer to the following table for common issues and their solutions:

| Problem | Possible Cause | Solution |
|----------------------------------|--|--|
| Ice maker not working / No power | Not plugged in; Power outage; Circuit breaker tripped. | Ensure unit is securely plugged in; Check power supply; Reset circuit breaker. |
| "ADD WATER" indicator on | Water reservoir is empty or low. | Fill the water reservoir with potable water up to the MAX line. |
| "ICE FULL" indicator on | Ice basket is full. | Remove ice from the basket. |
| Ice cubes are small or irregular | First few cycles; Water temperature too high; Air in system. | Discard first few batches; Use colder water; This is normal for initial operation. |
| Ice melts quickly | Ice maker is not a freezer; Ambient temperature too high. | Transfer ice to a freezer for storage; Place unit in a cooler environment. |
| Unusual noise during operation | Normal operation sounds (water pump, ice dropping); Unit not level; Fan obstruction. | Ensure unit is on a level surface; Check for obstructions around fan vents. If noise is excessive and persistent, contact support. |

8. SPECIFICATIONS

| Feature | Detail |
|--------------------------------|---|
| Model Name | Ice Maker |
| Brand | FOHERE |
| Product Dimensions (D x W x H) | 12.6" x 11.81" x 7.87" (32cm x 30cm x 20cm approx.) |
| Weight | Approximately 15 pounds |
| Ice Production Capacity | Up to 28 lbs per 24 hours |
| Water Tank Capacity | 1.2 Liters |

| Feature | Detail |
|-------------------|--------------|
| Ice Cube Shape | Bullet |
| Ice Cube Sizes | Small, Large |
| Rated Wattage | 120 watts |
| Noise Level | Under 35dB |
| Country of Origin | China |

LIGHTWEIGHT COUNTERTOP ICE MAKER



Figure 5: Lightweight Countertop Ice Maker Dimensions. This image provides a visual representation of the ice maker's compact size, comparing its dimensions to a standard A4 paper for scale, emphasizing its suitability for countertops.

ANTI-HEAT FOAMING LAYER




Figure 6: Anti-Heat Foaming Layer. This cutaway diagram illustrates the internal construction of the ice maker, highlighting the food-grade PP material interior, high-density ternary foaming layer, and premium ABS exterior, contributing to its insulation and durability.

9. WARRANTY AND SUPPORT

FOHERE products are manufactured to the highest quality standards. For warranty information, technical support, or service inquiries, please refer to the warranty card included with your product or visit the official FOHERE website. Please have your model number and purchase date ready when contacting support.

For further assistance, you may contact the seller directly via the platform where the product was purchased.

© 2025 FOHERE. All rights reserved.

This manual is for informational purposes only. Product specifications are subject to change without notice.