



[Manuals.plus](#) /

› [Eastman](#) /

› Eastman Washing Machine Drain Hose 60321N - 4 Foot, 3/4 Inch FHT Connection Instruction Manual

## Eastman 60321N

# Eastman Washing Machine Drain Hose 60321N - 4 Foot, 3/4 Inch FHT Connection

Instruction Manual

## INTRODUCTION

---

This manual provides essential information for the proper installation, operation, and maintenance of your Eastman 60321N Washing Machine Drain Hose. Please read these instructions carefully before use to ensure safe and efficient performance.

## SAFETY INFORMATION

---

- Always turn off the water supply to your washing machine before attempting any installation or maintenance.
- Ensure all connections are tight to prevent leaks. Do not overtighten.
- Inspect the hose regularly for signs of wear, cracks, or damage. Replace immediately if any damage is observed.
- This hose is designed for non-potable water applications.

## PRODUCT OVERVIEW

---

The Eastman 60321N Washing Machine Drain Hose is a durable, flexible black rubber hose designed for connecting washing machines to drainage systems or as a fill hose. It features 3/4 inch Female Hose Thread (FHT) connections on both ends, making it compatible with most standard washing machine outlets and valves.



4 ft.



## Black Rubber Washing Machine Hose

3/4 in. FHT x 3/4 in. FHT

Designed to connect hot and cold water supply lines to the washing machine

Image: The Eastman 4-foot black rubber washing machine hose, showing its 3/4 inch FHT connections at each end.

Your browser does not support the video tag.

Video: A product overview demonstrating the Eastman 4-foot washing machine drain hose, highlighting its features and flexibility.

## SPECIFICATIONS

<b>Brand</b>	Eastman
<b>Model Number</b>	60321N
<b>Material</b>	Rubber (EPDM)
<b>Color</b>	Black
<b>Item Length</b>	4 Feet (48 inches)
<b>Connection Type</b>	3/4 inch Female Hose Thread (FHT)
<b>Outside Diameter</b>	0.75 Inches

Maximum Pressure	200 PSI
Item Weight	8.8 ounces (249 Grams)




Image: A diagram illustrating the hose length and connection type.

## SETUP (INSTALLATION)

Follow these steps to properly install your Eastman Washing Machine Drain Hose:

- 1. Prepare the Area:** Ensure the washing machine is disconnected from power and the water supply is turned off. Position the washing machine to allow access to the drain outlet.
- 2. Connect to Washing Machine:** Take one end of the Eastman drain hose. Align the 3/4 inch FHT connection with the drain outlet on the back of your washing machine. Hand-tighten the connection until snug. Do not use tools to overtighten, as this can damage the threads.
- 3. Secure the Drain End:** The open end of the hose can be directed into a utility sink, a standpipe, or a floor drain. Ensure the hose is securely positioned to prevent it from dislodging during the wash cycle. Use a hose clamp or a U-bend bracket if necessary (not included) to keep the hose in place and prevent siphoning.
- 4. Check for Leaks:** Once connected, slowly turn on the water supply to the washing machine and

check for any leaks at the connection points. If leaks occur, tighten the connections slightly until they stop.

5. **Restore Power:** Reconnect the washing machine to power.

## Compatible with most washing machine brands



### Easy Installation

Equipped with 3/4 in. FHT brass nuts connection for easy installation



### Performance

Working temperature 40°F to 158°F  
Working pressure 200 psi  
Burst pressure 800 psi



Image: Demonstrating the connection of the hose to a washing machine's water inlet.



## Durable

Heavy-duty black rubber construction is designed to withstand many hours of use



Image: Another view of the hose being connected to a washing machine's water inlet.

## OPERATING

---

Once installed, the Eastman Washing Machine Drain Hose operates passively as part of your washing machine's water system. It is designed to handle both hot and cold water temperatures typically found in washing machine cycles. Ensure the hose is not kinked or crimped during operation to maintain proper water flow and prevent damage.

## MAINTENANCE

---

Regular maintenance helps prolong the life of your drain hose and prevents potential issues:

- **Visual Inspection:** Periodically check the entire length of the hose for any visible signs of wear, cracks, bulges, or leaks. Pay close attention to the areas near the connections.
- **Connection Check:** Ensure the hose connections remain tight. If you notice any dripping, gently tighten the connection by hand.
- **Prevent Kinks and Crimps:** Avoid bending the hose sharply, especially behind the washing machine. The flexible rubber construction is designed to resist kinking, but extreme bends can still cause damage over time.

- **Cleaning:** If necessary, wipe down the exterior of the hose with a damp cloth. Do not use harsh chemicals or abrasive cleaners.



## Black Rubber Hose

- Withstands high pressure and corrosion
- Prevent leaking, kinking and crimping

Image: The flexible black rubber hose, demonstrating its ability to resist kinking and crimping.

### TROUBLESHOOTING

---

If you encounter issues with your Eastman Washing Machine Drain Hose, consider the following:

- **Leaks at Connections:** If water is leaking from the hose connections, ensure they are hand-tightened securely. Check if the rubber washers inside the FHT connections are properly seated and not damaged. Replace washers if necessary.
- **Reduced Water Flow/Drainage:** Ensure the hose is not kinked or crimped, which can restrict flow. Check for any obstructions in the hose or the washing machine's drain outlet.
- **Hose Damage:** If the hose shows any signs of physical damage (e.g., cracks, punctures, severe wear), it must be replaced immediately to prevent water damage.

For issues related to the washing machine itself, refer to your washing machine's instruction manual.

### WARRANTY AND SUPPORT

---

For warranty information or technical support regarding your Eastman Washing Machine Drain Hose, please refer to the official Eastman website or contact Eastman customer service directly. Keep your purchase receipt as proof of purchase.