



Manuals.plus /

› Fanbulous /

› Fanbulous 65-Inch Farmhouse Ceiling Fan (Model F-QJ65BK-1D01) Instruction Manual

Fanbulous F-QJ65BK-1D01

Fanbulous 65-Inch Farmhouse Ceiling Fan (Model F-QJ65BK-1D01) Instruction Manual

Model: F-QJ65BK-1D01

1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before beginning installation and save this manual for future reference. Improper installation or use can lead to electric shock, fire, or personal injury. Always consult a qualified electrician if you are unsure about any part of the installation process.

- Ensure the power supply is disconnected at the main circuit breaker before installation or maintenance.
- All wiring must be in accordance with national and local electrical codes.
- The mounting bracket must be securely fastened to a ceiling joist or a suitable support structure capable of supporting the fan's weight.
- Maintain a minimum clearance of 7 feet from the floor to the fan blades.
- Do not operate the fan if any part is damaged.

2. PACKAGE CONTENTS

Verify that all components are present and undamaged before proceeding with installation. If any parts are missing or damaged, contact customer support.



Image: Overview of all Fanbulous 65-inch ceiling fan components and hardware.

- Motor and Housing
- Fan Blades (8 reversible blades: walnut/light oak)
- Blade Arms
- Downrods (5-inch, 10-inch, 15-inch options)
- Canopy and Coupling Cover
- Hanger Bracket
- Light Fixture (Seeded Glass Lampshade)
- Remote Control and Receiver
- Hardware Pack (screws, washers, wire nuts)
- User Manual

3. SETUP AND INSTALLATION

Follow these steps for proper assembly and installation. It is recommended to have a second person assist during the mounting process due to the fan's size and weight.

3.1 Blade Assembly

1. Attach each fan blade to a blade arm using the provided screws and washers. Ensure they are securely fastened.
2. Mount the assembled blade arms to the motor housing, tightening all screws firmly.

Your browser does not support the video tag.

Video: Detailed steps for assembling the fan blades to the motor housing.

3.2 Downrod Installation

1. Select the appropriate downrod length (5-inch, 10-inch, or 15-inch) for your ceiling height.
2. Thread the electrical wires from the motor through the chosen downrod.
3. Insert the downrod into the motor's yoke, aligning the holes. Secure with the downrod pin and clip.
4. Tighten the two screws on the yoke to firmly secure the downrod.
5. Slide the canopy cover and coupling cover onto the downrod.



Image: Guide for selecting the correct downrod length based on ceiling height.

3.3 Mounting the Fan

1. Mount the hanger bracket securely to the ceiling junction box using appropriate screws for your ceiling type (wood screws for wooden ceilings, expansion screws for concrete ceilings).
2. Carefully lift the fan assembly and hang the downrod onto the hanger bracket, ensuring the tab on the downrod ball aligns with the slot in the bracket.
3. Connect the fan's electrical wires to the household wiring: Neutral (white) to white, Live (black) to black, and Ground (green or yellow/green) to green. Use wire nuts to secure connections.
4. Place the remote receiver unit into the hanger bracket.
5. Push the canopy cover upward and rotate it to align with the screws on the hanger bracket. Tighten the screws to secure the canopy.

Your browser does not support the video tag.

Video: Installation guide for a 65-inch farmhouse ceiling fan, demonstrating mounting and wiring.

Your browser does not support the video tag.

Video: Demonstrates the correct installation position for the receiver box within the hanger bracket.

3.4 Light Kit Installation

1. Connect the light kit wires to the corresponding wires from the motor.
2. Align the light kit with the screw holes on the motor housing and secure it with the provided screws.
3. Install E26 base A19 bulbs (bulbs not included) into the light sockets.



Image: The light kit is compatible with E26 base bulbs (not included).

4. OPERATING INSTRUCTIONS

Your Fanbulous ceiling fan is operated by a multi-function remote control.

4.1 Remote Control Functions



Image: Remote control with various functions for fan and light operation.

- **Fan ON/OFF:** Turns the fan on or off.
- **Fan Speed (1-6):** Adjusts the fan speed from a gentle breeze (1) to a powerful airflow (6).
- **Light ON/OFF:** Turns the light kit on or off.
- **Reverse Function (F/R):** Changes the direction of the fan blades for summer (downward airflow) or winter (upward airflow) modes.
- **Timer (1H/4H/8H):** Sets the fan to automatically turn off after 1, 4, or 8 hours.
- **Mute:** Silences remote beeps.

4.2 Reversible DC Motor

The fan features an energy-efficient DC motor with a reversible function for year-round comfort.

Effortless Installation: Simple Setup No Hassle

✔ 1 Hour to Finish

✔ Less electrician fee



Image: Reversible DC motor function for optimal air circulation in summer and winter.

- **Summer Mode:** Set the fan to rotate counter-clockwise for a downward airflow, creating a cooling effect.
- **Winter Mode:** Set the fan to rotate clockwise for an upward airflow, circulating warm air trapped near the ceiling.

5. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:** Use a soft, damp cloth to clean the fan blades and motor housing. Do not use abrasive cleaners or solvents.
- **Light Kit:** Ensure the light kit is clean and free of dust. Replace bulbs as needed.
- **Tighten Screws:** Periodically check all screws on the fan assembly and mounting bracket to ensure they are tight.

6. TROUBLESHOOTING

If you experience issues with your fan, refer to the common problems and solutions below. If the problem persists, contact customer support.

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Remote battery low.	Check circuit breaker; Verify all wire connections are secure; Replace remote battery.
Fan wobbles	Loose blade screws; Unbalanced blades; Loose mounting bracket.	Tighten all blade screws; Use a balancing kit (not included) to balance blades; Ensure mounting bracket is secure.
Light does not work	Loose light kit wires; Faulty bulbs; No power to light kit.	Check light kit wire connections; Replace bulbs; Verify power to the light kit.
Noisy operation	Loose screws; Fan not properly seated in hanger bracket; Motor noise.	Tighten all screws; Ensure downrod is correctly seated in the hanger bracket; DC motor is designed for quiet operation (below 35dB).

7. SPECIFICATIONS

Detailed technical specifications for your Fanbulous ceiling fan.

- **Model Name:** F-QJ65BK-1D01
 - **Brand:** Fanbulous
 - **Size:** 65 inches
 - **Product Dimensions:** 65"D x 65"W x 16.4"H
 - **Item Weight:** 22 Pounds
 - **Color:** Black
 - **Motor Type:** Brushless DC Motor
 - **Power Source:** DC
 - **Voltage:** 120 Volts
 - **Wattage:** 36 Watts
 - **Number of Power Levels:** 6
 - **Control Method:** Remote Control
 - **Installation Type:** Ceiling Mount with Adjustable Height and Angle (supports tilt installation up to 15°)
 - **Indoor/Outdoor Usage:** Indoor
 - **Special Features:** LED Light (E26 base, bulbs not included), Remote Controlled, Timer, Reversible Motor
-

8. WARRANTY AND SUPPORT

Your Fanbulous ceiling fan comes with comprehensive support and warranty coverage.

- **Warranty:** This modern ceiling fan includes a 2-year warranty.
 - **Customer Support:** 24-hour customer support is available to ensure quick resolution of any issues.
-