

[manuals.plus](#) /

› [sajawass](#) /

› [sajawass Wireless Earbuds BX31 User Manual](#)

## sajawass BX31

# sajawass Wireless Earbuds BX31 User Manual

Model: BX31 | Brand: sajawass

## 1. PACKAGE CONTENTS

Verify that all items are present in your product package:



Image: Contents of the sajawass Wireless Earbuds BX31 package, including earbuds, charging case, eartips, Type-C cable, and user manual.

- Wireless Earbuds (L/R)
- Charging Case
- S, M, L Eartips (one set pre-installed)
- Type-C Charging Cable
- User Manual

## 2. PRODUCT OVERVIEW

The sajawass BX31 Wireless Earbuds are designed for comfort and performance, featuring an ergonomic over-ear hook design and a portable charging case with an LED power display.



Image: Black sajawass Wireless Earbuds BX31 resting in their open charging case, displaying the battery level on the front LED screen.

## Key Features:

- Bluetooth 5.3 for stable connectivity
- ENC Noise Reduction for clear calls
- IPX7 Waterproof rating
- Up to 75 hours total playtime with charging case
- LED Digital Power Display on charging case
- Ergonomic over-ear hook design
- Smart Touch Controls

## 3. GETTING STARTED

### 3.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and charging case.



Image: Visual representation of the charging case's LED display showing battery percentage and individual earbud charge status. Details on 8 hours playtime per charge and 75 hours total with the case.

1. Connect the provided Type-C charging cable to the charging port on the case and a USB power adapter (not included).
2. The LED digital display on the charging case will show the battery percentage during charging.
3. Place the earbuds into the charging case. The individual earbud battery indicators on the case will show their charging status.
4. A full charge for the case and earbuds typically takes approximately 1.5 hours.

The earbuds provide over 8 hours of playtime on a single charge, and the charging case extends the total playtime to 75 hours.

### 3.2 Powering On/Off

- **Power On:** Open the charging case, and the earbuds will automatically power on. Alternatively, long-press the touch area on both earbuds for 3 seconds.
- **Power Off:** Place the earbuds back into the charging case and close the lid. They will automatically power off and begin charging. Alternatively, long-press the touch area on both earbuds for 5 seconds.

### 3.3 Bluetooth Pairing

1. Ensure the earbuds are charged and powered on.
2. Enable Bluetooth on your device (smartphone, tablet, etc.).
3. Search for "BX31" in the list of available Bluetooth devices.
4. Select "BX31" to connect. Once connected, you will hear a confirmation prompt.
5. The earbuds will automatically reconnect to the last paired device when taken out of the case, if Bluetooth is enabled on the device.

### 3.4 Wearing the Earbuds

For optimal sound quality and comfort, choose the correct eartip size and adjust the ear hooks.




Image: A woman wearing the sajawass Wireless Earbuds BX31, illustrating how the over-ear hook design provides a stable and secure fit during activity.

1. Select the eartips (S, M, L) that provide a snug and comfortable seal in your ear canal.
2. Place the earbud into your ear, then gently hook the ear hook over your ear.
3. Adjust the earbud and hook until it feels secure and comfortable.

## 4. OPERATING INSTRUCTIONS

### 4.1 Touch Controls

The earbuds feature sensitive touch controls for various functions:



Image: A detailed diagram showing the touch control functions for the sajawass Wireless Earbuds BX31, including play/pause, volume, track skipping, call management, and voice assistant activation.

- **Play/Pause:** Single tap R/L earbud.
- **Next Track:** Double tap R earbud.
- **Previous Track:** Double tap L earbud.
- **Volume Up:** Long tap R earbud.
- **Volume Down:** Long tap L earbud.
- **Answer/End Call:** Single tap R/L earbud.
- **Reject Call:** Long tap R/L earbud.
- **Activate Voice Assistant:** Triple tap R/L earbud.

## 4.2 Mono/Twin Mode

The earbuds support both mono (single earbud) and twin (both earbuds) modes. You can use either earbud independently for calls or music, or use both for a stereo experience.

## 5. CARE AND MAINTENANCE

### 5.1 Cleaning

Regular cleaning helps maintain optimal performance and charging efficiency.

- Clean the charging contacts on both the earbuds and the charging case regularly.
- Remove any sweat, perspiration, or dirt from the charging contacts to prevent charging failures.
- Use a soft, dry cloth or cotton swab for cleaning. Avoid using abrasive materials or harsh chemicals.

### 5.2 Water Resistance

The earbuds feature an IPX7 nano-coating, providing protection against sweat and splashes. They are suitable for workouts and outdoor activities.

- Do not submerge the earbuds in water.
- Ensure the earbuds are dry before placing them back into the charging case to prevent damage.

## 6. TROUBLESHOOTING

### 6.1 Earbuds Not Charging

- Ensure the charging cable is securely connected to both the case and the power source.
- Verify that the charging case has sufficient battery charge.
- Clean the charging contacts on both the earbuds and inside the charging case.
- Ensure the earbuds are correctly seated in the charging slots.

### 6.2 Earbuds Not Pairing/Connecting

- Make sure Bluetooth is enabled on your device.
- Ensure the earbuds are powered on and in pairing mode (usually indicated by a flashing light).
- Forget or delete "BX31" from your device's Bluetooth list and attempt to pair again.
- Move the earbuds closer to your device and away from potential interference sources.
- Try resetting the earbuds (refer to manufacturer's website for specific reset instructions if needed).

### 6.3 Low Volume or Poor Sound Quality

- Adjust the volume on both your device and the earbuds.
- Ensure the eartips provide a proper seal in your ear. Try different sizes.
- Clean any debris from the earbud speaker mesh.
- Ensure the earbuds are fully charged.


## 7. SPECIFICATIONS


Feature	Specification
---------	---------------

Model Name	BX31
Brand	sajawass
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.4
Bluetooth Range	Up to 15 meters (49 feet)
Ear Placement	In Ear with Over Ear Hook
Noise Control	Environmental Noise Cancellation (ENC)
Water Resistance	IPX7
Control Type	Touch Control
Earbud Playtime (Single Charge)	Over 8 hours
Total Playtime (with Charging Case)	Up to 75 hours
Charging Time	Approx. 1.5 hours (earbuds & case)
Charging Port	Type-C
Material	Plastic
Item Weight	0.13 Kilograms (4.6 ounces)

© 2025 sajawass. All rights reserved.

## Related Documents - BX31

	<p><a href="#"><b>SYNYQ HD65 Wireless Earbuds: Instruction Manual &amp; Safety Guide</b></a></p> <p>Comprehensive instruction manual for SYNYQ HD65 wireless earbuds, covering connection, operation, troubleshooting, and safety guidelines. Learn how to pair, control playback, manage calls, and maintain your earbuds.</p>
	<p><a href="#"><b>Crestron Flex Unified Communications Solutions Product Manual</b></a></p> <p>This comprehensive product manual provides detailed information and instructions for setting up and using Crestron Flex Unified Communications Solutions. It covers various room designs, software configurations for Microsoft Teams Rooms and Zoom Rooms, and open-platform UC applications. The manual includes specifications, dimension drawings, installation guides, and troubleshooting tips for a range of Crestron Flex products.</p>



## [GIB Bracing Software, DeLonghi Radiators, BAXI Boilers & Metrofires Flue Systems](#)

A compilation of technical documents, product brochures, and installation guides covering structural bracing software, DeLonghi radiators, BAXI gas boilers, and Metrofires flue systems for building and home heating applications.



## [Crestron Flex Getting Started Guide](#)

A comprehensive guide to deploying, configuring, and managing Crestron Flex conference room solutions for Microsoft Teams Rooms and Zoom Rooms, including pre-deployment checklists, hardware information, and troubleshooting resources.