

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [addlon](#) /

> [addlon 52-inch Flush Mount Ceiling Fan with Light Instruction Manual \(Model KFM52WOO3B01R1-D\)](#)

addlon KFM52WOO3B01R1-D

addlon 52-inch Flush Mount Ceiling Fan with Light Instruction Manual

Model: KFM52WOO3B01R1-D

1. INTRODUCTION

This manual provides detailed instructions for the safe installation, operation, and maintenance of your new addlon 52-inch Flush Mount Ceiling Fan with Light. Please read all instructions carefully before beginning installation and retain this manual for future reference.

2. SAFETY INFORMATION

Risk of Electric Shock

- Before installing this ceiling fan, disconnect the power supply by turning off the circuit breaker.
- All electrical connections must be in accordance with local and National Electric Code (N.E.C.) standards and ANSI/NFPA 70.
- Consult a qualified electrician if you are unfamiliar with proper electrical wiring connections.
- Do not alter, re-locate, or remove wiring when nothing goes wrong with the product.
- Double-check all connections and screws to ensure they are tight and correct.
- Verify that the supply voltage is correct by comparing it with the product information.
- To avoid fire, shock, and serious personal injury, please read the following instructions carefully.

Important Safety Instructions

- Before installing the fan, disconnect the power by removing fuses or turning off circuit breakers.
- Ensure the installation site allows a minimum of 7.5 feet from the blades to the floor.



Image: Illustration of a circuit breaker being turned off to disconnect power, emphasizing safety before installation.

3. ACCESSORIES LIST

Please check the contents of the package against the list below to ensure all parts are present and undamaged.



Image: All components of the addlon 52-inch Flush Mount Ceiling Fan with Light, including blades, motor, light kit, remote, and mounting hardware, laid out on a table.

- Ceiling Fan Motor Assembly
- 3 Wood Blades
- Light Kit
- Remote Control (2 included for 2-pack)
- Mounting Hardware (screws, wire nuts, etc.)
- Instruction Manual

4. INSTALLATION INSTRUCTIONS (FLUSH MOUNT)

This section details the installation process for the flush mount ceiling fan. For visual guidance, please refer to the installation video below.

Your browser does not support the video tag.

Video: Detailed installation guide for the addlon 52-inch Wood Ceiling Fan with Light (Flush Mount version).

4.1. Prepare for Installation

1. **Disconnect Power:** Before starting, ensure the power supply to the installation area is turned off at the circuit breaker.

2. **Remove Motor Protection Plates:** Carefully remove the three motor protection plates from the motor assembly.

4.2. Install the Ceiling Bracket

3. **Remove Existing Bracket:** If an existing bracket is present, remove it.
4. **Secure New Bracket:** Use appropriate screws (provided) to securely attach the addlon ceiling bracket to your ceiling junction box. Ensure it is firmly mounted.

4.3. Wiring the Fan

5. **Hang Motor for Wiring:** Carefully hang the motor assembly to the ceiling bracket using the provided safety cable to support its weight during wiring.
6. **Connect Wires:** Connect the fan's wires to your household wiring using the wire nuts. Ensure connections are tight and wires of the same color are connected (e.g., White to Neutral, Black to Live, Green to Ground).
7. **Insert Controller:** Place the controller into the bracket and organize the wires neatly.

4.4. Mount the Motor Assembly

8. **Align and Secure:** Align the screw on the bracket with the L-shape slot hook in the canopy. Slightly rotate the fan body to make it sit in position.
9. **Tighten Screws:** Install the two screws and tighten all four screws on the sides to secure the motor assembly to the ceiling bracket.

4.5. Attach the Blades

10. **Install Blades:** Install each of the three wooden blades using two screws per blade. Ensure spacers are used on all screws for proper alignment and stability.
11. **Tighten All Screws:** After installing all three blades, tighten all six screws to ensure stability.

4.6. Install the Light Kit

12. **Unscrew for Light Kit:** Unscrew the three pre-installed screws on the motor for future use.
13. **Connect Light Kit:** Plug the terminal pairs of the light kit tightly.
14. **Secure Light Kit:** Put the three removed screws back in and tighten them to secure the light kit.
15. **Test Light:** Turn on the switch and select the desired color temperature before installing the light cover.
16. **Attach Light Cover:** Attach the decorative light cover to the light kit by twisting it clockwise until it snaps into place.

5. OPERATING INSTRUCTIONS

Your addlon ceiling fan is designed for ease of use with the included remote control. Familiarize yourself with its functions for optimal comfort.

5.1. Remote Control Functions

Remote Control




Image: Detailed diagram of the addlon remote control, showing buttons for fan speed, fan off, forward/reverse, security, natural wind, light dimmer, light color temperature, light on/off, and timer settings.

- **Fan Speed (1-6):** Adjust fan speed from low (1) to high (6).
- **Fan OFF:** Turns the fan off.
- **Forward/Reverse:** Changes the direction of blade rotation for seasonal use.
- **Light ON/OFF:** Turns the light on or off.
- **Light Dimmer (+/-):** Adjusts the brightness of the light (10%-100%).
- **Light Color Temperature:** Cycles through 3000K (Warm White), 4500K (Natural White), and 6000K (Cool White).
- **Timer (1H/2H/4H):** Sets the fan to automatically turn off after 1, 2, or 4 hours.
- **Security Function:** Turns the light on every 2 hours for 5 minutes.
- **Natural Wind:** Simulates natural breeze by varying fan speed.

5.2. Fan Speed Selection

6 Speeds Selectable




Image: Visual representation of the 6 selectable fan speeds, categorized as Low Comfortable Wind (Level 1-2), Medium Natural Wind (Level 3-4), and High Cooling Wind (Level 5-6).

The fan offers 6 speed settings to suit your comfort needs:

- **Levels 1-2:** Low Comfortable Wind
- **Levels 3-4:** Medium Natural Wind
- **Levels 5-6:** High Cooling Wind

5.3. Customizable Light

Customizable Light



Image: Demonstrates the dimmable light feature (10%-100%) and the three color temperature options: 3000K, 4500K, and 6000K. The integrated LED light is both dimmable (10%-100%) and offers three color temperature options:

- **3000K:** Warm White
- **4500K:** Natural White
- **6000K:** Cool White

5.4. Reversible DC Motor

Reversible DC Motor



Image: Illustrates the reversible DC motor function, showing downward airflow for cooling in summer and upward airflow for improved air circulation in winter.

The reversible DC motor allows for year-round use:

- **Summer Mode:** Downward airflow creates a cooling effect.
- **Winter Mode:** Upward airflow circulates warm air, improving heating efficiency.

5.5. Quiet Operation



Image: Graph comparing noise levels, showing the addlon fan operating at approximately 20dB, significantly quieter than typical city noise (80dB) or normal conversation (50dB).

The advanced DC motor ensures a quiet operation, contributing to a peaceful environment.

6. MAINTENANCE

Regular maintenance helps ensure the longevity and optimal performance of your ceiling fan.

- **Cleaning:** Use a soft, damp cloth to clean the fan blades and motor housing. Do not use abrasive cleaners or solvents.
- **Check Connections:** Periodically check all screws and connections to ensure they are secure.
- **Blade Balance:** If the fan wobbles, ensure all blades are securely attached and balanced.

7. TROUBLESHOOTING

If you encounter any issues with your fan, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not start	No power supply; Loose wiring; Remote control issue.	Check circuit breaker; Verify all wire connections are secure; Replace remote batteries.

Problem	Possible Cause	Solution
Light does not work	Loose light kit connection; Faulty LED.	Check light kit wiring; Contact customer support if LED is faulty.
Fan wobbles	Loose blades; Unbalanced blades; Loose mounting bracket.	Ensure all blade screws are tight; Use balancing kit (not included) if necessary; Tighten mounting bracket screws.
Remote not working	Dead batteries; Remote not paired.	Replace AAA batteries; Refer to remote pairing instructions in the manual.

8. SPECIFICATIONS

Feature	Detail
Brand	addlon
Model Name	KFM52WOO3B01R1-D
Size	52 inch
Style	Flush Mount
Blades	3 Wood Blades
Motor Type	Reversible DC Motor
Fan Speeds	6 levels
Light Features	3 Color Temperature (3000K/4500K/6000K), Dimmable (10%-100%)
Control Method	Remote Control
Timer	1/2/4 hour sleep shutdown
Indoor/Outdoor Usage	Indoor, Outdoor (Damp Rated, not for direct rain exposure)
Voltage	120 Volts
Wattage	50 watts
Item Weight	22 pounds
UPC	850076255831

9. WARRANTY AND SUPPORT

addlon is committed to customer satisfaction. We offer comprehensive warranty and support services for your product.

- **Motor Warranty:** Up to 120 months (10 years) warranty on the motor.
- **Other Parts Warranty:** 2 years warranty on the rest of the fan components.
- **Customer Support:** We offer 24-hour customer support. Please feel free to contact us with any questions you may have during installation or use.