

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [dormzie](#) /

› [dormzie Cordless Tire Inflator Portable Air Compressor User Manual](#)

dormzie Cordless Tire Inflator Portable Air Compressor

dormzie Cordless Tire Inflator Portable Air Compressor User Manual

Model: Cordless Tire Inflator Portable Air Compressor

INTRODUCTION

Thank you for choosing the dormzie Cordless Tire Inflator Portable Air Compressor. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new device. Please read this manual thoroughly before use and retain it for future reference.

This portable air compressor is designed for inflating tires on cars, motorcycles, bicycles, and various balls, offering convenience with its cordless design and rechargeable battery.

PACKAGE CONTENTS

- dormzie Cordless Tire Inflator Portable Air Compressor
- Rechargeable Battery
- 12V Car Power Adapter
- Air Hose with Tire Pressure Gauge
- Various Nozzle Adapters (e.g., for balls, bicycles)
- User Manual

SAFETY INSTRUCTIONS

Always observe the following safety precautions to prevent injury or damage to the device:

- Do not leave the inflator unattended during operation.
- Keep out of reach of children.
- Do not operate in wet conditions or near flammable liquids/gases.
- Ensure the correct pressure setting for the item being inflated to avoid over-inflation.
- Allow the device to cool down after extended use to prevent overheating.
- Use only the provided charging accessories.

SETUP

Charging the Battery

Before first use, fully charge the rechargeable battery. Connect the provided 12V car power adapter to the inflator's charging port and plug it into a compatible 12V car outlet. The charging indicator light will show the charging status. A full charge typically takes X hours (refer to specific product specifications for exact time).

Attaching the Air Hose

Screw the air hose securely onto the inflator's air outlet. Ensure a tight connection to prevent air leakage during operation.



Image: A placeholder image indicating that no specific product image is available for display. This space would typically show the dormzie Cordless Tire Inflator with its air hose attached.

OPERATING INSTRUCTIONS

1. Power On

Press the power button to turn on the inflator. The digital display will illuminate, showing the current pressure reading.

2. Select Unit and Set Target Pressure

Use the 'UNIT' button to cycle through pressure units (PSI, BAR, KPA, KG/CM²). Use the '+' and '-' buttons to set your desired target pressure. Refer to your vehicle's or item's recommended pressure specifications.

3. Connect to Valve

Screw the air hose nozzle onto the tire valve stem. For other items like balls or bicycle tires, attach the appropriate nozzle adapter before connecting.

4. Start Inflation

Press the 'START/STOP' button to begin inflation. The inflator will automatically stop once the preset pressure is reached.

5. Disconnect and Power Off

Once inflation is complete, quickly disconnect the nozzle from the valve. Press the power button to turn off the device.

MAINTENANCE

- Cleaning:** Wipe the exterior of the inflator with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- Storage:** Store the inflator in a cool, dry place away from direct sunlight and extreme temperatures. Ensure the battery is partially charged before long-term storage.
- Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Recharge the battery every 3-6 months if not in regular use.
- Hose Inspection:** Regularly inspect the air hose and nozzle for any signs of wear, cracks, or damage. Replace if necessary.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Inflator does not turn on.	Battery is depleted.	Charge the battery fully.
Inflator stops before reaching target pressure.	Overheating protection activated.	Allow the device to cool down for 10-15 minutes before resuming operation.
Air leaks during inflation.	Hose not securely attached or damaged.	Ensure hose is tightly screwed onto the inflator and valve. Inspect hose for damage and replace if necessary.
Inaccurate pressure reading.	Gauge calibration issue or external factors.	Ensure the gauge is clean. Compare reading with a known accurate gauge. If persistent, contact support.

SPECIFICATIONS

Model: Cordless Tire Inflator Portable Air Compressor

Brand: dormzie

Max Pressure: 150 PSI

Power Source: Rechargeable Battery / 12V Car Power Adapter

Display: Digital Pressure Gauge

Units: PSI, BAR, KPA, KG/CM²

Automatic Shut-off: Yes

WARRANTY AND SUPPORT

dormzie products come with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions, including warranty period and coverage details.

For technical support, troubleshooting assistance, or warranty claims, please contact dormzie customer service. Contact information can typically be found on our official website or on the product packaging.


Note: Keep your purchase receipt as proof of purchase for warranty purposes.

© 2025 dormzie. All rights reserved.

This manual is subject to change without notice.

Related Documents - Cordless Tire Inflator Portable Air Compressor

	<u>VXSCAN ATJ-8766 Portable Air Compressor User Guide</u> Comprehensive user guide for the VXSCAN ATJ-8766 portable tire inflator. Learn to use this 150 PSI fast-inflation air pump for cars, motorcycles, bikes, balls, and balloons, featuring a 15000mAh battery and 12V DC power.
-------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

	<p><u>OlarHike Portable Tire Inflator User Manual</u></p> <p>Comprehensive user manual for the OlarHike Portable Tire Inflator (Model TPP5V101), covering packaging contents, tire pressure references, product and display overview, operating instructions, charging, troubleshooting, specifications, safety guidelines, and warranty information.</p>
	<p><u>AUTDER Wireless Portable Air Compressor FC-368 User Manual</u></p> <p>This manual provides instructions and safety precautions for the AUTDER Wireless Portable Air Compressor, model FC-368. Learn how to charge the battery, connect and use the device, and understand its technical specifications.</p>
	<p><u>Merece CZK-3659 Portable Car Tire Inflator User Manual</u></p> <p>User manual for the Merece CZK-3659 portable car tire inflator. Provides instructions on usage, safety, specifications, and troubleshooting for efficient tire inflation.</p>
	<p><u>AstroAI ATJ-8366 Multifunctional Air Compressor User Manual</u></p> <p>Comprehensive user manual for the AstroAI ATJ-8366 Multifunctional Air Compressor, detailing features, instructions for tire mode and large-volume mode, troubleshooting, specifications, and warranty information. Supports AC/DC power and inflates various items like car tires, motorcycles, and bicycles.</p>
	<p><u>AstroAI 250 PSI Tire Inflator Gauge - User Manual and Specifications</u></p> <p>User guide and specifications for the AstroAI 250 PSI Tire Inflator Gauge, detailing its diagram, instructions for inflating tires with an air compressor, technical specifications, and package contents.</p>