

[manuals.plus](#) /› [Rapoo](#) /› [Rapoo 9050S Multi-Device Keyboard and Mouse Combo Instruction Manual](#)

Rapoo 9050S

Rapoo 9050S Multi-Device Keyboard and Mouse Combo Instruction Manual

Model: 9050S | Brand: Rapoo


Instructions	Introduction	Package Contents	Setup	Operating
	Maintenance	Troubleshooting	Specifications	Warranty & Support

1. INTRODUCTION

This manual provides detailed instructions for the Rapoo 9050S Multi-Device Keyboard and Mouse Combo. This wireless set offers versatile connectivity options (2.4GHz, Bluetooth 5.0/4.0) and supports up to four devices simultaneously, making it suitable for various operating systems including Windows, Mac, Linux, and Chrome. The keyboard features low-profile chiclet keys for a quiet typing experience, while the mouse offers adjustable DPI for precise control. Both devices are rechargeable and designed for efficient multi-tasking.

MULTI-DEVICE AND MULTI-OS

Wireless connectivity to 4 devices via 2.4GHz or
Bluetooth 5.0/4.0



Windows



Mac



Linux



Chrome

Image: The Rapoo 9050S keyboard and mouse combo displayed with a monitor, laptop, tablet, and smartphone, illustrating its multi-device and multi-OS compatibility.

2. PACKAGE CONTENTS

Verify that all items are present in your package:

- Rapoo 9050S Wireless Keyboard
- Rapoo 9050S Wireless Mouse
- USB Receiver (stored inside the mouse battery compartment)
- USB Charging Cable (USB-C for keyboard, Micro-USB for mouse)
- Quick Start Guide (this document)

3. SETUP

3.1. Initial Charging

Before first use, ensure both the keyboard and mouse are fully charged. Connect the provided USB charging cable to the charging port on each device and to a USB power source (e.g., computer USB port, USB wall adapter).

90-DAY RECHARGEABLE BATTERY

Lasts up to 90 days with upgraded low energy Bluetooth



Image: The Rapoo 9050S keyboard and mouse connected to a charging cable. The keyboard has a USB-C port, and the mouse has a micro-USB port. Both are shown with a charging cable plugged in.

3.2. Connecting the Keyboard

The keyboard supports connection via 2.4GHz wireless (USB receiver) or Bluetooth 5.0/4.0. It can connect to up to 4 devices.

3.2.1. 2.4GHz Wireless Connection (USB Receiver)

1. Locate the USB receiver, typically stored in the mouse's battery compartment.
2. Plug the USB receiver into an available USB port on your computer.
3. Turn on the keyboard. The keyboard should automatically connect.

3.2.2. Bluetooth Connection

1. Turn on the keyboard.
2. Press and hold one of the Bluetooth channel keys (F1, F2, F3, or F4) for 3 seconds until the indicator light blinks rapidly, indicating pairing mode.
3. On your device (computer, tablet, phone), go to Bluetooth settings and search for "Rapoo 9050S Keyboard".
4. Select the keyboard to pair. The indicator light will stop blinking once connected.



Image: Close-up of the Rapoo 9050S keyboard showing the F1-F4 keys with device indicators, used for switching between paired devices.

3.3. Connecting the Mouse

The mouse supports connection via 2.4GHz wireless (USB receiver) or Bluetooth 5.0/4.0. It can connect to up to 2 devices.

3.3.1. 2.4GHz Wireless Connection (USB Receiver)

1. Ensure the USB receiver is plugged into your computer.
2. Turn on the mouse and switch it to 2.4GHz mode (indicated by a switch on the bottom). The mouse should automatically connect.

3.3.2. Bluetooth Connection

1. Turn on the mouse and switch it to Bluetooth mode (indicated by a switch on the bottom).
2. Press and hold the Bluetooth pairing button on the bottom of the mouse for 3 seconds until the indicator light blinks rapidly.
3. On your device, go to Bluetooth settings and search for "Rapoo 9050S Mouse".
4. Select the mouse to pair. The indicator light will stop blinking once connected.



Image: The underside of the Rapoo 9050S mouse, showing the power switch and the Bluetooth pairing button.

3.4. Multi-Device Pairing and Switching

The Rapoo 9050S combo allows seamless switching between multiple paired devices.

- **Keyboard:** Use the F1, F2, F3, F4 keys to switch between up to four paired devices. A short press will switch to the corresponding device.
- **Mouse:** Use the switch on the bottom of the mouse to toggle between 2.4GHz (USB receiver) and Bluetooth connections.



Image: The Rapoo 9050S keyboard and mouse shown connected to a laptop and a tablet, illustrating multi-device functionality.

4. OPERATING INSTRUCTIONS

4.1. Keyboard Features

- **Low-Profile Chiclet Keys:** Designed for comfortable and quiet typing.
- **Dual System Hotkeys:** Supports Windows and Mac OS shortcuts for 12 widely used functions (e.g., play/pause, volume +/-). Use the **Fn** key in combination with the F-keys for these functions.
- **Indicator Lights:** The keyboard features indicator lights for device selection, capitalization (Caps Lock), and battery status.

DEVICE AND CAPITALIZATION INDICATOR LIGHTS

Get to know which device you are working on at a glance of view



Image: Close-up of the Rapoo 9050S keyboard highlighting the device and capitalization indicator lights.

DUAL SYSTEM MULTIMEDIA KEYS

Instant access to 12 most-used function keys like volume+, volume- and mute

Fn + F1 F2 F3 F4 F5 F6 F7 F8 F9 F10 F11 F12
◀ ▶ ⌂ ⌂ ⌂ ⌂ ⌂ ⌂ ⌂ ⌂ ⌂ ⌂ ⌂ ⌂



Image: The Rapoo 9050S keyboard illustrating the use of Fn key with F1-F12 for multimedia and system functions.

4.2. Mouse Features

- **Silent Click:** The mouse buttons are designed for quiet operation.
- **Adjustable DPI:** Cycle through 800/1000/1200/1600/2400 DPI resolutions using the DPI button, located near the scroll wheel, to adjust cursor speed and precision.

LOW-PROFILE CHICLET KEYCAPS

Experience a comfortable and quiet typing for hours at your desk



Image: A hand holding the Rapoo 9050S mouse, illustrating its ergonomic design and the location of the DPI switch button.

5. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the keyboard and mouse. For stubborn dirt, a slightly damp cloth can be used, ensuring no moisture enters the device.
- **Battery Care:** To prolong battery life, avoid fully discharging the devices frequently. Charge them when the battery indicator shows low power.
- **Storage:** When not in use for extended periods, turn off the devices to conserve battery. Store in a cool, dry place.

6. TROUBLESHOOTING

6.1. Device Not Connecting

- **Check Power:** Ensure both the keyboard and mouse are turned on and have sufficient battery charge.
- **Re-pair:** For Bluetooth, try unpairing and re-pairing the device. For 2.4GHz, ensure the USB receiver is securely plugged in.
- **Switch Modes:** Verify that the mouse is set to the correct connection mode (2.4GHz or Bluetooth) using the switch on its underside.

- **Interference:** Move closer to your device or away from potential sources of interference (e.g., other wireless devices, large metal objects).

6.2. Lag or Unresponsive Input

- **Battery Level:** Low battery can cause performance issues. Charge the devices.
- **Distance:** Ensure the devices are within the effective range of your computer (typically up to 10 meters for Bluetooth/2.4GHz).
- **DPI Setting (Mouse):** If the mouse cursor is too slow or fast, adjust the DPI setting.

7. SPECIFICATIONS

Feature	Detail
Model Number	9050S
Connectivity	2.4GHz Wireless, Bluetooth 5.0/4.0
Multi-Device Support	Keyboard: Up to 4 devices; Mouse: Up to 2 devices
Compatible OS	Windows, Mac, Linux, Chrome
Keyboard Type	Low-profile Chiclet Scissor Keys
Mouse DPI	800/1000/1200/1600/2400 adjustable
Battery	Rechargeable (2 AAA batteries included)
Item Weight	1.32 pounds
Package Dimensions	14.88 x 5.28 x 1.73 inches
Manufacturer	Shenzhen Rapoo Technology Co., Ltd.

8. WARRANTY AND SUPPORT

Rapoo products are designed for reliability and performance. For warranty information, please refer to the warranty card included in your product packaging or visit the official Rapoo website. For technical support, troubleshooting assistance, or product inquiries, please contact Rapoo customer service through their official channels.

You can find more information and support at the [Rapoo Store on Amazon](#).