



[Manuals.plus](#) /

> [LNTVOM](#) /

> LNTVOM Slaasoo N7 Portable Neck and Back Massager User Manual

## LNTVOM N7

# LNTVOM Slaasoo N7 Portable Neck and Back Massager User Manual

Model: N7

## 1. INTRODUCTION

---

Thank you for choosing the LNTVOM Slaasoo N7 Portable Neck and Back Massager. This device is designed to provide deep tissue relief and relaxation by mimicking human hand massage techniques. It features a heating function for enhanced comfort and is portable for use in various settings. Please read this manual thoroughly before use to ensure safe and effective operation.

## 2. SAFETY INFORMATION

---

**WARNING: To reduce the risk of electric shock, burns, fire, or injury, please observe the following precautions:**

- Always read and follow the instruction manual before use.
- Keep the massager away from water and do not use it while sleeping or bathing.
- Do not use the heat function if you have any medical conditions that could be affected by heat. Consult a physician if unsure.
- If you experience any discomfort or pain, stop using the massager immediately and consult a healthcare professional.
- Keep the massager out of reach of children and pets.
- Always unplug the massager when not in use and store it in a dry place.
- If the massager becomes damaged, stop using it and contact the manufacturer for assistance.
- Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition. This product is not a medical device.

### 3. PRODUCT OVERVIEW

---

The LNTVOM Slaasoo N7 massager is designed for versatile use on the neck, shoulders, back, and waist. Its ergonomic design and simulated hand-kneading nodes provide targeted relief.



*Figure 3.1: LNTVOM Slaasoo N7 Portable Neck and Back Massager. This image shows the overall design of the massager, highlighting its green fabric body, control buttons, and hand-shaped massage nodes.*

#### 3.1 Key Features

- **Simulated Hand Kneading:** Deep tissue massage nodes mimic real human hands.
- **Optional Heating Function:** Soothing warmth to ease muscle stiffness.
- **Adjustable Intensity Levels:** Customize your massage experience.
- **Portable Design:** Lightweight and compact for use at home, office, or while traveling.
- **Cordless Operation:** Built-in 2000mAh battery for extended use.

Simulates the gripping curvature of a human hand  
Ergonomically fits shoulders and neck



Figure 3.2: Visual representation of the massager's key features, including hand simulation, heating, adjustable intensity, and portability.

### 3.2 Components

1. **Main Unit:** Contains the massage mechanism, battery, and control panel.
2. **Massage Nodes:** Hand-shaped nodes for kneading massage.
3. **Control Panel:** Buttons for power, mode selection, and heat function.
4. **Adjustable Straps:** For securing the massager to different body parts.
5. **Charging Port:** USB-C port for recharging the device.



Figure 3.3: Close-up of the massager's control panel, showing the power button, mode selection button, and heat function button.

## 4. SETUP

### 4.1 Charging the Device

Before first use, fully charge the massager. Connect the provided USB-C cable to the charging port on the device and to a compatible USB power adapter (not included). The indicator light will show charging status (e.g., red for charging, green for fully charged).

- Charging time: Approximately 2-3 hours for a full charge.
- Battery life: Up to several hours depending on usage mode and heat function.

### 4.2 Positioning the Massager

The massager is designed to be versatile. Use the adjustable straps to secure it comfortably to the desired area.

- **For Neck and Shoulders:** Position the massager so the hand-shaped nodes align with your neck and shoulder muscles. Use the straps to hold it in place.
- **For Back and Waist:** Place the massager on your lower back or waist area and secure with the straps.



*Figure 4.1: Demonstrates the massager being used on the neck and back, showing its ergonomic fit and multi-dimensional curvature for contouring.*

## 5. OPERATION

---

### 5.1 Power On/Off

Press and hold the **Power Button** (usually marked with a power symbol) for 2-3 seconds to turn the massager on or off. The device will typically start in a default massage mode.

### 5.2 Selecting Massage Modes

Press the **Mode Button** (often marked with 'M' or wave symbols) to cycle through available massage modes. Each press will change the massage pattern or intensity. Refer to the indicator lights for the current mode.

### 5.3 Activating Heat Function

Press the **Heat Button** (often marked with a flame or temperature symbol) to activate the heating function. Press again to cycle through heat levels (e.g., Low, High) or to turn it off. The heat function provides soothing warmth to enhance relaxation and blood circulation.

# Feels Just Like Real Hands

Deep Kneading Shiatsu Massage  
for Neck & Back



Figure 5.1: Illustrates the internal heating elements of the massager, showing the two temperature settings: 40°C (Low-end) and 45°C (High-end).

## 5.4 Recommended Usage

- Start with the lowest intensity and gradually increase as comfortable.
- Do not use the massager for more than 15-20 minutes per session.
- Avoid using the massager on swollen, inflamed, or injured areas.

Your browser does not support the video tag.

Video 5.1: Demonstration of the Slaasoo Neck Massager in use, showing its application on the neck, shoulders, and other body parts. This video highlights the simulated hand massage action and the device's versatility.

## 6. MAINTENANCE

### 6.1 Cleaning

- Ensure the massager is turned off and unplugged before cleaning.
- Wipe the surface of the massager with a soft, slightly damp cloth.
- Do not use abrasive cleaners, alcohol, or harsh chemicals.
- Do not immerse the massager in water or any other liquid.

## 6.2 Storage

- Store the massager in a cool, dry place, away from direct sunlight and extreme temperatures.
- Keep it out of reach of children and pets.
- Avoid placing heavy objects on the massager during storage.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on.	Low battery or not charged.	Charge the device fully. Ensure the power button is pressed and held for 2-3 seconds.
Massage intensity is weak.	Incorrect mode selected or low battery.	Cycle through massage modes. Recharge the device if battery is low.
Heat function not working.	Heat function not activated or device malfunction.	Ensure the heat button is pressed. If still not working, contact customer support.
Device stops unexpectedly.	Overheat protection activated or low battery.	Allow the device to cool down. Recharge the device.

If the problem persists after trying the above solutions, please contact LNTVOM customer support for further assistance.

## 8. SPECIFICATIONS

Feature	Detail
Product Dimensions	0.39 x 0.39 x 0.39 inches
Item Weight	2.2 Pounds (1000 Grams)
Model Number	N7
Brand	LNTVOM
Power Source	Battery Powered (2000mAh)
Use for	Neck, Shoulder, Back, Waist
Heat Function	Yes (40°C / 45°C)

## 9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact LNTVOM customer service directly. Contact details can typically be found on the manufacturer's official website or through your purchase platform.

For online support, visit the [LNTVOM Store on Amazon](#).