

[Manuals.plus](#) /

› [PANCERKA](#) /

› PANCERKA 1.8L Electric Kettle Instruction Manual (Model BD-123456)

## PANCERKA BD-123456

# PANCERKA 1.8L Electric Kettle Instruction Manual (Model BD-123456)

Your guide to safe and efficient use of your new electric kettle.

## IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or electric kettle in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or personal injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Scalding may occur if the lid is removed during the heating cycle.
- This appliance is for household use only.

## PRODUCT OVERVIEW

The PANCERKA 1.8L Electric Kettle is designed for fast and efficient water boiling. It features a cool-touch exterior and built-in safety mechanisms.



**Figure 1:** PANCERKA 1.8L Electric Kettle. This image shows the white electric kettle with grey accents, featuring the PANCERKA logo and "Heat. Pour. Enjoy." slogan on the front.

### Key Components:

- **Kettle Body:** Contains the heating element and water reservoir.
- **Lid:** Hinged lid for easy filling and cleaning.
- **Handle:** Ergonomically designed for comfortable pouring.
- **Power Switch:** Located on the handle to initiate boiling.
- **Power Base:** 360° swivel base for cord-free serving.
- **Spout:** Designed for controlled pouring.



**Figure 2:** Close-up view of the kettle's lid, demonstrating the push-button mechanism for opening.



**Figure 3:** Close-up of the power switch located on the kettle's handle, used to activate the heating element.

## SETUP

---

1. **Unpack:** Carefully remove the kettle and all accessories from the packaging.
2. **Initial Cleaning:** Before first use, fill the kettle with clean water to the maximum level. Boil the water, then discard it. Repeat this process 2-3 times to remove any manufacturing residues.
3. **Placement:** Place the power base on a flat, stable, heat-resistant surface. Ensure the power cord is not dangling or in contact with hot surfaces.
4. **Power Connection:** Plug the power base into a grounded electrical outlet.

## OPERATING INSTRUCTIONS

---

1. **Fill the Kettle:** Open the lid and fill the kettle with the desired amount of water. Do not fill below the minimum mark or above the maximum mark.
2. **Close the Lid:** Ensure the lid is securely closed before operating.
3. **Place on Base:** Position the kettle firmly onto the power base.
4. **Start Boiling:** Press the power switch to the "ON" position. The indicator light will illuminate, signaling that the kettle is heating.
5. **Automatic Shut-Off:** The kettle will automatically turn off once the water has boiled. The indicator light will extinguish.

6. **Pouring:** Carefully lift the kettle from its base and pour the hot water. Be cautious of steam escaping from the spout.
7. **Re-boiling:** If you need to re-boil water, wait a few moments for the internal thermostat to reset before pressing the power switch again.

## STYLISH DESIGN

*Stylish 1.8L Kettle  
- Elegance Meets Practicality*



**Figure 4:** The PANCERKA electric kettle pouring hot water into a teacup. This demonstrates the kettle's ease of use for preparing hot beverages.



**Figure 5:** The 360-degree swivel base allows for cord-free serving and features boil-dry protection, automatically shutting off power if the kettle is empty or runs out of water during operation.

## MAINTENANCE AND CLEANING

Regular cleaning will help maintain the performance and longevity of your electric kettle.

1. **Before Cleaning:** Always unplug the kettle from the power outlet and allow it to cool completely before cleaning.
2. **Exterior Cleaning:** Wipe the exterior of the kettle with a soft, damp cloth. Do not use abrasive cleaners or scouring pads, as they may scratch the surface.
3. **Interior Cleaning (Descaling):** Over time, mineral deposits (limescale) may build up inside the kettle, especially in hard water areas.
  - Fill the kettle with a mixture of one part white vinegar and two parts water.
  - Boil the mixture and let it stand for at least 30 minutes, or longer for heavy buildup.
  - Pour out the mixture and rinse the interior thoroughly with fresh water several times.
  - For stubborn deposits, gently scrub with a non-abrasive brush or sponge.
4. **Do Not Immerse:** Never immerse the kettle body or power base in water or any other liquid.

# EASY TO REFILL AND CLEAN



**Figure 6:** A hand is shown wiping the interior of the kettle with a cloth, demonstrating the ease of cleaning due to its wide opening.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Kettle does not heat up.	Not plugged in. Power switch not activated. Kettle not properly seated on base. Boil-dry protection activated.	Ensure plug is securely in outlet. Press the power switch to "ON". Reposition kettle on the power base. Allow kettle to cool, then refill with water and restart.
Water takes too long to boil.	Limescale buildup. Low power supply.	Descal the kettle (see Maintenance section). Ensure kettle is plugged into a dedicated, properly functioning outlet.

Problem	Possible Cause	Solution
Kettle leaks.	Lid not closed properly. Overfilled.	Ensure lid is securely closed. Do not fill above the maximum fill line.

## SPECIFICATIONS

Feature	Detail
Brand	PANCERKA
Model Name	Electric Kettle
Model Number	BD-123456
Capacity	1.8 Liters
Material	Interior: 304 Stainless Steel, Exterior: BPA Free Material
Rated Power	1000W
Rated Voltage	120V/60Hz
Special Feature	Automatic Shut-Off, Boil-Dry Protection, Cool-Touch Exterior, 360° Swivel Base
Product Dimensions	8.27"L x 6.89"W x 9.45"H
Item Weight	15.5 ounces



**Figure 7:** Diagram showing the dimensions of the PANCERKA Electric Kettle: 21.7cm/8.54in in length and 24.5cm/9.64in in height.



**Figure 8:** Visual representation of key specifications including 1.8L capacity, 304 stainless steel material, 1000W rated power, and 120V/60Hz rated voltage.

## ADDITIONAL INFORMATION

### Double Wall Design

The kettle features a double-wall design for thermal insulation, keeping the exterior cool to the touch for safe handling while maintaining water temperature inside.



**Figure 9:** Diagram illustrating the double-wall construction: an interior of 304 Stainless Steel, a middle layer for insulation, and an exterior made of BPA-free material.

### British Strix Thermostat System

This kettle incorporates a British Strix Thermostat controlling system, ensuring reliable performance with features like auto shut-off, boil-dry protection, overheating protection, and prolonged service life.

## BRITISH STRIX THERMOSTAT CONTROLLING SYSTEM



**Figure 10:** Image highlighting the British Strix Thermostat system, detailing its benefits: Auto Shut-Off, Boil-Dry Protection, Overheating Protection, and Prolonged Service Life.

## WARRANTY AND SUPPORT

Specific warranty details and customer support contact information are typically provided with your product packaging or on the manufacturer's official website. Please refer to those resources for the most accurate and up-to-date information.

For general inquiries or assistance, you may visit the PANCERKA brand page on Amazon or contact their customer service as indicated in your purchase documentation.