

AOC Captain 600

AOC Captain 600 Wireless Headset User Manual

MODEL: CAPTAIN 600 (ACW2212)

Introduction

Thank you for choosing the AOC Captain 600 Wireless Headset. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your headset. Please read it carefully to ensure optimal performance and a long lifespan for your device.

Package Contents

- 1 x AOC Captain 600 Wireless Headset
- 1 x USB Dongle
- 1 x Type-C to 3.5mm Audio Cable
- 1 x Type-C Charging Cable
- 1 x User Manual (this document)

Safety Information

- Do not expose the headset to extreme temperatures, humidity, or corrosive substances.
- Avoid dropping or subjecting the headset to strong impacts.
- Do not attempt to disassemble or modify the headset. This will void the warranty.
- Keep the headset away from children and pets.
- Use only the provided charging cable or a certified Type-C cable for charging.
- Prolonged listening at high volume levels may cause hearing damage. Adjust volume to a comfortable level.

Setup

1. Initial Charging

Before first use, fully charge your headset. Connect the provided Type-C charging cable to the headset's charging port and the other end to a USB power source (e.g., computer USB port, wall adapter). The LED indicator will show charging status.

The headset offers up to 30 hours of talking time and supports fast charging.

ALL DAY PALY

Work non-stop

400

Hours of Standy Time



30H Talking Time



2.5H Fast Charge



Image: Headset highlighting 30 hours of talking time and 2.5 hours fast charge.

2. Power On/Off

- **Power On:** Press and hold the Power button for 3 seconds until the LED indicator lights up.
- **Power Off:** Press and hold the Power button for 3 seconds until the LED indicator turns off.

3. Connectivity Options

The AOC Captain 600 offers versatile triple connectivity: Bluetooth, USB Dongle, and Wired (3.5mm).

3-in-1 Connection

Bluetooth, USB Dongle & Wired
stay connected anywhere.



Bluetooth



USB



Cable

Image: Headset illustrating its 3-in-1 connection capabilities: Bluetooth, USB, and wired.

Bluetooth Pairing

1. Ensure the headset is powered off.
2. Press and hold the Power button for 5-7 seconds until the LED indicator flashes blue and red alternately, indicating pairing mode.
3. On your device (smartphone, laptop), enable Bluetooth and search for "AOC Captain 600".
4. Select the headset from the list to connect. The LED will turn solid blue when connected.

USB Dongle Connection

1. Plug the USB dongle into an available USB port on your computer.
2. Power on the headset. It will automatically attempt to connect to the dongle.
3. The LED on both the headset and dongle will turn solid blue when connected.
4. Ensure the AOC Captain 600 is selected as the audio input/output device in your computer's sound settings.

Wired Connection (3.5mm Audio Cable)

1. Connect one end of the Type-C to 3.5mm audio cable to the headset's Type-C port.
2. Connect the other end of the 3.5mm audio cable to the 3.5mm audio jack on your device.
3. The headset will operate in passive wired mode. Bluetooth and USB dongle functions are disabled when using the wired connection.

Operating Instructions

1. Controls Overview

The headset features intuitive controls for managing calls and audio playback.

- **Power Button:** Power on/off, enter pairing mode.
- **Volume Up/Down:** Adjust audio volume.
- **Multi-function Button:** Play/pause music, answer/end calls.
- **Microphone Mute Button:** Mute/unmute microphone.

2. Call Management

- **Answer Call:** Press the Multi-function button once.
- **End Call:** Press the Multi-function button once during a call.
- **Reject Call:** Press and hold the Multi-function button for 2 seconds.
- **Redial Last Number:** Double-press the Multi-function button.

3. Microphone Mute Function

The headset features a dedicated mute button on the microphone boom for instant privacy.

One-Touch Mute

Instant privacy and meeting control.

*The microphone mute button can only be used during calls and cannot function as a pause button when playing audio.



Image: Close-up of the headset's microphone boom, indicating the one-touch mute button.

- **Mute:** Press the mute button on the microphone boom. The LED on the microphone will turn red.
- **Unmute:** Press the mute button again. The LED will turn off.

Note: The microphone mute button is primarily for calls. It may not function as a pause button for audio playback.

4. Noise-Cancelling Microphone

The integrated noise-cancelling microphone effectively filters out background noise, ensuring clear voice transmission during calls and meetings.

Crystal-Clear Calls



Noise-cancelling microphone filters background



Guarantee pristine call clarity



Image: A person using the headset, illustrating the clarity of calls due to the noise-cancelling microphone.

5. Rotatable Microphone

The microphone boom can be rotated up to 270 degrees, allowing for optimal positioning for voice pickup or to move it out of the way when not in use.

270° Rotatable Microphone

Flexible Design for Optimal Voice Pickup




Image: Diagram illustrating the 270-degree rotatable microphone for flexible positioning.

Maintenance

1. Cleaning

- Wipe the headset with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Avoid getting moisture into any openings.

2. Storage

- Store the headset in a cool, dry place away from direct sunlight.
- Avoid storing in areas with extreme temperatures or high humidity.
- When storing for extended periods, charge the headset periodically to maintain battery health.

Troubleshooting

Problem	Possible Cause	Solution
Headset does not power on.	Low battery.	Charge the headset fully.
Cannot pair via Bluetooth.	Headset not in pairing mode; device Bluetooth off.	Ensure headset is in pairing mode (flashing blue/red LED). Turn on Bluetooth on your device.
No audio or microphone not working (USB Dongle).	Dongle not connected; incorrect audio device selected.	Ensure dongle is securely plugged in. Check computer sound settings to select "AOC Captain 600" as default.
Microphone mute button not working.	Not in a call; software conflict.	The mute button is primarily for calls. Ensure you are in an active call. Restart the headset and device.
Poor audio quality.	Weak connection; interference; low battery.	Move closer to the connected device. Avoid sources of interference. Charge the headset.

Specifications

Feature	Detail
Brand	AOC
Model Name	ACW2212
Model Number	Captain 600
Color	White
Ear Placement	On Ear
Impedance	32 Ohms
Connectivity Technology	Wired, Wireless (Bluetooth, USB Dongle)
Bluetooth Version	5.4
Bluetooth Range	Up to 32.8 Feet (10 meters)
Headphone Jack	3.5 mm Jack (via Type-C to 3.5mm cable)
Battery Average Life	30 Hours (Talking Time)
Noise Control	Passive Noise Cancellation (for earcups), Noise-Cancelling Mic
Frequency Response	20 Hz - 20 KHz
Audio Driver Size	40 Millimeters
Material	Acrylonitrile Butadiene Styrene (ABS)
Compatible Devices	Laptops, Desktops, Gaming Consoles, Tablets, Telephones, Smart Speakers, Televisions, Cellphones
Additional Features	Adjustable Headband, Fast Charging, Lightweight, Microphone Included, Volume Control, 270° Rotatable Microphone

Warranty and Support

Warranty Information

The AOC Captain 600 Wireless Headset comes with a **1-year manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

Worry-Free Guarantee



Image: Headset with a 'Worry-Free Guarantee' badge, indicating product reliability.

Customer Support

For technical assistance, warranty claims, or any questions regarding your AOC Captain 600 Wireless Headset, please contact AOC customer support through the official AOC website or your retailer's support channels. Please have your purchase receipt and product model number (Captain 600 / ACW2212) ready when contacting support. Visit the [AOC Store on Amazon](#) for more information.

© 2026 AOC. All rights reserved.