CHARGEWORX B0FP48NM7X

Chargeworx Smart Location Tag - Instruction Manual

Model: B0FP48NM7X

| Introduction | Overview | Setup | Operation | Maintenance & Support | Troubleshooting | Specifications | Warranty |

1. INTRODUCTION

The Chargeworx Smart Location Tag is designed to help you keep track of your personal items. This device utilizes the Apple Find My network, allowing you to locate your belongings using the Find My app on your compatible iOS device. This manual provides instructions for setting up, operating, and maintaining your Smart Location Tag.

2. PRODUCT OVERVIEW

The Chargeworx Smart Location Tag is a compact, lightweight device that can be attached to various items such as keys, bags, or luggage. It communicates with the Apple Find My network to provide location information.

Key Features:

- **Apple Find My Network Integration:** Locate your items using the Apple Find My app.
- **Left Behind Alerts:** Receive notifications if you leave your tagged item behind.
- **Lost Mode:** Mark your item as lost to receive location updates and contact information if found.
- **Device Sharing:** Share access to your tag's location with trusted friends and family.
- **Compact Design:** Easily attaches to various personal items.

Image 2.1: The Chargeworx Smart Location Tag packaging, illustrating the two-pack and key features like 'Left Behind Alerts' and 'Locate items WORLDWIDE'.

3. SETUP INSTRUCTIONS

Follow these steps to set up your Chargeworx Smart Location Tag with your Apple device.

3.1. Requirements

- An iPhone, iPad, or iPod touch with iOS 14.5 or later, or iPadOS 14.5 or later.
- The Find My app enabled.
- Bluetooth turned on.
- A stable internet connection (Wi-Fi or cellular data).

3.2. Pairing Your Smart Location Tag

1. Ensure your Chargeworx Smart Location Tag has a working battery installed.
2. Bring the Smart Location Tag close to your iOS device.
3. Open the **Find My** app on your iOS device.
4. Tap the **Items** tab at the bottom of the screen.
5. Tap **+ Add Item**, then select **Other Supported Item**.
6. Follow the on-screen instructions to name your item and register it to your Apple ID.
7. Once paired, your Smart Location Tag will appear in the Items list within the Find My app.

Devices +

Andre's iPhone
This iPhone
With You

Andre's Bike
Last seen today at 9:11 AM
0.3 mi

Andre's iPad
New York, NY · Yesterday at 8:25 PM

Andre's Apple Watch
New York, NY · Yesterday at 8:25 PM

Image 3.1: An iPhone displaying the Apple Find My app interface, showing a map with various devices and items, including a Smart Location Tag, listed below.

4. OPERATING INSTRUCTIONS

Once your Chargeworx Smart Location Tag is set up, you can use the Find My app to manage and locate your items.

4.1. Locating Your Item

1. Open the **Find My** app.
2. Tap the **Items** tab.
3. Select your Chargeworx Smart Location Tag from the list.
4. The app will display the item's current or last known location on a map.
5. If the item is nearby, you can tap **Play Sound** to help locate it.
6. If the item is not nearby, you can tap **Directions** to get walking or driving directions to its location.

Image 4.1: An iPhone screen displaying the Apple Find My app, showing a map with a key icon indicating the item's location, along with 'Play Sound' and 'Directions' buttons.

4.2. Left Behind Alerts

Left Behind Alerts notify you when you leave your item at an unfamiliar location. To manage these alerts:

1. In the **Find My** app, select your Smart Location Tag.
2. Scroll down and tap **Notify When Left Behind**.
3. Toggle the feature on or off.
4. You can also set specific locations where you *don't* want to be notified (e.g., your home or office) by tapping **New Location** under 'Notify Me, Except At'.

4.3. Lost Mode

If your item is truly lost, you can activate Lost Mode to help recover it.

1. In the **Find My** app, select your Smart Location Tag.
2. Scroll down and tap **Enable** under 'Lost Mode'.
3. Follow the prompts to enter a phone number or email address where you can be contacted.
4. You can also write a custom message that will be displayed to anyone who finds your item and scans it with an NFC-enabled smartphone.
5. Confirm to activate Lost Mode.

When Lost Mode is active, you will receive a notification if your item is detected by another device on the Apple Find My network.


Lost Mode

Andre's Compact Tracking
hndre@gmail.com

SUMMARY

PHONE

(631) 123-4567

MESSAGE   42/160

This device has been lost. Please call me.

Turn Off Lost Mode

Image 4.2: An iPhone screen displaying the 'Lost Mode' setup within the Apple Find My app, prompting for contact information and a message for a lost item.

4.4. Sharing Your Item

You can share access to your Smart Location Tag's location with family and friends who also use the Find My app.

1. In the **Find My** app, select your Smart Location Tag.
2. Scroll down and tap **Add Person** under 'Share This Item'.
3. Select the contact you wish to share with and follow the on-screen instructions.

5. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your Chargeworx Smart Location Tag.

5.1. Battery Replacement

The Chargeworx Smart Location Tag uses a replaceable coin cell battery (e.g., CR2032). When the battery level is low, you will receive a notification in the Find My app.

1. Locate the battery compartment on your Smart Location Tag.
2. Use a small tool (e.g., a coin) to twist open the battery cover.
3. Remove the old battery.
4. Insert a new CR2032 battery with the positive (+) side facing up.
5. Replace the battery cover and twist to secure it.

5.2. Cleaning

To clean your Smart Location Tag, wipe it with a soft, dry, or slightly damp cloth. Avoid using harsh chemicals, abrasive cleaners, or submerging the device in water.

6. TROUBLESHOOTING

If you encounter issues with your Chargeworx Smart Location Tag, refer to the following common solutions.

Problem	Possible Solution
Tag not appearing in Find My app	- Ensure the tag has a fresh battery. - Make sure Bluetooth is enabled on your iOS device. - Ensure your iOS device is running iOS 14.5 or later. - Try resetting the tag (refer to manufacturer's website for specific reset instructions if needed). - Attempt the pairing process again.

Problem	Possible Solution
Inaccurate location or no location updates	- The tag's location is updated when it is near an Apple device on the Find My network. If it's in a remote area, updates may be infrequent. - Check the battery level of the tag. - Ensure your iOS device has a stable internet connection.
Left Behind Alerts not working	- Verify that 'Notify When Left Behind' is enabled for the tag in the Find My app. - Check if the current location is added to the 'Notify Me, Except At' list. - Ensure your iOS device's location services are enabled for the Find My app.
Cannot hear the sound from the tag	- Ensure the tag is within Bluetooth range of your iOS device. - Check the tag's battery level. - The sound may be faint in noisy environments or if the tag is covered.

7. SPECIFICATIONS

- **Model:** B0FP48NM7X
- **Package Dimensions:** 3 x 3 x 1 inches
- **Item Weight:** 4 ounces
- **Connectivity Technology:** Bluetooth
- **Special Features:** Real Time Tracking
- **Compatible Devices:** iOS Devices (iPhone, iPad, iPod touch with iOS/iPadOS 14.5 or later)
- **Material:** Plastic
- **Battery:** CR2032 coin cell (not included)
- **Manufacturer:** Chargeworx

8. WARRANTY AND SUPPORT

8.1. Warranty Information

The Chargeworx Smart Location Tag typically comes with a **1-Year Limited Warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. Please retain your proof of purchase for warranty claims. For specific terms and conditions, refer to the warranty card included with your product or visit the official Chargeworx website.

8.2. Customer Support

If you require further assistance or have questions not covered in this manual, please contact Chargeworx customer support. Contact information can usually be found on the product packaging, the official Chargeworx website, or through your retailer.