

Amazon Basics LACC175

Amazon Basics 25W Qi2.2 Certified Wireless Charging Pad (Model LACC175) User Manual

Brand: Amazon Basics | Model: LACC175

INTRODUCTION

Thank you for choosing the Amazon Basics 25W Qi2.2 Certified Wireless Charging Pad. This manual provides essential information for the safe and efficient use of your new wireless charger. Please read it thoroughly before use and retain it for future reference.

Key Features

- **Qi2.2 Certified:** Delivers up to 25W of fast wireless charging for Qi-enabled phones and devices.
- **Lightweight Design:** Sleek, compact, and convenient for use at home, in the office, or on the go.
- **Case-Friendly:** Wireless charging works through phone cases up to 3mm (0.1 in) thick with magnetic ring for hassle-free charging.
- **Extra-Long Cable:** 5ft cord provides flexible placement and convenient charging wherever you need it.
- **Compact Dimensions:** Measures 2.36 x 2.36 x 0.33 inches for space-saving setup.

Key features

Fast 25W Qi2.2 certified wireless charging

Sleek, compact & lightweight portable design

Works w/ phone cases (through magnetic ring) up to 0.1in(3mm)

Non-detachable 5ft cord; pair with min. 30W adapter (not included)



Image: Top view of the Amazon Basics 25W Qi2.2 Certified Wireless Charging Pad, showcasing its compact design.

SETUP INSTRUCTIONS

1. **Unpack the Charger:** Carefully remove the wireless charging pad and its integrated USB-C cable from the packaging.
2. **Connect to Power Adapter:** Connect the USB-C end of the charging pad's cable to a compatible Power Delivery (PD) certified wall charger. For optimal 25W fast charging performance, a wall charger with a minimum 30W output is recommended. **Note: The wall adapter is not included.**
3. **Plug into Power Outlet:** Plug the wall adapter into a standard electrical outlet.
4. **Placement:** Place the charging pad on a flat, stable surface, ensuring there are no metallic objects or foreign materials on or near the pad.



Image: The wireless charging pad with its integrated USB-C cable, ready for connection to a power adapter.

OPERATING INSTRUCTIONS

1. **Place Your Device:** Center your Qi-enabled smartphone or device on the charging pad. For MagSafe compatible devices, the magnetic ring will assist in proper alignment.
2. **Charging Confirmation:** Your device should indicate that it is charging. The charging pad itself does not have an LED indicator.
3. **Case Compatibility:** The charger is designed to work with phone cases up to 3mm (0.1 inches) thick. For optimal charging and magnetic attraction, remove any magnetic or metallic attachments, decorations, or cases exceeding 3mm in thickness.
4. **Charging Speed:** Charging speed may vary depending on your device, its battery level, and the power adapter used. Ensure you are using a 30W minimum PD-certified adapter for maximum 25W output.



Image: A smartphone positioned on the wireless charging pad, demonstrating proper placement for charging.

MAINTENANCE

- **Cleaning:** Disconnect the charger from the power source before cleaning. Use a soft, dry cloth to wipe the surface of the charging pad. Do not use abrasive cleaners, solvents, or harsh chemicals.
- **Storage:** When not in use, store the charging pad in a cool, dry place away from direct sunlight and extreme temperatures.
- **Cable Care:** Avoid bending or crimping the integrated cable excessively. Do not pull the cable to disconnect the charger from the power outlet.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Device is not charging.	<ul style="list-style-type: none"> ◦ Charger not connected to power. ◦ Device not properly aligned. ◦ Incompatible phone case. ◦ Foreign objects on the pad. ◦ Power adapter insufficient. 	<ul style="list-style-type: none"> ◦ Ensure the USB-C cable is securely connected to a 30W (minimum) PD-certified wall adapter and the adapter is plugged into a live outlet. ◦ Reposition your device to ensure it is centered on the charging pad. ◦ Remove phone case or ensure it is no thicker than 3mm (0.1 inches) and free of metallic attachments. ◦ Remove any metal objects, credit cards, or other foreign materials from the charging pad. ◦ Use a PD-certified wall charger with at least 30W output.
Slow charging.	<ul style="list-style-type: none"> ◦ Power adapter output is too low. ◦ Device misalignment. ◦ Background apps consuming power. 	<ul style="list-style-type: none"> ◦ Verify your wall adapter provides at least 30W output and is PD-certified. ◦ Adjust device placement for optimal contact with the charging coil. ◦ Close unnecessary applications on your device.
Charger or device gets warm.	<ul style="list-style-type: none"> ◦ Normal operation during wireless charging. ◦ Poor alignment or foreign objects. 	<ul style="list-style-type: none"> ◦ A slight increase in temperature is normal. If it becomes excessively hot, discontinue use and check for proper alignment and foreign objects. ◦ Ensure proper alignment and remove any foreign objects.

SPECIFICATIONS

Brand	Amazon Basics
Model Number	LACC175
Wattage	25 Watts
Input Voltage	15 Volts
Output Current	1.38 Amps
Output Voltage	1.38 Volts
Connector Type	USB Type C
Wireless Charging Standard	Qi

Compatible Devices	iPhone 17/16/15/14/13/12 series, SAMSUNG S20, HUAWEI P50 Pro, XIAOMI14, AirPods Pro 3/2, AirPods 4/3/2 (with charging case), and other Qi-enabled phones.
Cable Length	5 ft (non-detachable)
Dimensions (L x W x H)	2.36 x 2.36 x 0.33 inches
Item Weight	77.7 Grams

WARRANTY AND SUPPORT

This Amazon Basics product is covered by a **1-year limited warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use.

For warranty claims, technical support, or further assistance, please contact Amazon Basics customer service through the Amazon website or your purchase platform. Please have your product model number (LACC175) and proof of purchase available.

Do not attempt to disassemble or repair the product yourself, as this may void the warranty and pose safety risks.