#### Manuals+

Q & A | Deep Search | Upload

#### manuals.plus /

- jumper /
- jumper 17.6 Inch Laptop Ezbook P1 User Manual

# jumper Ezbook P1



# jumper Ezbook P1 17.6-inch Laptop User Manual

Model: Ezbook P1

#### 1. Introduction

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your new jumper Ezbook P1 laptop. Please read this guide thoroughly to ensure optimal performance and longevity of your device. The jumper Ezbook P1 is designed for productivity and entertainment, featuring a large 17.6-inch display, a powerful Intel N95 processor, and Windows 11 operating system.



Image 1.1: The jumper Ezbook P1 laptop, showcasing its large display and sleek design.

# 2. GETTING STARTED (SETUP)

#### 2.1 Unpacking and Initial Inspection

Carefully remove the laptop and all accessories from the packaging. Verify that all components are present:

- jumper Ezbook P1 Laptop
- Power Adapter
- User Manual (this document)

Inspect the laptop for any physical damage. If any damage is found or components are missing, contact customer support immediately.

## 2.2 Connecting the Power Adapter

Before first use, ensure the laptop is fully charged. Connect the power adapter to the DC charging port on the laptop and then plug the adapter into a power outlet. The charging indicator light will illuminate.

#### 2.3 First Boot and Windows 11 Setup

Press the power button to turn on the laptop. The system will guide you through the initial Windows 11 setup process. Follow the on-screen instructions to configure language, region, network connection, and user account settings.

#### 3.1 Keyboard and Touchpad

The laptop features a full-sized keyboard with a numeric keypad for efficient data entry. The keyboard is backlit, allowing for comfortable typing in low-light conditions. To activate or adjust the backlight, press **Fn + F5**.

The integrated touchpad supports multi-touch gestures for navigation. Refer to Windows settings for customizing touchpad sensitivity and gestures.




Image 3.1: The laptop's backlit keyboard with a dedicated numeric keypad.

## 3.2 Display

The Ezbook P1 is equipped with a 17.6-inch Full HD (1920x1200) IPS display, offering wide viewing angles and accurate color reproduction (100% sRGB). The screen also features anti-glare technology to reduce reflections and eye strain.



Image 3.2: Illustration of the anti-glare, eye-protection screen technology.

#### 3.3 Ports and Connections

The laptop provides various ports for connecting peripherals and external devices:

- USB 3.0 Ports (x3): For connecting USB devices like mice, keyboards, and external storage.
- HDMI Port: For connecting to external monitors or projectors.
- Type-C Port: A full-featured port supporting data transfer, video output, and Power Delivery (PD) fast charging.
- 3.5mm Headphone Jack: For audio output to headphones or external speakers.
- TF Card Slot: For expanding storage with a microSD card (up to 1TB).
- DC Charging Port: Dedicated port for the included power adapter.




Image 3.3: Overview of the laptop's various input/output ports.

#### 3.4 Wireless Connectivity

- Wi-Fi 6: Provides faster and more reliable wireless internet connectivity.
- Bluetooth 5.2: For connecting wireless peripherals such as headphones, mice, and keyboards.

#### 3.5 Webcam and Audio

The integrated webcam is suitable for video calls and online meetings. A physical webcam shield is included for privacy. Slide the cover to open or close the camera lens. The laptop also features stereo speakers and a digital microphone for clear audio communication.



Image 3.4: The laptop's webcam with an integrated privacy switch.

#### 4. POWER MANAGEMENT

The Ezbook P1 is equipped with a 7000mAh battery, providing extended usage time. It supports PD fast charging via the Type-C port in addition to the dedicated DC charging port.

- **Charging:** Connect the power adapter to either the DC port or the Type-C port (with a compatible PD charger, not included) to charge the battery.
- **Battery Life:** Battery life varies based on usage. To optimize battery life, adjust screen brightness, close unused applications, and utilize power-saving modes in Windows settings.



Image 4.1: The laptop's 7000mAh battery and dual charging options.

#### 5. MAINTENANCE

#### 5.1 Cleaning Your Laptop

- Screen: Use a soft, lint-free cloth lightly dampened with water or a screen cleaner. Do not spray liquid directly onto the screen.
- **Keyboard and Casing:** Use a soft, dry cloth. For stubborn dirt, a slightly damp cloth with mild soap solution can be used, ensuring no liquid enters the device.

• Vents: Periodically clean the ventilation openings with compressed air to prevent dust buildup, which can affect cooling performance.

# **5.2 Software Updates**

Regularly check for and install Windows updates to ensure your system has the latest security patches and performance improvements. Go to **Settings > Windows Update**.

# 6. TROUBLESHOOTING

Problem	Possible Solution
Laptop does not power on.	Ensure the power adapter is securely connected and the outlet is functional. The battery might be completely drained; allow it to charge for at least 30 minutes before attempting to power on again.
Screen is blank or black.	Check if the laptop is powered on. Try adjusting the screen brightness. If an external monitor is connected, ensure the display output is correctly configured (Fn + F10 or Windows P key).
Wi-Fi connection issues.	Verify Wi-Fi is enabled in Windows settings. Restart your router and the laptop. Ensure you are within range of the Wi-Fi network and have the correct password.
Keyboard or touchpad not responding.	Restart the laptop. Check Windows settings for touchpad and keyboard drivers. Ensure no external devices are interfering.
System is slow or unresponsive.	Close unnecessary applications. Check Task Manager for processes consuming high CPU/RAM. Ensure sufficient free storage space. Run a system scan for malware.

# 7. SPECIFICATIONS

Feature	Detail
Model Name	Ezbook P1
Display Size	17.6 Inches
Screen Resolution	1920 x 1200 pixels (FHD IPS, 100% sRGB)
Processor	Intel N95 (up to 3.4 GHz)
RAM	16GB DDR5
Storage	640GB SSD (512GB SSD + 128GB eMMC), expandable via TF card
Graphics Coprocessor	Intel UHD Graphics
Operating System	Windows 11 Home
Wireless Connectivity	Wi-Fi 6, Bluetooth 5.2
Ports	3x USB 3.0, 1x HDMI, 1x Full-featured Type-C, 1x 3.5mm Audio Jack, 1x TF Card Slot, 1x DC Charging Port
Battery	7000mAh
Weight	3.67 pounds (approx. 1.66 kg)

Feature	Detail
Dimensions (LxWxH)	14.37 x 9.61 x 0.79 inches
Special Features	Backlit Keyboard, Webcam Privacy Shield, Office 365 (12-month subscription included)

## 8. WARRANTY AND SUPPORT

# 8.1 Warranty Information

jumper laptops come with a one-year warranty from the date of purchase. This warranty covers manufacturing defects. Please retain your proof of purchase for warranty claims.

## **8.2 Customer Support**

For any product-related issues, technical assistance, or warranty inquiries, please contact jumper customer support:

- Email: service@jumper-customersupport.com
- Online: Log in to your Amazon buyer account, find your order, and click "Get Product Support."

Our support team aims to assist you within 24 hours.



Image 8.1: Contact information for jumper customer support.

© 2025 jumper. All rights reserved. Information in this manual is subject to change without notice.

Related Documents - Ezbook P1

