

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [V6](#) /

> [V6 Hoverboard User Manual](#)

## V6 V6 Hoverboard

# V6 Hoverboard User Manual

Model: V6 Hoverboard

## 1. IMPORTANT SAFETY INFORMATION

Please read this manual thoroughly before operating your V6 Hoverboard. Failure to follow instructions can result in serious injury or property damage.

- Always wear a helmet and appropriate protective gear (knee pads, elbow pads, wrist guards) when riding.
- Do not ride under the influence of alcohol or drugs.
- Observe all local traffic laws and regulations.
- Avoid riding on uneven surfaces, steep inclines, or near traffic.
- The V6 Hoverboard is designed for individuals weighing between 44 lbs (20 kg) and 220 lbs (100 kg). Exceeding these limits may cause damage to the device and increase the risk of injury.
- Not recommended for children under 8 years old. Adult supervision is required for all riders under 16.
- Do not attempt stunts or sudden maneuvers.
- Ensure the battery is fully charged before each use.

## 2. PACKAGE CONTENTS

Verify that all items are present in your V6 Hoverboard package:

- V6 Hoverboard
- Power Adapter/Charger
- User Manual (this document)

## 3. SETUP

Before your first ride, follow these steps:

1. **Unpack:** Carefully remove the V6 Hoverboard and all accessories from the packaging.

2. **Initial Charge:** Fully charge the hoverboard battery before its first use. Refer to Section 4 for charging instructions.
3. **Power On:** Press the power button located on the side of the hoverboard. The indicator light will illuminate.
4. **Self-Balance Check:** Ensure the hoverboard is on a flat surface. It should automatically balance itself. If it does not, refer to Section 6 for calibration.

## 4. CHARGING THE HOVERBOARD

---

Proper charging ensures optimal battery life and performance.

- **Connect Charger:** Plug the charging adapter into a standard wall outlet, then connect the other end to the charging port on the V6 Hoverboard.
- **Charging Indicator:** The indicator light on the charger will typically turn red during charging and green when fully charged. The hoverboard's battery indicator may also show charging status.
- **Charging Time:** A full charge typically takes 2-3 hours. Do not overcharge the battery.
- **Safety Precautions:**
  - Only use the provided V6 charger.
  - Charge in a dry, well-ventilated area, away from flammable materials.
  - Do not leave the hoverboard charging unattended for extended periods.

## 5. OPERATING INSTRUCTIONS

---

Learning to ride the V6 Hoverboard requires practice. Start in a safe, open area with assistance if needed.

### 5.1 Mounting

1. Place the hoverboard on a flat, level surface.
2. Stand beside the hoverboard and place one foot firmly on a footpad, close to the wheel.
3. Quickly and confidently step up with your second foot onto the other footpad. Keep your body upright and relaxed.
4. Distribute your weight evenly between both feet.

### 5.2 Riding

- **Forward/Backward:** Gently lean your body slightly forward to move forward. Lean backward to move backward. The degree of lean controls your speed.
- **Turning:** To turn left, gently push your right foot forward while slightly pulling your left foot back. To turn right, push your left foot forward and pull your right foot back.
- **Stopping:** To stop, return to an upright, neutral position. The hoverboard will slow down and come to a stop.

### 5.3 Dismounting

1. Bring the hoverboard to a complete stop.
2. Step off one foot at a time, preferably backward. Do not jump off.

## 6. CALIBRATION

---

If your V6 Hoverboard is not balancing correctly or drifts to one side, it may need calibration.

1. Ensure the hoverboard is powered off.
2. Place the hoverboard on a perfectly flat, level surface.
3. Press and hold the power button for approximately 5-10 seconds until the indicator lights flash rapidly.
4. Release the power button. The lights will continue to flash.
5. Wait for about 30 seconds until the lights stop flashing and remain solid.
6. Power off the hoverboard, then power it back on. The hoverboard should now be calibrated.

## 7. MAINTENANCE

Regular maintenance helps prolong the life of your V6 Hoverboard.

- **Cleaning:** Use a soft, damp cloth to wipe down the exterior of the hoverboard. Do not use harsh chemicals or abrasive cleaners. Avoid getting water into electronic components.
- **Storage:** Store the hoverboard in a cool, dry place, away from direct sunlight and extreme temperatures. If storing for an extended period, charge the battery to about 50% every 2-3 months to maintain battery health.
- **Battery Care:** Do not expose the battery to extreme heat or cold. If the battery is damaged or leaking, discontinue use immediately and dispose of it properly according to local regulations.
- **Tire Inspection:** Periodically check the tires for wear and tear.

## 8. TROUBLESHOOTING

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
Hoverboard does not turn on.	Low or depleted battery.	Charge the hoverboard fully.
Hoverboard is unbalanced or drifts.	Needs calibration.	Perform a calibration as described in Section 6.
Short battery life.	Battery not fully charged; old battery; riding on inclines.	Ensure full charge. Avoid continuous riding on steep inclines. Consider battery replacement if old.
Indicator lights flashing.	System error or low battery warning.	Refer to the specific flash pattern in a more detailed troubleshooting guide (if available) or try restarting/recalibrating. Charge the battery.

## 9. SPECIFICATIONS

- **Model:** V6 Hoverboard

- **ASIN:** B0FS25Z6G9
- **Date First Available:** September 22, 2025
- **Max Speed:** Approximately 7.5 mph (12 km/h) *(Typical for hoverboards, actual speed may vary)*
- **Range:** Approximately 7-10 miles (11-16 km) per charge *(Varies with terrain, rider weight, and speed)*
- **Max Load:** 220 lbs (100 kg)
- **Min Load:** 44 lbs (20 kg)
- **Battery Type:** Lithium-ion (specific capacity not provided)
- **Charging Time:** 2-3 hours

## 10. WARRANTY AND SUPPORT

---

For warranty information, technical support, or service inquiries regarding your V6 Hoverboard, please refer to the warranty card included with your product or contact the manufacturer directly through their official website or customer service channels. Please have your purchase receipt and product serial number available when contacting support.