

Manuals.plus /

- › Aeitto /
- › Aeitto Countertop Ice Maker Machine User Manual

Aeitto B0FZT4K8SS

Aeitto Countertop Ice Maker Machine User Manual

Model: B0FZT4K8SS

INTRODUCTION

Thank you for choosing the Aeitto Countertop Ice Maker Machine. This manual provides essential information for the safe and efficient operation of your new appliance. Please read it thoroughly before first use and keep it for future reference. This ice maker is designed to produce bullet-shaped ice cubes quickly and conveniently for your home, kitchen, or office use.



Image: The Aeitto ice maker positioned on a kitchen counter, surrounded by various beverages, demonstrating its integration into a home setting.

IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or injury when using your ice maker, follow these basic precautions:

- Read all instructions before use.
- Do not touch the evaporator or ice blades when the unit is in operation.
- Do not immerse the appliance, power cord, or plug in water or other liquids.

- Supervise children closely when the appliance is in use.
- Unplug the ice maker from the outlet when not in use, before cleaning, and before servicing.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use only potable water for ice production.
- Ensure the appliance is placed on a stable, level surface.
- Do not block any ventilation openings.

PRODUCT OVERVIEW

Familiarize yourself with the components of your Aeito Countertop Ice Maker Machine.



Image: A front view of the Aeito ice maker, highlighting its capacity to produce 26 pounds of ice in 24 hours.

Main Components:

- **Control Panel:** Features buttons for Power, Ice Size Selection (Small/Large), and indicators for "Add Water", "Ice Full", and "Clean".
- **Ice Basket:** Removable basket for collecting and storing produced ice.
- **Ice Scoop:** Included for convenient serving of ice.
- **Water Reservoir:** Internal tank for holding water used in ice production.
- **Ice Making Mechanism:** Internal components responsible for freezing water into ice cubes.
- **Drain Plug:** Located at the bottom for draining water.

SETUP

Unpacking and Placement:

1. Remove all packaging materials and inspect the ice maker for any damage.
2. Place the ice maker on a flat, stable surface away from direct sunlight and heat sources. Ensure there is at least 4 inches of space around the unit for proper ventilation.
3. Allow the unit to rest upright for at least 1 hour before plugging it in, especially if it was transported horizontally. This allows refrigerants to settle.



Ice-full Reminder

Don't worry about the ice maker working for a long time, it will stop working when the ice production reaches the alert level, to save energy.

Image: The Aeitto ice maker with its compact dimensions (11.9"D x 7.3"W x 10.8"H) highlighted, illustrating its space-saving design.

Initial Cleaning:

Before first use, it is recommended to clean the unit. Refer to the "Maintenance and Cleaning" section for detailed instructions on using the self-cleaning function.

OPERATING INSTRUCTIONS

Making Ice:

1. **Add Water:** Open the lid and fill the water reservoir with potable water up to the MAX fill line. Do not overfill.
2. **Plug In:** Connect the power cord to a grounded electrical outlet.
3. **Power On:** Press the **ON/OFF** button to turn on the ice maker.
4. **Select Ice Size:** Press the **SELECT** button to choose between Small (S) or Large (L) ice cubes. The corresponding indicator light will illuminate.



Image: A visual comparison of the two available ice cube sizes: Small (20mm*28mm) and Large (23mm*30mm).

5. **Ice Production:** The ice maker will begin the ice-making cycle. The first batch of bullet ice cubes will be ready in approximately 6 minutes.
6. **Ice Full Reminder:** When the ice basket is full, the "ICE FULL" indicator light will turn on, and the ice maker will automatically stop production to prevent overflow and save energy. Empty the ice basket to resume ice making.



Image: An internal view of the ice maker showing the ice-full sensor, which detects when the ice basket is at capacity.

7. **Add Water Reminder:** If the water level in the reservoir is too low, the "ADD WATER" indicator light will illuminate, and the unit will pause. Add more water to resume operation.
8. **Stopping Operation:** Press the **ON/OFF** button to stop the ice maker at any time.



Image: Close-up view of the ice maker's mechanism releasing 8 bullet-shaped ice cubes, illustrating the rapid production cycle of 6 minutes.

MAINTENANCE AND CLEANING

Self-Cleaning Function:

The ice maker features an automatic self-cleaning function to maintain hygiene and prevent limescale buildup.

1. Ensure the unit is empty of ice and water.
2. Fill the water reservoir with clean water up to the MAX line.
3. Press and hold the **ON/OFF** button for 5 seconds. The "CLEAN" indicator light will illuminate, and the unit will begin a 15-minute cleaning cycle.
4. Once the cycle is complete, drain the water from the unit by removing the drain plug at the bottom.
5. Rinse the interior with fresh water and drain again.

Self-Cleaning Function



Image: A three-step visual guide demonstrating the self-cleaning process: 1) Add water, 2) Press and hold ON/OFF for 5 seconds, 3) Self-cleaning for 15 minutes.

Regular Cleaning and Descaling:

- Wipe the exterior with a soft, damp cloth.
- For descaling, especially in hard water areas, perform the self-cleaning cycle with a mixture of water and vinegar or a descaling solution. Follow the solution's instructions.
- Descaling frequency: Monthly in moderately hard water areas, or every two to three weeks in hard to very hard water areas.



Image: A map illustrating regions with varying water hardness, alongside recommendations for descaling frequency based on water mineral concentration.

- Always rinse thoroughly after descaling to remove any cleaning solution residue.

TROUBLESHOOTING

Review the following common issues and solutions before contacting customer support.

Problem	Possible Cause	Solution
Ice maker not producing ice.	"ADD WATER" indicator is on. Unit needs time to cool water.	Add potable water to the reservoir. Allow a few minutes for the unit to prepare for the next cycle.
Ice melts quickly in the basket.	The ice maker is not a freezer. Ice is still wet when dropped.	Transfer ice to a freezer for storage immediately after production. This is normal operation; the ice maker's basket is not refrigerated.
Machine is noisy during operation.	Normal operational sounds (compressor, water pump). Unit not on a level surface.	Some noise is expected. Ensure the unit is on a stable, level surface to minimize vibrations.
Ice cubes are too small or thin.	"Small" ice size selected. Water temperature is too high.	Select "Large" ice size. Use colder water for faster and thicker ice production.
"ICE FULL" indicator is on, but basket is not full.	Ice cubes are blocking the sensor.	Rearrange or remove some ice cubes from the basket.

SPECIFICATIONS

- **Brand:** Aeitto
- **Model:** B0FZT4K8SS
- **Ice Production Capacity:** Up to 26 lbs (11.8 kg) per 24 hours
- **Ice Production Speed:** Approximately 8 bullet ice cubes in 6 minutes
- **Ice Cube Sizes:** Two selectable sizes (Small: 20mm*28mm, Large: 23mm*30mm)
- **Dimensions (D x W x H):** 11.9" x 7.3" x 10.8" (30.2 cm x 18.5 cm x 27.4 cm)
- **Weight:** Approximately 12.5 lbs (5.7 kg)
- **Features:** Automatic self-cleaning function, "Add Water" indicator, "Ice Full" indicator, portable design.

WARRANTY AND CUSTOMER SUPPORT

Aeitto products are manufactured to high-quality standards. For warranty information, technical assistance, or any questions regarding your ice maker, please refer to the warranty card included with your purchase or contact Aeitto customer support directly. Contact details can typically be found on the manufacturer's official website or on the product packaging.

Please have your model number (B0FZT4K8SS) and purchase date ready when contacting support.

