

[Manuals.plus](#) /

› [Warehouse of Tiffany](#) /

› Warehouse of Tiffany Angel 3-Light Crystal Chandelier 5-Blade Ceiling Fan Instruction Manual

## Warehouse of Tiffany CFL-8110REMO/CHx

# Warehouse of Tiffany Angel 3-Light Crystal Chandelier 5-Blade Ceiling Fan

MODEL: CFL-8110REMO/CHx

## 1. Safety Information

---

Please read and understand all instructions before beginning installation. Failure to follow these instructions may result in electric shock, fire, or personal injury.

- **WARNING:** To reduce the risk of electric shock, ensure electricity is turned off at the circuit breaker or fuse box before installation or servicing.
- All wiring must be in accordance with national and local electrical codes. If you are unfamiliar with wiring, consult a qualified electrician.
- Mounting structure must be capable of supporting the weight of the fan (approximately 35 lbs).
- Do not operate the fan with damaged blades or housing.
- Keep hands, clothing, and other objects clear of fan blades when the fan is in operation.
- This fan is designed for indoor use only.

## 2. Package Contents

---

Verify that all components are present before beginning installation. If any parts are missing or damaged, do not proceed with installation and contact customer support.

- Fan Motor Housing Assembly
- Ceiling Mounting Bracket
- Downrod and Canopy
- Fan Blades (5)
- Blade Brackets
- Light Kit Assembly

- Crystal Chandelier Shade
- Remote Control with Wall Mount
- Hardware Pack (screws, wire nuts, washers)
- Instruction Manual

### 3. Setup and Installation

---

Follow these steps carefully for proper installation. It is recommended to have two people for installation.

1. **Turn Off Power:** Ensure the power supply to the fan location is turned off at the circuit breaker or fuse box.
2. **Install Mounting Bracket:** Secure the ceiling mounting bracket to the ceiling junction box. Ensure the junction box is securely fastened to the building structure and can support the fan's weight.
3. **Assemble Downrod:** Insert the downrod through the canopy and connect it to the fan motor housing. Secure with pins and screws as directed.
4. **Hang Fan Assembly:** Carefully lift the fan assembly and hang it on the mounting bracket using the hook provided on the downrod ball.
5. **Wiring:** Connect the electrical wires from the fan to the supply wires in the ceiling according to the wiring diagram in the manual. Use the provided wire nuts. Ensure all connections are secure.
6. **Secure Canopy:** Slide the canopy up to the ceiling and secure it to the mounting bracket with the provided screws.
7. **Attach Fan Blades:** Attach the fan blades to the blade brackets, then secure the blade brackets to the motor housing. Ensure all screws are tightened.
8. **Install Light Kit:** Connect the light kit wiring to the fan motor housing wiring. Secure the light kit assembly to the bottom of the fan motor housing.
9. **Attach Crystal Chandelier Shade:** Carefully attach the crystal chandelier shade to the light kit assembly. Ensure all crystals are securely in place.
10. **Install Light Bulbs:** Screw in the required incandescent light bulbs (not included) into the sockets.



**Image:** Dimensional diagram of the ceiling fan, illustrating side and top views with measurements in inches. This helps in planning installation space.

## 4. Operating Instructions

---

This ceiling fan is operated using the included remote control.



**Image:** The Warehouse of Tiffany Angel Ceiling Fan with its remote control. The remote allows for convenient operation of fan speeds and lighting.

### Remote Control Functions:

- **Fan ON/OFF:** Press the fan button to turn the fan on or off.
- **Fan Speed Control:** Use the speed buttons (typically 1, 2, 3 or low, medium, high) to adjust the fan's rotation speed. This fan features three speeds.
- **Light ON/OFF:** Press the light button to turn the chandelier lights on or off.
- **Light Dimming:** If your remote has a dimming function (often a long press on the light button), you can adjust the brightness of the incandescent bulbs.
- **Fan Direction (if applicable):** Some fans have a reverse switch on the motor housing to change blade direction for summer (downward airflow) or winter (upward airflow). Consult the fan motor housing for this switch.

## 5. Maintenance

---

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:** Periodically wipe the fan blades, motor housing, and crystal shade with a soft, damp cloth. Do not use abrasive cleaners or solvents. Ensure power is off before cleaning.
- **Crystal Care:** For the crystal chandelier, use a soft, lint-free cloth to gently clean the crystals. A mild glass cleaner can be used sparingly if needed, applied to the cloth, not directly to the crystals.
- **Bulb Replacement:** Ensure power is off before replacing light bulbs. Use incandescent bulbs as specified for the fixture. Do not exceed the maximum wattage indicated on the light kit.
- **Tighten Fasteners:** Check all screws and fasteners on the fan blades, motor housing, and mounting

bracket periodically to ensure they are secure.

## 6. Troubleshooting

---

If you experience issues with your ceiling fan, refer to the following common problems and solutions.

- **Fan Does Not Start:**
  - Check that the power is turned on at the circuit breaker.
  - Ensure all wire connections are secure.
  - Verify that the remote control batteries are working and correctly inserted.
- **Lights Do Not Work:**
  - Check that the power is turned on at the circuit breaker.
  - Ensure all wire connections to the light kit are secure.
  - Verify that the light bulbs are screwed in tightly and are not burnt out.
- **Fan Wobbles:**
  - Ensure all blade screws are tightened.
  - Check that the mounting bracket is securely fastened to the ceiling.
  - Verify that the downrod is properly seated in the mounting bracket.
  - Ensure blades are balanced. A balancing kit (often sold separately) can help.
- **Noisy Operation:**
  - Check that all screws on the fan housing and blades are tight.
  - Ensure the canopy is not touching the ceiling.
  - Allow a 24-hour break-in period for new fans; some noise may decrease over time.

## 7. Specifications

---

Key technical specifications for the Warehouse of Tiffany Angel Ceiling Fan.

Feature	Detail
Brand	Warehouse of Tiffany
Model Number	CFL-8110REMO/CHx
Style	Modern & Contemporary
Material	Metal, Glass Crystal, Composites
Color	Silver fixture with Brown blades
Light Type	3-Light Chandelier, Incandescent
Fan Speeds	3-Speed
Room Type	Medium Rooms up to 175 sq. ft
Usage	Indoor use only
Power Source	DC

Dimensions (L x W x H)	43"L x 43"W x 24"H
Airflow (High Speed)	3,246 Cubic Feet Per Minute
Electricity Use (Fan Only)	37 Watts
Airflow Efficiency	89 Cubic Feet Per Minute Per Watt
Estimated Yearly Energy Cost	\$27 (based on 12 cents per kWh and 6.4 hours use per day)



**Image:** Energy Information label detailing the fan's airflow (3,246 CFM), electricity use (37 Watts excluding lights), and airflow efficiency (89 CFM/Watt) at high speed.

# ENERGYGUIDE

Estimated  
Yearly Energy Cost  
**\$27**



Cost Range of Similar Models (19" – 83")

- Based on 12 cents per kWh and 6.4 hours use per day
- **Your cost depends on rates and use**
- Energy Use: 52 Watts

Ceiling fan CFL-8110REMO/CH  
**Airflow**

**4067**

Cubic Feet Per Minute

- The higher the airflow, the more air the fan will move
- Airflow Efficiency: 79 Cubic Feet Per Minute Per Watt



All estimates based on typical use, excluding lights

[ftc.gov/energy](http://ftc.gov/energy)

**Image:** EnergyGuide label indicating an estimated yearly energy cost of \$27 and an airflow of 4067 Cubic Feet Per Minute for the CFL-8110REMO/CHx model.

## 8. Warranty and Support

For warranty information or technical support, please refer to the documentation included with your purchase or contact Warehouse of Tiffany customer service. Keep your proof of purchase for any warranty claims.

**Contact Information:** Please visit the official Warehouse of Tiffany website or refer to your purchase receipt for customer service contact details.