

## Aeitto ICM125

# Aeitto ICM125 Countertop Ice Maker User Manual

Model: ICM125

<a href="#">Introduction</a>	<a href="#">Product Overview</a>	<a href="#">Setup</a>	<a href="#">Operation</a>	<a href="#">Maintenance</a>	<a href="#">Troubleshooting</a>
	<a href="#">Specifications</a>		<a href="#">Warranty &amp; Support</a>		

## 1. Introduction

---

Thank you for choosing the Aeitto ICM125 Countertop Ice Maker. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new ice machine. Please read these instructions thoroughly before first use and retain them for future reference.

### Important Safety Instructions

- Ensure the ice maker is placed on a stable, level surface away from direct sunlight and heat sources.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Supervise children when the appliance is in use.
- Use only potable water in the ice maker.
- Unplug the appliance before cleaning or when not in use.
- This appliance uses flammable refrigerant. Handle with care and do not puncture refrigerant tubing.

## 2. Product Overview

---

The Aeitto ICM125 is a portable countertop ice maker designed for convenience and efficiency. It produces bullet-shaped ice cubes in two sizes.

### Components:

- Ice Maker Unit
- Ice Basket
- Ice Scoop

# Release Ice in 6 Mins

No need to wait for a long time



Figure 2.1: Aeitto ICM125 Countertop Ice Maker. This image displays the main unit with its transparent lid open, revealing the ice basket and the control panel on the front.

## 3. Setup

---

### 3.1 Unpacking

1. Remove all packaging materials and accessories.
2. Inspect the ice maker for any damage. If damaged, do not operate and contact customer support.
3. Clean the interior of the ice maker, ice basket, and ice scoop with warm water and a mild detergent before first use. Rinse thoroughly.

### 3.2 Placement

- Place the ice maker on a flat, stable, and heat-resistant surface.
- Ensure there is at least 6 inches (15 cm) of clearance around the appliance for proper ventilation.
- Avoid placing the unit near heat sources or in direct sunlight.

### 3.3 Initial Use

Before making ice for consumption, it is recommended to run the self-cleaning cycle once or twice to ensure the internal components are clean.

## 4. Operation

### 4.1 Adding Water

1. Open the lid and remove the ice basket.
2. Fill the water reservoir with potable water up to the MAX fill line. Do not overfill.
3. Replace the ice basket and close the lid.

### 4.2 Powering On and Selecting Ice Size

1. Plug the ice maker into a grounded electrical outlet.
2. Press the **ON/OFF** button to turn on the appliance. The "POWER" indicator will illuminate.
3. Press the **SELECT** button to choose your desired ice cube size:
  - **SMALL:** For faster melting in drinks, ideal for iced coffee or cocktails.
  - **LARGE:** For slower melting, suitable for smoothies or food preservation.



Figure 4.1: Ice Cube Sizes. This image illustrates the two available ice cube sizes, small and large, produced by the ice maker.

### 4.3 Ice Production Cycle

- The ice maker will begin producing ice approximately 6 minutes after starting.
- The "ICE FULL" indicator will illuminate when the ice basket is full, and the machine will pause ice

production. Remove ice to resume.

- The "ADD WATER" indicator will illuminate when the water reservoir is low. Add more water to resume ice production.

**Note:** The ice maker does not have a refrigeration function for storing ice long-term. It is recommended to transfer ice to a freezer for storage once produced.

## 5. Maintenance

### 5.1 Auto-Cleaning Function

The ice maker features an auto-cleaning function to help remove mineral buildup and maintain hygiene. It is recommended to use this function weekly.

1. Ensure the water reservoir is filled with clean water.
2. Press and hold the **ON/OFF** button for 5 seconds. The "CLEAN" indicator will illuminate, and the cleaning cycle will begin.
3. The cleaning cycle typically lasts for 15 minutes.
4. Once the cycle is complete, drain the water from the reservoir.



Figure 5.1: Self-Cleaning Function. This image illustrates the internal water circulation during the self-cleaning process, highlighting its benefits for fresh ice and limescale removal.

## 5.2 Regular Cleaning

- **Exterior:** Wipe the exterior with a soft, damp cloth.
- **Interior:** For thorough cleaning, unplug the unit, remove the ice basket, and drain all water. Clean the interior with a soft cloth and a mild, non-abrasive cleaner. Rinse thoroughly and dry.
- **Ice Basket & Scoop:** Wash with warm, soapy water and rinse well.

## 5.3 Draining Water

To drain water from the reservoir, locate the drain plug at the bottom of the unit. Place a container underneath and remove the plug to allow water to flow out. Replace the plug securely after draining.

## 5.4 Storage

When storing the ice maker for an extended period, ensure it is completely dry. Drain all water, clean the unit, and leave the lid slightly ajar to prevent mold and mildew growth. Store in a cool, dry place.

## 6. Troubleshooting

Problem	Possible Cause	Solution
Ice maker not working.	Not plugged in; power outage; unit off.	Ensure unit is plugged in; check power supply; press ON/OFF button.
"ADD WATER" indicator on.	Water reservoir is empty or low.	Add potable water to the MAX fill line.
"ICE FULL" indicator on.	Ice basket is full.	Remove ice from the basket.
Ice cubes are too small or cloudy.	Water temperature too high; air bubbles in water.	Use colder water; ensure water is fresh. Select "LARGE" ice size.
Water leakage.	Drain plug not secured; unit not level.	Check and secure the drain plug; ensure the unit is on a level surface.

## 7. Specifications

Feature	Detail
Model Name	ICM125
Brand	Aeitto
Ice Production	Up to 26 lbs (11.8 kg) per 24 hours
Ice Cube Production Cycle	9 cubes in approximately 6 minutes
Ice Cube Sizes	Small, Large
Self-Cleaning Function	Yes
Dimensions (Approx.)	8.74" (W) x 10.43" (D) x 10.98" (H)

# Sleek & Space-Saving Design

Without taking up valuable counter space



Figure 7.1: Product Dimensions. This image provides a visual representation of the ice maker's dimensions for placement reference.

## 8. Warranty and Support

### 8.1 Warranty Information

Aeitto products are manufactured to the highest quality standards. For detailed warranty information, please refer to the warranty card included with your product or visit the official Aeitto website. Keep your purchase receipt as proof of purchase for warranty claims.

### 8.2 Customer Support

If you have any questions, concerns, or require assistance with your Aeitto ICM125 Ice Maker, please contact our customer support team:

- **Email:** [support@aeitto.com](mailto:support@aeitto.com)
- **Website:** [www.aeitto.com](http://www.aeitto.com)
- **Facebook:** [facebook.com/aeitto](https://facebook.com/aeitto)
- **Phone:** 1-855-835-9999 (Toll-Free)

Please have your model number (ICM125) and purchase date available when contacting support.

