

[Manuals.plus](#) /

› [SofaBaton](#) /

› SofaBaton X2 Universal Remote with Touchscreen and Hub - Instruction Manual

SofaBaton SofaBaton X2

SofaBaton X2 Universal Remote with Touchscreen and Hub - Instruction Manual

INTRODUCTION

The SofaBaton X2 Universal Remote is a sophisticated control system designed to unify your home entertainment and smart home devices. Featuring a 2.4-inch HD touchscreen and multi-protocol support (IR, Bluetooth, RF, Wi-Fi), it can command over 500,000 devices from more than 6,000 brands. This manual provides detailed instructions for setting up, operating, and maintaining your SofaBaton X2 remote and its powerful hub.

WHAT'S IN THE BOX

- SofaBaton X2 Universal Remote with Touchscreen
- Powerful Hub
- Type-C Charging Dock
- USB-C Charging Cable
- User Manual (this document)

One-Touch Control with Customizable Activities

Activate Multiple Devices Simultaneously with a Single Button Press



Image: The SofaBaton X2 remote, its powerful hub, and the charging dock laid out on a wooden surface.

SETUP GUIDE

1. Connect the Hub to Your Smartphone

1. Install the SofaBaton application on your smartphone.
2. Connect your smartphone to the 2.4 GHz Wi-Fi network of your home.
3. Power on the SofaBaton Hub by connecting it to a power outlet.
4. Press and hold the button on the hub for 3 seconds until the blue light blinks, indicating pairing mode.
5. Open the SofaBaton app, select 'X Series', then 'Setup New Hub'.
6. Follow the on-screen prompts to connect the hub to your Wi-Fi network.

SofaBaton X2 Universal Remote

Meet the Ultimate Universal Remote with
Touchscreen & Charging Dock



Image: The SofaBaton Hub centrally located in a home, illustrating its extended range and connectivity to multiple devices across different rooms.

2. Pair the Remote with the Hub

1. In the SofaBaton app, navigate to 'Me' then 'Settings'.
2. Select 'Paired Remotes' and then 'Pair New Remote'.
3. On the X2 remote's touchscreen, go to 'Settings' and select 'Pair New Hub'.
4. The remote will automatically pair with the hub.

3. Add Devices

1. In the SofaBaton app, go to the 'Devices' tab and tap the '+' icon.
2. Choose the control method for your device (Infrared, Bluetooth, Wi-Fi, or RF).
3. **For Infrared Devices:** You can either 'Search in the database' by brand/model or use 'Learning' mode to teach the hub commands from your original remote.
4. **For Wi-Fi Devices (Roku, Sonos, Philips Hue):** The app will scan for compatible devices on your network. Select your device and follow any specific on-screen instructions (e.g., enabling 'Permissive' access on Roku TVs).
5. **For Bluetooth Devices (Apple TV, Fire TV):** The app will guide you to your device's Bluetooth settings to complete pairing.
6. Name your device and select an icon, then tap 'Complete'. The code library will download and sync to your remote.



Image: The SofaBaton X2 remote and hub illustrating connectivity to a wide range of home entertainment devices and brands.

4. Add Activities

Activities allow you to execute multiple commands across different devices with a single touch. For example, a 'Watch TV' activity could turn on your TV, soundbar, and set the correct inputs.

1. In the SofaBaton app, navigate to the 'Activities' tab and tap the '+' icon.
2. Select the devices you want to include in the activity.
3. Configure power settings (on/off sequence) and source configuration (input switching) for each device within the activity.
4. Assign volume control to your preferred device (e.g., TV or soundbar).
5. Name your activity and select an icon, then tap 'Complete'.

HA Remote & Supports Home Assistant

Unlock smart home automation through Home Assistant enables true cross-platform synchronization




Image: A hand holding the SofaBaton X2 remote, demonstrating one-touch control to activate multiple devices simultaneously for a customizable activity.

OPERATING THE REMOTE

Touchscreen Navigation

The 2.4-inch HD touchscreen allows for intuitive navigation. Swipe left or right to access different screens, and tap on icons to select devices, activities, or settings. Dedicated shortcut buttons below the display provide quick access to number pads and macros.



Image: The intuitive touchscreen of the SofaBaton X2 remote displaying navigation options and an on-screen number pad.

Physical Buttons

The remote features backlit physical buttons for essential controls like volume, channel, and playback, ensuring ease of use even in low-light conditions.

Voice Control

The SofaBaton X2 supports voice commands via Alexa and Google Assistant for operating pre-programmed activities (on/off). This enables hands-free control of your home theater system.



Image: A man relaxing on a sofa, using voice commands with an Alexa device to control his smart home lighting, demonstrating the smart voice control feature.

HOME ASSISTANT INTEGRATION

Achieve seamless smart home automation through native Home Assistant integration. By adding the SofaBaton integration to your HA system, you can utilize Home Assistant automations to trigger activities on your remote, enabling true cross-platform device synchronization and creating a unified smart home entertainment experience. The SofaBaton X2 can also act as a dedicated physical controller for Home Assistant. Through MQTT integration, your HA system can subscribe to remote commands and trigger supported automation functions, enabling direct control of audio-video equipment, lighting, curtains, and other smart devices directly from your remote.



Image: A smartphone displaying the Home Assistant interface, highlighting the seamless integration with SofaBaton for smart home control.

SofaBATON APP CONTROL & CUSTOMIZATION

Maximize your control with the SofaBaton APP that offers deep customization and smart functionality. Design custom button layouts for each device, create macros, reassign buttons, and access advanced programming features beyond physical button limitations. The SofaBaton all-in-one universal remote ensures smooth operation while automatically backing up your settings to the cloud for storage and easy retrieval.




Image: Multiple smartphone screens showcasing the SofaBaton app's interface with various customization options for devices, activities, and settings.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the remote and hub. Avoid liquid cleaners.
- **Battery:** The remote uses 1 Nonstandard Battery (included). Recharge regularly using the provided Type-C charging dock to ensure continuous operation.
- **Storage:** Store the remote and hub in a cool, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

- **Remote not responding:** Ensure the remote is charged. Check if the hub is powered on and connected to Wi-Fi.
- **Device not responding:** Verify the device is correctly added and configured in the SofaBaton app. Ensure the correct control method (IR, Bluetooth, Wi-Fi, RF) is selected. For IR devices, ensure the hub or IR blaster has a clear line of sight.
- **Pairing issues:** Ensure your smartphone is connected to a 2.4 GHz Wi-Fi network during hub setup. Make sure the hub's blue light is blinking during pairing.
- **Activities not working:** Check the power settings and source configuration for all devices within the activity in the SofaBaton app.

SPECIFICATIONS

- **Product Dimensions:** 6 x 4 x 11 inches
- **Item Weight:** 2.2 pounds
- **Item Model Number:** SofaBaton X2
- **Batteries:** 1 Nonstandard Battery (included)
- **Special Features:** Backlit, Charging Dock, Remote Finder, Touchscreen, Universal Remote Compatible
- **Color:** Black
- **Max Number of Supported Devices:** 50
- **Compatible Devices:** Television, Streaming Device, DVD/Blu-ray Player, Home Theater, Soundbar

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official SofaBaton website or contact their customer service directly. Keep your purchase receipt for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question