



[Manuals.plus](#) /

› [Olakids](#) /

› OLAKIDS Kids Bike 14-Inch User Manual

**Olakids TS10352**

# OLAKIDS Kids Bike 14-Inch User Manual

Model: TS10352

## 1. INTRODUCTION

---

Thank you for choosing the OLAKIDS 14-inch Kids Bike. This manual provides essential information for the safe assembly, operation, and maintenance of your child's bicycle. Please read these instructions carefully before assembly and use, and retain them for future reference. This bike is designed for children aged 3-6 years with a rider height of 37.4"-43.3" (95-110 cm).



Image: A child riding the OLAKIDS 14-inch Kids Bike.

## 2. SAFETY INFORMATION

---

Always prioritize safety when operating the bicycle. Failure to follow these safety guidelines may result in injury.

- **Helmet Use:** Always ensure the rider wears a properly fitted helmet that meets safety standards.
- **Supervision:** Children should always be supervised by an adult while riding.
- **Pre-Ride Check:** Before each ride, check that the brakes are functioning correctly, tires are properly inflated, and all bolts and quick releases are securely tightened.
- **Riding Environment:** Ride in safe areas away from traffic, obstacles, and steep inclines.
- **Reflectors and Bell:** Ensure all reflectors are clean and visible, and the safety bell is functional to alert others.
- **Clothing:** Avoid loose clothing that could get caught in the wheels or chain.

# For Safe Riding



Image: Sturdy carbon steel frame and fully enclosed chain guard for safe riding.

## 3. PACKAGE CONTENTS

The OLAKIDS Kids Bike is 85% pre-assembled. Please verify that all components listed below are present in the packaging before beginning assembly.

- 1 x OLAKIDS Kids Bike (main frame with wheels, chain, and rear brake pre-assembled)
- 1 x Handlebar assembly
- 1 x Seat post with saddle
- 2 x Training Wheels (detachable)
- 2 x Pedals
- 1 x DIY Drawing Board
- 1 x Safety Bell
- 1 x User Guide
- 1 x Wrench and other essential assembly tools

# 85% Pre-installed



Image: All included components for the OLAKIDS Kids Bike.

## 4. ASSEMBLY INSTRUCTIONS

Follow these steps to complete the assembly of your OLAKIDS Kids Bike.

1. **Install the Handlebar:** Insert the handlebar stem into the fork tube. Ensure the handlebar is straight and aligned with the front wheel. Tighten the stem bolt securely using the provided wrench.
2. **Attach the Front Wheel (if not pre-installed):** If the front wheel is separate, align it with the fork dropouts and insert the axle. Secure it with the axle nuts, ensuring the wheel spins freely and is centered.
3. **Install the Seat Post:** Insert the seat post with the saddle into the seat tube of the bike frame. Adjust the height as needed (refer to Section 5) and tighten the quick-release lever or bolt securely.
4. **Attach the Pedals:** Identify the left (L) and right (R) pedals. The left pedal screws counter-clockwise, and the right pedal screws clockwise. Thread them into the crank arms and tighten firmly with the wrench.
5. **Install Training Wheels:** Attach the training wheels to the rear axle using the provided bolts and washers. Ensure they are securely fastened and provide stable support.
6. **Attach DIY Drawing Board and Bell:** Secure the DIY drawing board to the handlebar using the

provided fasteners. Mount the safety bell on the handlebar in an easily accessible position.

7. **Final Checks:** Double-check all bolts, nuts, and quick releases for tightness. Ensure brakes are functional and tires are inflated to the recommended pressure.

## 5. ADJUSTMENTS

---

Proper adjustments ensure comfort and safety for the rider.

### 5.1 Seat Height Adjustment

The seat height is adjustable to accommodate your child's growth. To adjust, loosen the quick-release lever or bolt on the seat post clamp, raise or lower the seat until the child can comfortably touch the ground with their toes while seated, then re-tighten securely.

### 5.2 Handlebar Height Adjustment

The handlebar height can be adjusted by loosening the stem bolt, raising or lowering the handlebar to a comfortable position for the rider, and then re-tightening the bolt firmly.

### 5.3 Training Wheels Adjustment/Removal

The detachable training wheels provide stability for beginners. As your child gains confidence and balance, the training wheels can be removed. To remove, simply loosen the bolts securing them to the rear axle and detach.

# Grow with Kid



Image: Adjustable seat and detachable training wheels for growing children.

## 6. OPERATING THE BIKE

Understanding the bike's controls is crucial for safe riding.

### 6.1 Braking System

This bike is equipped with a dual braking system for enhanced safety:

- **Handbrake:** Located on the handlebar, this brake controls the front wheel. Squeeze the lever gently to slow down or stop.
- **Coaster Brake:** Activated by pedaling backward, this brake controls the rear wheel. Apply backward pressure on the pedals to engage.

Teach your child to use both brakes smoothly and effectively. Practice braking in a safe, open area.

# Dual Brake System



Image: Dual brake system featuring handbrake and coaster brake.

## 6.2 DIY Drawing Board

The integrated DIY drawing board allows children to personalize their bike. Use washable markers to draw and color on the board, fostering creativity. Ensure the board is clean and dry before each use.



## Creative DIY Drawing Board

Graffiti, creations—Let kids unleash every wild idea in their minds

Image: Creative DIY drawing board on the handlebar.

## 7. MAINTENANCE

---

Regular maintenance will prolong the life of the bicycle and ensure safe operation.

- **Cleaning:** Clean the bike regularly with a damp cloth and mild soap. Avoid using high-pressure washers directly on bearings or electrical components.
- **Tire Pressure:** Check tire pressure before each ride. Maintain the recommended PSI (pounds per square inch) indicated on the tire sidewall.
- **Chain Lubrication:** Periodically lubricate the chain with bicycle-specific chain lubricant to ensure smooth operation and prevent rust.
- **Brake Inspection:** Regularly inspect brake pads for wear and brake cables for fraying. Adjust brake tension as needed to ensure effective stopping power.
- **Bolt Tightness:** Periodically check and tighten all bolts and nuts, especially on the handlebars, seat post, wheels, and pedals.
- **Storage:** Store the bike in a dry place, away from direct sunlight and extreme temperatures, to prevent rust and material degradation.

# Child-Friendly Details



Comfortable Widen Seat



Safety Bell



Anti-slip Handlebars



Different Reflectors

Image: Child-friendly details including comfortable seat, safety bell, anti-slip handlebars, and reflectors.

## 8. TROUBLESHOOTING

This section addresses common issues you might encounter.

- **Brakes not engaging effectively:** Check brake cable tension and brake pad alignment. Adjust as necessary. Ensure brake pads are not worn out.
- **Pedals are stiff or noisy:** Lubricate the pedal bearings if possible, or check if pedals are securely tightened.
- **Chain slipping or noisy:** Clean and lubricate the chain. Check for bent or damaged chain links.
- **Tires losing air quickly:** Inspect tires for punctures. Check valve stem for leaks. Ensure tire beads are properly seated on the rim.
- **Bike feels unstable:** Ensure all bolts, especially on the handlebars and wheels, are securely tightened. Check if training wheels (if installed) are properly aligned and tightened.

## 9. SPECIFICATIONS

Detailed specifications for the OLAKIDS 14-inch Kids Bike.

<b>Feature</b>	<b>Specification</b>
Model Number	TS10352
Bike Type	Kids Bike
Wheel Size	14 Inches
Frame Material	Carbon Steel
Brake Style	Handbrake (Front), Coaster Brake (Rear)
Number of Speeds	1
Seat Height Range	20"-22" (51-55 cm)
Handlebar Height	29" (73 cm)
Recommended Age Range	3-6 Years
Recommended Rider Height	37.4"-43.3" (95-110 cm)
Maximum Weight Capacity	143 lbs (65 kg)
Product Dimensions	100.99 x 50.01 x 75.01 cm
Item Weight	11.09 kg
Assembly Required	Yes (85% pre-assembled)

# Product Size



Bike Size	Seat Height	Handlebar Height	Age Range	Rider Height	Max Weight Capacity
12 inch	17"-20"/44.5-49.5 cm	26"/66 cm	3-4	31.5"-41.3"/80-105 cm	143 lbs/65 kg
14 inch	20"-22"/51-55 cm	29"/73 cm	3-6	37.4"-43.3"/95-110 cm	143 lbs/65 kg
16 inch	21"-25"/55-63 cm	31"/79 cm	4-7	41.3"-51.2"/105-130 cm	143 lbs/65 kg
18 inch	23"-27"/59-67 cm	33"/84 cm	5-9	47.2"-59.1"/120-150 cm	148 lbs/67 kg

Image: Product size diagram and specification table.

## 10. WARRANTY AND SUPPORT

The OLAKIDS Kids Bike comes with a **6-month warranty** from the date of purchase, covering manufacturing defects. This warranty does not cover damage resulting from misuse, accidents, improper assembly, or normal wear and tear.

For technical support, warranty claims, or any questions regarding your product, please contact the manufacturer:

**Manufacturer:** Olakids

**Contact Information:** AKUSTIK, 11250 POPLAR AVE BLDG C, FONTANA

Please have your model number (TS10352) and proof of purchase ready when contacting support.