

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Mikado](#) /

› [Mikado MD-SBT32 Bluetooth Soundbar Speaker User Manual](#)

Mikado MD-SBT32

Mikado MD-SBT32 Bluetooth Soundbar Speaker User Manual

Model: **MD-SBT32** | Brand: **Mikado**

1. INTRODUCTION

Thank you for purchasing the Mikado MD-SBT32 Bluetooth Soundbar Speaker. This manual provides essential information for the safe and efficient operation of your device. Please read it thoroughly before use and retain it for future reference.

2. PACKAGE CONTENTS

Ensure all items listed below are present in your package:

- Mikado MD-SBT32 Bluetooth Soundbar Speaker
- USB Type-C Charging Cable
- AUX Audio Cable
- User Manual (this document)

3. PRODUCT OVERVIEW

Familiarize yourself with the components and controls of your MD-SBT32 soundbar.



Figure 3.1: Top view of the soundbar, illustrating the speaker grille and integrated control buttons.

3.1. Control Buttons

- **Power Button ():** Press and hold to power on/off. Short press to change input mode (Bluetooth/AUX).
- **Volume Down (-):** Decrease volume.
- **Play/Pause Button (▶):** Play or pause audio.
- **Volume Up (+):** Increase volume.
- **RGB Light Button:** Short press to cycle through 7 RGB light modes.



Figure 3.2: Rear view of the soundbar, highlighting the Type-C charging port and AUX input.

3.2. Input Ports

- **Type-C Port:** Used for charging the soundbar.
- **AUX Input:** For wired audio connection using the provided 3.5mm AUX cable.

4. SETUP

4.1. Charging the Soundbar

1. Connect the supplied USB Type-C charging cable to the Type-C port on the soundbar.
2. Connect the other end of the USB cable to a compatible USB power adapter (DC 5V 2A recommended, not included).
3. The charging indicator light will illuminate. A full charge takes approximately 4 hours.
4. Once fully charged, the indicator light will change or turn off, and the soundbar is ready for use.

4.2. Powering On/Off

- **To Power On:** Press and hold the Power Button () for a few seconds until the indicator light turns on

and you hear an audible prompt.

- **To Power Off:** Press and hold the Power Button () again for a few seconds until the indicator light turns off and you hear an audible prompt.

5. OPERATING INSTRUCTIONS

5.1. Bluetooth Connection

The MD-SBT32 uses Bluetooth version 5.3 for stable wireless audio streaming.

1. Ensure the soundbar is powered on and in Bluetooth mode. If not, short press the Power Button () to cycle through modes until you hear the Bluetooth pairing prompt. The indicator light will flash, indicating it is ready to pair.
2. Enable Bluetooth on your audio device (smartphone, tablet, computer).
3. Search for available Bluetooth devices and select "**MD-SBT32**" from the list.
4. Once connected, the soundbar will emit a confirmation tone, and the indicator light will stop flashing.
5. You can now play audio wirelessly from your device through the soundbar.

5.2. AUX (Wired) Connection

1. Connect one end of the supplied 3.5mm AUX audio cable to the AUX input port on the soundbar.
2. Connect the other end of the AUX cable to the headphone jack or audio output port of your audio device.
3. Short press the Power Button () on the soundbar to switch to AUX input mode. You will hear an audible prompt confirming the mode change.
4. Adjust the volume on both your audio device and the soundbar.

5.3. RGB Light Modes

The MD-SBT32 features 7 distinct RGB light modes.

- Short press the dedicated **RGB Light Button** on the soundbar to cycle through the available light modes.
- Continue pressing to find your preferred lighting effect.

5.4. Basic Audio Controls

- **Volume Adjustment:** Use the **Volume Up (+)** and **Volume Down (-)** buttons on the soundbar to adjust the playback volume.
- **Play/Pause:** Press the **Play/Pause Button (▶)** to pause or resume audio playback in Bluetooth mode.

6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the surface of the soundbar. Do not use abrasive cleaners, waxes, or solvents.
- **Storage:** When not in use for extended periods, store the soundbar in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in active use.

7. TROUBLESHOOTING

If you encounter issues with your MD-SBT32 soundbar, refer to the following common problems and solutions:

Problem	Possible Solution
Soundbar does not power on.	Ensure the battery is charged. Connect the soundbar to a power source using the Type-C cable and try again.
No sound from the soundbar.	Check volume levels on both the soundbar and your connected device. Ensure the correct input mode (Bluetooth/AUX) is selected. For AUX, verify the cable is securely connected.
Bluetooth device cannot find the soundbar.	Ensure the soundbar is in Bluetooth pairing mode (indicator light flashing). Move your device closer to the soundbar. Turn off and on Bluetooth on your device.
Poor audio quality via Bluetooth.	Reduce the distance between the soundbar and your Bluetooth device. Avoid obstacles that may interfere with the signal.

8. SPECIFICATIONS

Detailed technical specifications for the Mikado MD-SBT32 Soundbar Speaker:

Feature	Specification
Model	MD-SBT32
Output Power	16W (8W*2)
Bluetooth Version	5.3
Material	Plastic + Iron Mesh
Speaker Dimensions	346W x 54.75D x 79.2H mm
Battery Capacity	2000mAh
Speaker Impedance	4 Ohm
Power Input	DC 5V 2A
Functions	Bluetooth, RGB Lighting, AUX Input
Input Ports	AUX, Type-C (Charging)
Charging Time	Approximately 4 Hours
Maximum Operating Time	Approximately 3 Hours
Cable Length (Charging)	1.5M
Net Weight	551g (0.551 kg)
RGB Light Modes	7
Color	Black
Mounting Type	Desktop Mount

9. WARRANTY AND SUPPORT

The Mikado MD-SBT32 Bluetooth Soundbar Speaker comes with a **24-month warranty** from the date of purchase. This warranty covers manufacturing defects under normal use.

For warranty claims, technical support, or any questions not covered in this manual, please contact your retailer or Mikado customer service. Please have your product model number (MD-SBT32) and proof of purchase ready when contacting support.