

LOFREE OE929

LOFREE Pudding Dual Mode Wireless Mouse OE929 User Manual

Model: OE929

INTRODUCTION

The LOFREE Pudding Dual Mode Wireless Mouse (Model OE929) is designed for versatile use across various operating systems and devices. It offers both Bluetooth and 2.4G wireless connectivity, adjustable DPI settings, and a comfortable, ergonomic design. This manual provides instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance of your device.

PACKAGE CONTENTS

- LOFREE Pudding Dual Mode Wireless Mouse
- USB Receiver (2.4G)
- Charging Cable (USB-C to USB-A, typically)
- User Manual

PRODUCT OVERVIEW

The LOFREE Pudding mouse features a unique transparent texture and an ergonomic design for comfortable use. It includes an adjustable ambient light feature and a scroll wheel with integrated button functionality.

High transparency texture



Image: The LOFREE Pudding mouse showcasing its high transparency texture and sleek design.

Comfortable grip
Skin-like touch feeling



Image: A hand holding the LOFREE Pudding mouse, illustrating its comfortable, skin-like touch and ergonomic grip.

SETUP

1. Charging the Mouse

Before first use, ensure the mouse is fully charged. Connect the provided charging cable to the mouse's charging port and to a USB power source. The ambient light may indicate charging status (e.g., breathing light while charging, solid when full).

Approximately 100 hours
of battery life



Image: The LOFREE Pudding mouse, highlighting its approximately 100 hours of battery life on a single charge.

2. Dual-Mode Connection

The mouse supports two wireless connection methods: 2.4G via USB receiver and Bluetooth.

Dual-mode connection



Image: The LOFREE Pudding mouse demonstrating its dual-mode connection capability, supporting both Bluetooth and 2.4G wireless technologies.

2.1. 2.4G Wireless Connection

1. Locate the USB receiver, typically stored in a compartment on the mouse or in the packaging.
2. Plug the USB receiver into an available USB port on your computer.
3. Turn on the mouse. The computer should automatically detect and install the necessary drivers.
4. *Note:* For systems below Windows 7, the 2.4G connection is recommended as Bluetooth mode may not be supported.

2.2. Bluetooth Connection

1. Ensure your device's Bluetooth is enabled.
2. Switch the mouse to Bluetooth mode (refer to the mouse's bottom switch or button for mode selection).
3. On your device, search for Bluetooth devices. The mouse should appear as "LOFREE Pudding Mouse" or similar.
4. Select the mouse to pair. Follow any on-screen prompts to complete the pairing process.

3. Compatibility

The LOFREE Pudding mouse is compatible with a wide range of operating systems and devices, including:

- Windows (Windows 7 and above for Bluetooth)
- macOS
- iOS
- Android
- PC, Mac, Laptop, and other compatible devices.

OPERATING INSTRUCTIONS

1. Adjusting DPI Levels

The mouse features 5 adjustable DPI levels to suit different tasks and preferences. You can cycle through these settings by pressing the DPI button, usually located near the scroll wheel or on the bottom of the mouse.

- Available DPI settings: 600, 800, 1200, 1600, 3600.
- Press the DPI button to switch between levels. The mouse cursor speed will change accordingly.

5 levels of DPI optional
600 | 800 | 1200 | 1600 | 3600



Image: A hand demonstrating the adjustment of DPI levels on the LOFREE Pudding mouse, with available settings of 600,

2. Ambient Light Modes

The mouse is equipped with an adjustable ambient light feature, offering two modes:

- **Constant Always On:** The light remains steadily illuminated.
- **Breathing Mode:** The light gently pulses on and off.

To switch between these modes, refer to the dedicated light control button or combination of buttons on the mouse. In dormant state, the ambient light will turn off and can be reactivated by clicking any button on the mouse.



Image: The LOFREET Pudding mouse displaying its adjustable ambient light feature, with options for "Always On" or "Breathing" modes.

3. Power Management

The mouse is designed to conserve battery life. It will enter a dormant state after a period of inactivity, turning off the ambient light. To wake the mouse, simply click any button.

MAINTENANCE

1. Cleaning

- Use a soft, dry, lint-free cloth to clean the mouse surface.
- For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner.
- Avoid using harsh chemicals, solvents, or abrasive materials, as these can damage the mouse's finish.
- Ensure no liquid enters the mouse's internal components.

2. Battery Care

- Charge the mouse regularly to maintain battery health.
- Avoid fully discharging the battery frequently.
- If storing the mouse for an extended period, charge it to approximately 50% to prevent deep discharge.

TROUBLESHOOTING

Mouse Not Responding / Disconnecting

- **Check Battery:** Ensure the mouse is charged. Connect it to a power source.
- **2.4G Connection:**
 - Ensure the USB receiver is securely plugged into a working USB port.
 - Try a different USB port.
 - Ensure the mouse is switched to 2.4G mode.
- **Bluetooth Connection:**
 - Ensure Bluetooth is enabled on your device.
 - Ensure the mouse is switched to Bluetooth mode.
 - Unpair and re-pair the mouse from your device's Bluetooth settings.
 - Ensure your device's operating system supports Bluetooth for mice (e.g., Windows versions below 7 may have limited support).
- **Interference:** Move the mouse closer to the receiver/device. Avoid using it near other wireless devices that might cause interference.

DPI Not Changing

- Ensure you are pressing the correct DPI adjustment button.
- If the mouse is unresponsive, try restarting it (turn off and on).

Ambient Light Not Working

- Check if the mouse is in a dormant state; click a button to wake it.
- Ensure the battery is sufficiently charged.
- Verify you are using the correct button or combination to cycle through light modes.

SPECIFICATIONS

Feature	Detail
---------	--------

Model Number	OE929
Connectivity Technology	Bluetooth, 2.4G Radio Frequency
Movement Detection Technology	Optical
DPI Levels	600, 800, 1200, 1600, 3600 (Adjustable)
Battery Capacity	500mAh
Battery Life	Approximately 100 hours
Special Features	LED Lights (Ambient), Lightweight, Rechargeable, Wireless
Compatibility	Windows, macOS, iOS, Android (PC, Mac, Laptop)
Item Weight	8.9 ounces
Package Dimensions	5.2 x 4.13 x 2.4 inches

WARRANTY AND SUPPORT

LOFREE products are manufactured to high-quality standards. For warranty information, technical support, or service inquiries, please refer to the official LOFREE website or contact their customer support directly.

Keep your purchase receipt for warranty claims.

For more information, visit the [LOFREE Store on Amazon](#).