

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Lumisky](#) /

› [Lumisky BRISA LED Outdoor Wall Light Warm White H26cm Instruction Manual](#)

Lumisky BRISA

Lumisky BRISA LED Outdoor Wall Light Instruction Manual

Model: BRISA

1. PRODUCT OVERVIEW

The Lumisky BRISA LED Outdoor Wall Light is designed to provide reliable and constant illumination for outdoor spaces such as entrances, patios, or driveways. Featuring a durable stainless steel structure with a corten-colored finish, it adds a modern and warm aesthetic to any facade. This fixture includes an integrated LED that emits a powerful 700 lumens of warm white light at 3000 K. It is designed for direct connection to a 220-240 V mains power supply and boasts an IP54 certification, ensuring excellent resistance to weather conditions and water splashes for long-lasting outdoor use.



Image 1.1: Lumisky BRISA LED Outdoor Wall Light, showcasing its design and warm illumination.

Key Features:

- **Mains Powered:** Provides continuous high-performance lighting independent of daylight.
- **Robust Structure:** Designed for durability against rain and temperature variations.
- **Optimal Visibility:** Stable luminous flux for effective night access illumination.
- **Sleek Style:** Modern design that harmoniously adapts to any wall surface.
- **Easy Installation:** Simplified mains installation for immediate wall lighting.

2. SAFETY INSTRUCTIONS

Please read all safety instructions carefully before installation and use. Failure to follow these instructions may result in electric shock, fire, or other hazards.

- **Electrical Safety:** Installation must be performed by a qualified electrician in accordance with local electrical codes and regulations. Always disconnect power at the main circuit breaker before installation, maintenance, or cleaning.
- **Outdoor Use:** This fixture is rated IP54 for outdoor use, providing protection against dust and splashing water. Ensure all connections are properly sealed to maintain this rating.

- **Mounting:** Mount the fixture securely to a solid surface that can support its weight. Do not install on unstable or vibrating surfaces.
- **Heat:** The LED light source may become warm during operation. Do not touch the fixture immediately after prolonged use.
- **Damage:** Do not operate the fixture if any part is damaged. Contact customer support for replacement parts or service.

3. PACKAGE CONTENTS

Verify that all components are present and undamaged before proceeding with installation.

- Lumisky BRISA LED Outdoor Wall Light Fixture (with integrated LED)
- Mounting hardware (screws, wall anchors)
- Instruction Manual

4. SETUP AND INSTALLATION

Professional installation by a qualified electrician is highly recommended for this mains-powered fixture.

Installation Steps:

1. **Prepare the Installation Area:** Choose a suitable outdoor location on a wall. Ensure the surface is clean, dry, and structurally sound.
2. **Disconnect Power:** IMPORTANT! Turn off the main power supply to the installation area at the circuit breaker. Verify that the power is off using a voltage tester.
3. **Mark Mounting Points:** Hold the fixture's mounting bracket against the wall at the desired installation height. Use a pencil to mark the positions for drilling holes.
4. **Drill Holes:** Drill pilot holes at the marked positions. Insert appropriate wall anchors if necessary (e.g., for masonry walls).
5. **Secure Mounting Bracket:** Attach the mounting bracket to the wall using the provided screws. Ensure it is firmly secured.
6. **Wire the Fixture:** Carefully connect the electrical wires from the wall to the fixture's wiring terminals. Follow standard wiring color codes: Live (Brown/Black), Neutral (Blue/White), Earth (Green/Yellow). Ensure all connections are tight and secure.
7. **Attach the Fixture:** Align the fixture with the mounting bracket and secure it in place using the provided screws or fasteners. Ensure a tight seal against the wall to maintain the IP54 rating.
8. **Restore Power:** Once the fixture is securely installed and all connections are checked, restore power at the main circuit breaker.



Image 4.1: The BRISA wall light illuminating a patio area, demonstrating typical installation.



Image 4.2: The BRISA wall light providing warm illumination on a darker exterior wall.

5. OPERATING INSTRUCTIONS

The Lumisky BRISA LED Outdoor Wall Light operates simply by connecting to your mains power supply. Once installed and power is restored, the light can be controlled via your existing wall switch or an external timer/sensor connected to the circuit.

- **Power On/Off:** Use the wall switch connected to the fixture's circuit to turn the light on or off.
- **Continuous Illumination:** The integrated LED provides consistent warm white light when powered.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your Lumisky BRISA LED Outdoor Wall Light.

- **Cleaning:** Disconnect power before cleaning. Wipe the fixture with a soft, damp cloth. Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish or electrical components.
- **Integrated LED:** This fixture uses an integrated LED light source, which is designed for long life and is

not user-replaceable. Do not attempt to open or replace the LED module.

- **Inspection:** Periodically inspect the fixture for any signs of damage, loose connections, or wear. Ensure the seal against the wall remains intact to maintain its weather resistance.

7. TROUBLESHOOTING

If you encounter issues with your Lumisky BRISA LED Outdoor Wall Light, refer to the following common problems and solutions:

- **Light Does Not Turn On:**

- Check if the power supply to the fixture is active at the circuit breaker.
- Ensure the wall switch is in the 'ON' position.
- Verify all electrical connections are secure (consult a qualified electrician if unsure).

- **Light is Dim or Flickering:**

- Ensure the fixture is receiving the correct voltage (220-240 V).
- Check for loose wiring connections.
- If the issue persists, the integrated LED module may be faulty, requiring professional inspection or replacement of the entire fixture.

- **Water Inside Fixture:**

- Immediately disconnect power.
- Inspect the installation for proper sealing against the wall and ensure all components are correctly assembled to maintain the IP54 rating.
- If water ingress occurs, the fixture may be damaged and should be replaced.

For issues not covered here, please contact Lumisky customer support or a qualified electrician.

8. SPECIFICATIONS

Attribute	Detail
Brand	Lumisky
Model Number	BRISA
Product Dimensions	19.2 x 11 x 26 cm
Product Weight	1.1 kg
Material	Stainless Steel (Corten finish)
Color	Brown (Corten)
Fixture Type	Wall-mounted
Light Source	Integrated LED
Luminous Flux	700 lumens

Color Temperature	3000 K (Warm White)
Voltage	220-240 V
IP Rating	IP54 (Dust protected, splash-proof)
Batteries Required	No
Specific Product Uses	Balcony, Home, Street lighting, Patio, Driveway
ASIN	B0GK9RPR6K

9. WARRANTY AND SUPPORT

Specific warranty information for the Lumisky BRISA LED Outdoor Wall Light is not provided in the product data. For details regarding warranty coverage, terms, and conditions, please refer to the documentation included with your purchase or contact the seller/manufacturer directly.

For technical support, troubleshooting assistance beyond this manual, or inquiries about replacement parts, please contact Lumisky customer service through their official website or the retailer from whom you purchased the product.