

Gamrombo PlayStation 5

Gamrombo LED Wireless Controller for PS5/PC - Instruction Manual

Model: PlayStation 5

INTRODUCTION

This manual provides detailed instructions for setting up, operating, and maintaining your Gamrombo LED Wireless Controller. This controller is designed for use with PlayStation 5 series consoles (PS5, PS5 Pro, PS5 Slim) and Windows PCs. It features dual vibration, macro/turbo functions, a 3.5mm audio jack, and 6-axis motion control for an enhanced gaming experience.

PACKAGE CONTENTS

- Gamrombo LED Wireless Controller
- USB-C Charging/Data Cable
- Instruction Manual (this document)

SETUP AND CONNECTION

Initial Connection to PS5 Console

1. Ensure your PS5 console is powered on.
2. Connect the controller to the PS5 console using the included USB-C data cable. **Important:** Use the data cable included in the package or an original data cable for proper functionality.
3. Press the **Home button** on the controller to activate it. The controller will pair with the console.
4. Once paired, the controller can be used wirelessly.

Your browser does not support the video tag.

Video: This video demonstrates the process of connecting the Gamrombo controller to a PS5 console and performing joystick and trigger calibration.

Connecting to Windows PC

- Connect the controller to your Windows PC using the USB-C data cable.

- The PC should automatically detect and install the necessary drivers.
- The controller is now ready for use with compatible PC games.

Note: This controller is not compatible with PS4 consoles.

OPERATING INSTRUCTIONS

Customizable LED Lighting

The controller features customizable LED lighting around the joysticks and face buttons. You can change the colors and lighting effects to match your preference.

- Press the **LIGHT button** (located between the joysticks) to cycle through different color modes and effects.
- The controller has a color memory function, retaining your last selected lighting setting.



Image: The Gamrombo controller showcasing its customizable LED lighting around the joysticks and buttons.



Image: A diagram illustrating the four different LED lighting modes: Single Color Cycle, Dazzling Color Change, Single Color Mode, and Light Off Mode.

Macro and Turbo Functions

The controller includes programmable back keys (PR/PL) for macro functions and a Turbo button for rapid fire.

Macro Programming (PR/PL Buttons)

- The two back keys (PR and PL) can be programmed to record up to 16 key values.
- **Note:** Specific programming steps are typically detailed in a separate quick start guide or on the manufacturer's website. Refer to those resources for detailed macro setup.



Image: A visual guide to the PR/PL programmable back keys, indicating their location and the types of button inputs that can be mapped.

Turbo Function

- Press the **TURBO button** (located between the joysticks) to activate rapid fire for assigned buttons.
- When activated, a single press of a designated button will register multiple inputs, useful for certain game mechanics.



Image: An illustration highlighting the Turbo button and its effect on button inputs for faster rapid fire.

Audio Features

The controller includes a built-in speaker and a 3.5mm TRRS headphone jack.

- **Built-in Speaker:** Provides in-game audio feedback for an immersive experience. **Note:** The controller's speaker does not include a microphone.
- **3.5mm TRRS Headphone Jack:** Connect an external headset for audio and microphone functionality. **Compatibility:** Not compatible with Apple headphones.



Image: The controller connected to a PS5, showing the location of the built-in speaker and the 3.5mm audio jack for headset connection.

Advanced Control Features

- **High-Precision Joysticks:** Equipped with upgraded joysticks designed to reduce dead zones and extend service life.
- **Dual Vibration Function:** Provides tactile feedback during gameplay, enhancing immersion.
- **6-Axis Gyroscope:** Offers precise motion control for compatible games.
- **Hall Effect Analog Triggers:** Designed for precise control with an accuracy of up to 0.1mm.



Image: A detailed view of the controller's joystick, highlighting its "Zero Deadzone Stick" technology for improved precision and durability.



Image: An X-ray view illustrating the Hall Effect Analog Triggers, emphasizing their precise control with 0.1mm accuracy.

BATTERY AND CHARGING

The controller is equipped with a 1000 mAh battery.

- **Runtime:** Approximately 10-15 hours on a full charge.
- **Charging Time:** Approximately 3-4 hours for a full charge.
- **Charging Method:** Connect the controller to a USB power source (e.g., PS5 console, PC, USB wall adapter) using the provided USB-C cable.



Image: An internal view of the controller highlighting the 1000 mAh battery and its charging specifications.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the controller. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the controller in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the controller frequently. Charge it regularly, even if not in constant use.
- **Cable Care:** Handle the USB-C cable gently. Avoid bending or twisting it excessively to prevent damage.

TROUBLESHOOTING

Controller Not Connecting/Responding

- **Check Cable:** Ensure the USB-C cable is securely connected to both the controller and the console/PC.
- **First-time Connection:** For PS5, ensure you are using the provided data cable or an original PS5 data cable for the initial wired connection and activation via the Home button.
- **Re-pair:** If the controller loses connection, try re-pairing it by connecting it via USB-C and pressing the Home button.
- **Restart Devices:** Restart your PS5 console or PC and try connecting the controller again.
- **Charge Battery:** Ensure the controller has sufficient battery charge. Connect it to a power source and allow it to charge for a few minutes before attempting to connect.

Joystick Drift or Inaccurate Input

- **Calibration:** Perform joystick and trigger calibration if available. Refer to the manufacturer's support resources for specific calibration instructions.
- **Restart:** Sometimes restarting the controller and console/PC can resolve minor input issues.

Your browser does not support the video tag.

Video: This video demonstrates the process of connecting the Gamrombo controller to a PS5 console and performing joystick and trigger calibration.

Audio Issues (Speaker/Headphone Jack)

- **No Sound from Speaker:** Ensure in-game audio settings are configured to output sound through the controller.
- **No Sound from Headset:** Check that the headset is fully plugged into the 3.5mm jack. Verify headset functionality with another device. Ensure the headset is not an Apple-branded product, as they are not compatible.
- **Microphone Not Working:** The built-in speaker does not have a microphone. An external headset with a microphone must be used for voice chat. Ensure your headset's microphone is enabled in console/PC

settings.

SPECIFICATIONS

| Feature | Detail |
|-------------------------|---|
| Brand | Gamrombo |
| Model Name | PlayStation 5 |
| Compatible Devices | PlayStation 5, PlayStation 5 Pro, Windows PC |
| Controller Type | Wireless |
| Connectivity Technology | Wireless |
| Additional Features | Ergonomic, Motion Sensor (6-Axis Gyroscope), Dual Vibration, Customizable LED, Macro/Turbo Function |
| Button Quantity | 21 |
| Power Source | Wireless (Rechargeable Battery) |
| Battery Capacity | 1000 mAh |
| Audio Jack | 3.5mm TRRS (not compatible with Apple headphones) |

WARRANTY

This Gamrombo controller comes with a **3-month warranty** from the date of purchase. Please retain your proof of purchase for warranty claims. The warranty covers manufacturing defects and malfunctions under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

SUPPORT

For further assistance, technical support, or warranty inquiries, please contact Gamrombo customer service through the retailer where the product was purchased or visit the official Gamrombo website for contact information.

Manufacturer: Gamrombo