



Astro Tool 52SL-WCP Light USB-C Dual wireless User Manual

[Home](#) » [Astro Tool](#) » Astro Tool 52SL-WCP Light USB-C Dual wireless User Manual 



Contents

- [1 Product Description](#)
- [2 Specifications](#)
- [3 Operation](#)
- [4 Maintenance](#)
- [5 Warning](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)

Product Description

- Double wireless charging pad fitted with two strong magnets for attaching to a metal surface.
- Four holes at each corner for the permanent fixture to non-metallic surface or wall
- Supplied with USB-C charging cable and 5V 2A charging adaptor
- With 5V 1A USB output

Specifications

Input voltage:	5V 2A
Output (Wireless):	5V 1A
Output (USB):	5V 1A

Operation

- If required, either place the charging pad on a metallic surface using the magnets (on the underside) to hold it

in position or permanently fix it to a non-metallic surface or wall using the four 5mm diameter counter bored holes in each corner.

- Connect the charging base to a wall socket using the cable and plug supplied. Turn on the power source and the LED on the top surface of the pad will light green indicating that the USB charging output is able to be used.
- Place the front face of light onto the front face of the charging pad ensuring alignment of charging pads and magnets.
- The LED on the top surface of the pad will light red indicating that the USB charging output socket is not able to be used.
- Once the light indicates fully charged, remove it from the charging pad and disconnect the pad power supply.

Maintenance

- Keep the charging pad clean by wiping it with a slightly damp cloth.
- Store the charging pad in a dry childproof area.

Warning

- To reduce the risk of electric shock, burns or fire
- Do not attempt to open, disassemble, modify or service the charging pad
- Do not crush, puncture, or dispose of in fire or water

FCC Warning

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This equipment should be installed and operated with a minimum distance of 20cm between the radiator& your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Documents / Resources

