


**ASUS**  
MH2741A  
Computer Monitor



# ASUS MH2741A Computer Monitor User Guide


[Home](#) » [Asus](#) » ASUS MH2741A Computer Monitor User Guide 

## Contents

- 1 ASUS MH2741A Computer Monitor
- 2 FCC STATEMENT
- 3 Safety information
- 4 Care & Cleaning
- 5 Package contents
- 6 Assembling the monitor arm/base
- 7 OSD (On-Screen Display) menu
- 8 Troubleshooting (FAQ)
- 9 Documents / Resources
  - 9.1 References
- 10 Related Posts



**ASUS MH2741A Computer Monitor**



Copyright © 2023 ASUSTeK COMPUTER INC. All Rights Reserved. No part of this manual, including the products and software described in it, may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form or by any means, except documentation kept by the purchaser for backup purposes, without the express written permission of ASUSTeK COMPUTER INC. ("ASUS"). Product warranty or service will not be extended if: (1) the product is repaired, modified or altered, unless such repair, modification or alteration is authorized in writing by ASUS; or (2) the serial number of the product is defaced or missing. ASUS PROVIDES THIS MANUAL "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT SHALL ASUS, ITS DIRECTORS, OFFICERS, EMPLOYEES OR AGENTS BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES (INCLUDING DAMAGES FOR LOSS OF PROFITS, LOSS OF BUSINESS, LOSS OF USE OR DATA, INTERRUPTION OF BUSINESS AND THE LIKE), EVEN IF ASUS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES ARISING FROM ANY DEFECT OR ERROR IN THIS MANUAL OR PRODUCT. SPECIFICATIONS AND INFORMATION CONTAINED IN THIS MANUAL ARE FURNISHED FOR INFORMATIONAL USE ONLY, AND ARE SUBJECT TO CHANGE AT ANY TIME WITHOUT NOTICE, AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY ASUS. ASUS ASSUMES NO RESPONSIBILITY OR LIABILITY FOR ANY ERRORS OR INACCURACIES THAT MAY APPEAR IN THIS MANUAL, INCLUDING THE PRODUCTS AND SOFTWARE DESCRIBED IN IT. Products and corporate names appearing in this manual may or may not be registered trademarks or copyrights of their respective companies, and are used only for identification or explanation and to the owners' benefit, without intent to infringe

## Notices

### Federal Communications Commission Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received including interference that may cause undesired operation.

## FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, under Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used by the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The use of shielded cables for connection of the monitor to the graphics card is required to assure compliance with FCC regulations. Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

### **ENERGY STAR® complied product**

ENERGY STAR® is a joint program of the U.S. Environmental Protection Agency and the U.S. Department of Energy helping us all save money and protect the environment through energy-efficient products and practices. All ASUS products with the ENERGY STAR® logo comply with the ENERGY STAR® standard, and the power management feature is enabled by default. The monitor and computer are automatically set to sleep after 10 and 30 minutes of user inactivity. To wake your computer, click the mouse or press any key on the keyboard. Please visit <http://www.energystar.gov/powermanagement> for detailed information on power management and its benefits to the environment. In addition, please visit <http://www.energystar.gov> for detail information on the ENERGY STAR® joint program.

### **Canadian Department of Communications Statement**


This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of the Canadian Department of Communications. This class B digital apparatus complies with Canadian ICES-003. This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

### **Flicker-Free technology**

The Monitor adopts Flicker-Free technology, which clears the eye's visible flicker, brings comfort viewing experience, and prevents users suffer from eye strain and fatigue.

### **TCO certified**

- A third-party certification according to ISO 14024



### **Say hello to a more sustainable product**

IT products are associated with a wide range of sustainability risks throughout their life cycle. Human rights

violations are common in the factories. Harmful substances are used both in products and their manufacture. Products can often have a short lifespan because of poor ergonomics, low quality, and when they are not able to be repaired or upgraded. This product is a better choice. It meets all the criteria of TCO Certified, the world's most comprehensive sustainability certification for IT products. Thank you for making a responsible product choice, that helps drive progress towards a more sustainable future! Criteria in TCO Certified have a life-cycle perspective and balance environmental and social responsibility. Conformity is verified by independent and approved verifiers that specialize in IT products, social responsibility, or other sustainability issues. Verification is done both before and after the certificate is issued, covering the entire validity period. The process also includes ensuring that corrective actions are implemented in all cases of factory non-conformities. Last but not least, to make sure that the certification and independent verification are accurate, both TCO Certified and the verifiers are reviewed regularly.

### **Want to know more?**

Read information about TCO Certified, full criteria documents, news, and updates at [tcocertified.com](https://tcocertified.com). On the website, you'll also find our Product Finder, which presents a complete, searchable listing of certified products.

### **Safety information**

- Before setting up the monitor, carefully read all the documentation that came with the package.
- To prevent fire or shock hazards, never expose the monitor to rain or moisture.
- Never try to open the monitor cabinet. The dangerous high voltages inside the monitor may result in serious physical injury.
- If the power supply is broken, do not try to fix it by yourself. Contact a qualified service technician or your retailer.
- Before using the product, make sure all cables are correctly connected and the power cables are not damaged. If you detect any damage, contact your dealer immediately.
- Slots and openings on the back or top of the cabinet are provided for ventilation. Do not block these slots. Never place this product near or over a radiator or heat source unless proper ventilation is provided.
- The monitor should be operated only from the type of power source indicated on the label. If you are not sure of the type of power supply to your home, consult your dealer or local power company.
- Use the appropriate power plug which complies with your local power standard.
- Do not overload power strips and extension cords. Overloading can result in fire or electric shock.
- Avoid dust, humidity, and temperature extremes. Do not place the monitor in any area where it may become wet. Place the monitor on a stable surface.
- Unplug the unit during a lightning storm or if it will not be used for a long period. This will protect the monitor from damage due to power surges.
- Never push objects or spill liquid of any kind into the slots on the monitor cabinet.
- To ensure satisfactory operation, use the monitor only with UL-listed computers that have appropriate configured receptacles marked between 100- 240V AC. Use a power cord connected to a socket outlet with an earthing connection.
- If you encounter technical problems with the monitor, contact a qualified service technician or your retailer.
- Adjustment of the volume control as well as the equalizer to other settings than the center position may increase the ear-/headphone output voltage and therefore the sound pressure level.

This symbol of the crossed out wheeled bin indicates that the product (electrical, electronic equipment, and mercury-containing button cell battery) should not be placed in municipal waste. Please check local regulations for disposal of electronic products.

### **Care & Cleaning**

- Before you lift or reposition your monitor, it is better to disconnect the cables and power cord. Follow the correct lifting techniques when positioning the monitor. When lifting or carrying the monitor, grasp the edges of the monitor. Do not lift the display by the stand or the cord.
- Cleaning. Turn your monitor off and unplug the power cord. Clean the monitor surface with a lint-free, non-abrasive cloth. Stubborn stains may be removed with a cloth dampened with mild cleaner.
- Avoid using a cleaner containing alcohol or acetone. Use a cleaner intended for use with the monitor. Never spray cleaner directly on the screen, as it may drip inside the monitor and cause an electric shock.

#### **The following symptoms are normal with the monitor:**

- You may find slightly uneven brightness on the screen depending on the desktop pattern you use.
- When the same image is displayed for hours, an afterimage of the previous screen may remain after switching the image. The screen will recover slowly or you can turn off the Power Switch for hours.
- When the screen becomes black or flashes, or cannot work anymore, contact your dealer or service center to fix it. Do not repair the screen by yourself!

#### **Conventions used in this guide**

- **WARNING:** Information to prevent injury to yourself when trying to complete a task.
- **CAUTION:** Information to prevent damage to the components when trying to complete a task.
- **IMPORTANT:** Information that you **MUST** follow to complete a task.
- **NOTE:** Tips and additional information to aid in completing a task.

#### **Where to find more information**

Refer to the following sources for additional information and for product and software updates.

#### **ASUS websites**

The ASUS websites worldwide provide updated information on ASUS hardware and software products. Refer to <http://www.asus.com>

#### **Optional documentation**

Your product package may include optional documentation that may have been added by your dealer. These documents are not part of the standard package.

#### **Takeback Services**

ASUS recycling and takeback programs come from our commitment to the highest standards for protecting our environment. We believe in providing solutions for our customers to be able to responsibly recycle our products, batteries and other components as well as the packaging materials. Please go to <http://csr.asus.com/english/Takeback.htm> for detailed recycling information in different regions.

#### **Product information for EU energy label**



PA278CFRV  
TBD

### **Welcome!**

Thank you for purchasing the ASUS® LCD Monitor! The latest widescreen LCD monitor from ASUS provides a broader, brighter and crystal-clear display, plus a host of features that enhance your viewing experience. With these features, you can enjoy the convenience and delightful visual experience that the monitor brings to you!


### **Package contents**

Check your package for the following items:

- LCD monitor
- Monitor base
- Quick start guide
- Warranty card
- Power cord
- HDMI cable (optional)
- DisplayPort cable (optional)
- USB C to C cable (optional)
- Color calibration testing report
- ProArt welcome card
  - If any of the above items is damaged or missing, contact your retailer immediately.
  - If you need to replace the power cord or the connection cable(s), please contact ASUS customer service.

### **Monitor introduction**

#### **Front view**



#### 1. Light Sensor:

- Detects ambient light source & color temperature, and automatically adjusts screen brightness.

#### 2. Power button/power indicator

- Turns the monitor on/off. Press and hold this button for 0.6 seconds will shut down the monitor.
- The color definition of the power indicator is as the below table.

Status	Description
White	On
Amber	Standby mode
Off	Off

#### 3. QuickFit Plus button:

- Press this button to display the OSD menu when the OSD is off.
- Selects the QuickFit Plus function.

#### 4. Signal button:

- Press this button to display the OSD menu when the OSD is off.
- Press this button to switch to next active input source (if available).

#### 5. Shortcut 2

- Press this button to display the OSD menu when the OSD is off.
- Default: Brightness hotkey
- To change the hotkey function, go to the Shortcut > Shortcut 2 menu. Shortcut 1
- Press this button to display the OSD menu when the OSD is off.
- Default: Energy Saving hotkey
- To change the hotkey function, go to the Shortcut > Shortcut 1 menu.


#### 6. Exit button:

- Press this button to display the OSD menu when the OSD is off.

## 7. Menu (5-way) button

- Press this button to display the OSD menu when the OSD is off. Press this button again to enter the OSD main menu.
- Enacts the selected OSD menu items.
- Increases/Decreases values or moves your selection up/down/left/right.
- Push the 5-way button down for over 5 seconds to toggle the Key Lock function between on and off.

## Back view



1. Kensington lock slot.
2. Power switch: Press the switch to turn on/off power.
3. AC-IN port: This port connects the power cord.
4. Earphone jack: This port is only available when an HDMI/DisplayPort/USB Type-C cable is connected.
5. HDMI port: This port is for connection with an HDMI-compatible device.
6. DisplayPort in: This port is for connection with a DisplayPort-compatible device.
7. Daisy-Chain DisplayPort output: This port allows you to connect multiple DisplayPort-compatible monitors.
8. USB 3.2 Gen 1 Type-C: This port is for connection with a USB upstream cable. The connection supports USB power, data delivery, and DP ALT mode support. This monitor is Super-Speed USB 3.2 Gen 1 compatible (5Gbps). The port offers 96W power delivery with an output maximum voltage of 20V/4.8A.
9. USB 3.2 Gen 1 Type-A: These ports are for connection with USB devices, such as USB keyboard/mouse, USB flash drive, etc.
10. USB 3.2 Gen 1 Type-C: This port is for connection with USB devices, such as USB keyboard/mouse, USB flash drive, etc.
11. USB 3.2 Gen 1 Type-A: These ports are for connection with USB devices, such as USB keyboard/mouse, USB flash drive, etc.




12. USB 3.2 Gen 1 Type-A: These ports are for connection with USB devices, such as USB keyboard/mouse, USB flash drive, etc.

### Other Function(s)

Daisy chaining (for selected models) The monitor supports a daisy chain on DisplayPort and USB Type-C. Daisy Chaining allows up to 1 monitor to be connected in series with the video signal being passed from the source to a monitor (when the input source is 2560 x 1440@100Hz and no USB-C device is connected). To enable daisy chaining, please make sure the source is transported. This function is only available when Power Saving is Normal Level. If you set Power Saving to Deep Level, all the connected monitors will display the same content at the same time (clone).

**Note:** The input port will be fixed (no auto-detection) when the DP out cable is plugged.

2560 x 1440 @100Hz




### Assembling the monitor arm/base

To assemble the monitor base:

1. Make sure the triangle marks of the VESA cover are aligned.
2. Attach the arm to the VESA cover.
3. Shut the lock to make the arm and VESA cover assembled.
4. Have the front of the monitor face down on a table, and slide the tabs on the arm into the slots on the VESA cover.
5. Press down the arm assembly to snap it into place.
6. Attach the base to the arm, making sure the tab on the arm fits into the groove on the base.
7. Fix the base to the arm by fastening the bundled screw.


We recommend that you cover the table surface with a soft cloth to prevent damage to the monitor.



#### Detaching the arm/base (for VESA wall mount)

The detachable arm/base of this monitor is specially designed for VESA wall mount. To detach the arm/base:

1. Have the front of the monitor face down on a table.
2. Press the release button, and then detach the arm/base from the monitor (Figure 1).



We recommend that you cover the table surface with a soft cloth to prevent damage to the monitor.

- The VESA wall mount kit (100 x 100 mm) is purchased separately.
- The VESA mount should be installed by a skilled person. For horizontal placement or vertical use, please refer to the next page.
- Use only with UL/CSA/GS Listed Wall Mount Bracket with minimum weight/load bearing capacity of 5.85 kg


(12.9 |b) (Screw size: M4 x 10 mm).

## Adjusting the monitor

- For optimal viewing, we recommend that you look at the full face of the monitor, then adjust the monitor to the angle that is most comfortable for you.
- Hold the stand to prevent the monitor from falling when you change its angle.
- You can adjust the monitor's angle from  $+23^{\circ}$  to  $-5^{\circ}$ ,  $\pm 30^{\circ}$  swivel adjustment from either left or right, and it allows  $\pm 90^{\circ}$  pivot adjustment. You can also adjust the monitor's height within  $\pm 130$  mm.




(Tilt)



(Swivel)



(Height adjustment)




(Pivot)

- It is normal that the monitor slightly shakes while you adjust the viewing angle.

## Connecting the cables

Connect the cables as per the following instructions:





- To connect the power cord: Connect one end of the power cord securely to the AC input port, and the other end to a power outlet.
- To connect the HDMI/DisplayPort/USB Type-C\* cable:
  - Plug one end of the HDMI/DisplayPort/USB Type-C\* cable into the monitor's HDMI/DisplayPort/USB Type-C jack.
  - Connect the other end of the HDMI/DisplayPort/USB Type-C\* cable to your device's HDMI/DisplayPort/USB Type-C jack.
  - It is suggested to use USB certified Type-C cable. If the signal source supports DP Alt mode, all video, audio, and data signals can be transmitted.
  - To use the earphone: connect the end with plug type to the monitor's earphone jack when an HDMI/DisplayPort/USB Type-C signal is fed.

#### To use the USB 3.2 Gen 1 ports:


- **Upstream:** Use a USB Type-C cable and plug on the end of the Type-C connector to the monitor's USB Type-C port upstream and the other end to your computer's USB Type-C jack. Or use a USB Type-C to Type-A cable and plug the Type-C connector to the monitor's USB Type-C upstream and the Type-A connector into your computer's USB Type-A jack. Make sure your computer is installed with the Windows or macOS operating system. That will enable the USB ports on the monitor to work.
- **Downstream:** Do not use an extension cord. Please directly connect your USB device with the monitor's USB Type-A or Type-C jack.
  - When these cables are connected, you can choose the desired signal from the Signal item in the OSD menu.
  - If you need to replace the power cord or the connection cable(s), please contact ASUS customer service.









#### Turning on the monitor

Press the power button . See page 1-2 for the location of the power button. The power indicator  lights up in white to show that the monitor is ON.

## OSD (On-Screen Display) menu


### How to reconfigure




1. Press any button to display the OSD menu.
2. Press the  Menu (5-way) button to enter the OSD main menu.
3. Move the  Menu (5-way) button up/down/left/right to navigate through the functions. Highlight the desired function and press the Menu (5-way) button to activate it. If the function selected has a sub-menu, move the  Menu (5-way) button up/down to navigate through the sub-menu functions. Highlight the desired sub-menu function and press the  Menu (5-way) button or move the  Menu (5-way) button to activate it.
4. Move the  Menu (5-way) button up/down to change the settings of the selected function.
5. To exit and save the OSD menu, press the  button or move the  Menu (5-way) left repeatedly until the OSD menu disappears. To adjust other functions, repeat steps 1-4.





## OSD (On-Screen Display) menu

### How to reconfigure





1. Press any button to display the OSD menu.

2. Press the  Menu (5-way) button to enter the OSD main menu.

3. Move the  Menu (5-way) button up/down/left/right to navigate through the functions. Highlight the desired function and press the  Menu (5-way) button to activate it. If the function selected has a sub-menu, move the  Menu (5-way) button up/down to navigate through the sub-menu functions. Highlight the desired sub-menu function and press the  Menu (5-way) button or move the Menu (5-way) button to activate it.


4. Move the Menu (5-way) button up/down to change the settings of the selected function.

5. To exit and save the OSD menu, press the  button or move the  Menu (5-way) left repeatedly until the OSD menu disappears. To adjust other functions, repeat steps 1-4.

## OSD function introduction

### Preset

This function contains 10 sub-functions you can select for your preference. Each mode has the Reset selection, allowing you to maintain your setting or return to the preset mode.



- **Native Mode:** Best choice for document editing.
- **sRGB Mode:** Compatible with sRGB color space, sRGB mode is the best choice for document editing.

sRGB Mode default settings meet ENERGY STAR® requirements.(Return to ENERGY STAR® default settings, must execute ALL Reset in the setting menu)Native Mode with Dynamic Dimming turned off is used for TCO-certified compliance.

- Adobe RGB Mode: Compatible with Adobe RGB color space.
- Rec.2020 Mode: Compatible with Rec.2020 color space.
- DCI-P3 Mode: Compatible with DCI-P3 color space.
- DICOM Mode: Compatible with DICOM standard, best choice for medical image checking.
- Rec. 709 Mode: Compatible with Rec. 709 color space.
- HDR: High Dynamic Range. Contains three HDR modes (PQ Optimized, PQ Clip, and PQ Basic).

To activate this function, you need to do the following: turn off PIP/PBP. For better HDR performance (to meet DisplayHDR standard), you need to do the following: set Dynamic Dimming to Fast and HDR mode to PQ Clip.

- User Mode 1/User Mode 2: Allows you to make color adjustments in the Advanced Setting.


Below table shows the default configurations for each ProArt Pr set mode:

Function	Native Mode	sRGB Mode	Adobe RGB Mode	Rec. 2020 Mode	DCI-P3 Mode	DICOM	Rec. 709 Mode	Mode HDR	User Mode 1/ User Mode 2
Color Temp.	6500K	Fixed (6500K)	Fixed (6500K)	6500K	P3-Theater	6500K	6500K	Fixed (6500K)	6500K
Brightness	50	Fixed 80 nits	160 nits	100 nits	48 nits	50	100 nits	250 nits/Max	50
Contrast	80	80	80	80	80	80	80	Fixed	80
Sharpness	Enable (0)	Enable (0)	Enable (0)	Enable (0)	Enable (0)	Enable (0)	Enable (0)	Enable (0)	Enable (0)
Saturation	Middle (50)	Fixed	Middle (50)	Middle (50)	Middle (50)	Middle (50)	Middle (50)	Fixed	Middle (50)
Hue	Middle (50)	Fixed	Middle (50)	Middle (50)	Middle (50)	Middle (50)	Middle (50)	Fixed	Middle (50)
ProArt Palette/ Color	Enable (Default)	Fixed	Enable (Default)	Enable (Default)	Enable (Default)	Enable (Default)	Enable (Default)	Enable (RGB Gain only)	Enable (RGB Gain only)
Black Level	Enable (Default)	Enable (Default)	Enable (Default)	Enable (Default)	Enable (Default)	Enable (Default)	Enable (Default)	Enable (Default)	Enable (Default)
Gamma	Enable (2.2)	Fixed (2.2)	Fixed (2.2)	Enable (2.4)	Enable (2.2, 2.6 only)	Fixed (DICOM)	Enable (2.4)	Fixed	Fixed (2.2)
Input Range	Enable (Auto)	Enable (Auto)	Enable (Auto)	Enable (Auto)	Enable (Auto)	Enable (Auto)	Enable (Auto)	Enable (Auto)	Enable (Auto)

### Palette

Set a desired color setting from this menu.






- Brightness: The adjusting range is from 0 to 100.
- Contrast: The adjusting range is from 0 to 100.
- Saturation: The adjusting range is from 0 to 100.
- Hue: Shifts the image color between green and purple.
- Color Temp.: Contains 5 modes including 9300K, 6500K, 5500K, 5000K and P3-Theater. P3-Theater is only available for DCI-P3 Mode.
- Gamma: Allows you to set the color mode to 2.6, 2.4, 2.2, 2.0 or 1.8 (Mac).
- RGB Tuning:
  - Gain: The adjusting range is from 0 to 100.
  - Offset: The adjusting range is from 0 to 100.
- Black Level: To adjust the initialized 1st signal level of darkest gray level.
  - Signal: The adjusting range is from 0 to 100.
  - Backlight: To adjust darkness of the backlight.
- Color Reset:
  - Current mode color reset: Resets the color settings of the current color mode to the factory default value.
  - All modes color reset: Resets the color settings of all color modes to the factory default value.

## Image

Set the image-related setting from this menu.




- Sharpness: The adjusting range is from 0 to 100.
- Trace Free: Adjusts the response time of the monitor. To activate this function, you need to do the following: turn off PIP/PBP, turn off MediaSync and disable HDR on your device.
- Aspect Control: Adjusts the aspect ratio to Full, Dot to Dot or 1:1 Ratio. To activate this function, you need to do the following: turn off MediaSync and PBP.
- Input Range: To map signal range with whole black to white presented range of display.
- Blue Light Filter: Adjust the strength of the blue light filter. In this function, you can adjust the blue light filter from 0 to Max.
- 0: No change.
- Max: The higher the level, the less blue light is scattered. When the blue light filter is activated, the default settings of Native Mode will be automatically imported. Besides the maximum level, the brightness is user-configurable. Maximum is the optimized setting. It complies with TÜV low blue light certification\*. The brightness function is not user-configurable.
- To activate this function, you need to do the following: disable HDR on your device and turn off Ambient effect.
- When color augmentation is in default value (50).
- Please refer to the following to alleviate eye strains:
- Users should take some time away from the display if working for long hours. It is advised to take short breaks (at least 5 mins) after around 1 hour of continuous working at the computer. Taking short and frequent breaks is more effective than a single longer break.
- To minimize eye strain and dryness in your eyes, users should rest the eye periodically by focusing on objects that are far away.
- Eye exercises can help to reduce eye strain. Repeat these exercises often. If eye strain continues please consult a physician. Eye exercises: (1) Repeating look up and down (2) Slowly roll your eyes (3) Move your eyes diagonal.

PIP/PBP

The PIP/PBP menu allows you to open up another sub-window connected from another video source (when input source is below 60Hz) besides the main-window from your original video source.


- To activate this function, you need to do the following: turn off MediaSync/Dynamic Dimming and disable HDR on your device.




- **Mode:** Selects PIP, PBP function, or turn it off.
- **Source:** Select the video input source from among HDMI, DisplayPort and USB Type-C. The table below shows the input source combinations.
- **Color setting:** Select color Preset for Main and Sub windows.
- **PIP Size:** Adjust the PIP size to Small, Medium or Large (Only available for the PIP mode).

QuickFit Plus

In this function, you can use different kinds of alignment patterns. To activate this function, you need to do the following: turn off PIP/PBP, disable HDR on your device and restore your screen back to normal position (do not rotate).



- Safe Area: Facilitates designers and users to organize content and layout on one page and achieve a consistent look and feel. The selections are: 1:1, Action Safe, Title Safe, 3 x 3.
- Center Marker: Adjusts the Type 1, Type 2, Type 3.
- Mirror Mode: Flip the image horizontally.
- Customization: You can decide the frame size by moving the  Menu (5-way) button up/down/left/right.
- Ruler: This pattern presents physical ruler on top and left side.

## Signal

In this function, you can select your desired input source.



**Auto Detection:** automatically detects other active signals when current input signal is inactive.  
To activate this function, you need to do the following: remove the connection of Daisy-Chain DisplayPort output (to disable MST output).

### Settings

Allows you to adjust the system.



**MediaSync:** Turn on VESA MediaSync support.

- MediaSync can only be activated within 48Hz ~100Hz.
- For supported GPUs, minimum PC system, and driver requirements, please contact the GPU manufacturers.

To activate this function, you need to do the following: turn off PIP/PBP.

- **Dynamic Dimming:** Synchronizes with contents while contrast changing to execute backlight dynamic dimming. You can adjust the synchronization speed to “Fast”, “Medium”, “Gradual” or “Off”. To activate this function, you need to do the following: turn off PIP/PBP. Dynamic Dimming is related to ECO Mode.
- **Power Saving:** Select Normal Level for power on the hub during power saving. Select Deep Level for power off hub during power saving. To activate daisy chaining, you need to do the following: set Power Saving to Normal Level. Note: The input port will be fixed (no auto-detection when the DP out cable is plugged).

## OSD Setup:

- Adjust the OSD Timeout from 10 to 120 seconds.
- Enables or disables the DDC/CI function.
- Adjust the OSD background from Opaque to Transparent.
- Enables or disables the OSD Auto Rotation function.

To activate OSD Auto Rotation, you need to do the following: turn off PIP/PBP.

## Sound


- Adjusts Volume from 0 to 100.
- Mute or un-mute the audio output.
- Select audio input from PIP/PBP Sources.
- DisplayPort Stream: Compatibility with graphic card. Select DisplayPort 1.2, DisplayPort 1.4, or DisplayPort 1.4 + USB 3.2 by graphic card DP version.
  - To activate daisy chaining, you need to do the following: set Power Saving to Normal Level. Note: The input port will be fixed (no auto-detection when the DP out cable is plugged).
- Key Lock: To disable all function keys. Push the 5-way button down for over 5 seconds to cancel the key lock function.
- Power Indicator: Turns the power LED indicator on/off.

### Ambient Effect:

- Actively detect the brightness of the environment to adjust the brightness of the screen.
- Turn on the automatic color temperature and adjust the monitor RGB color settings based on ambient light.
- Language: There are 22 languages for your selection, including English, French, German, Italian, Spanish, Dutch, Portuguese, Russian, Czech, Croatian, Polish, Romanian, Hungarian, Turkish, Simplified Chinese, Traditional Chinese, Japanese, Korean, Thai, Indonesian, Persian, Ukrainian.
- Information: Shows the monitor information.
- All Reset: “Yes” allows you to restore the default settings, meanwhile meeting ENERGY STAR ® requirements.

## Shortcut

Defines the functions for Shortcut 1 and 2 buttons.



- Shortcut 1/Shortcut 2: Selects a function for Shortcut 1 and 2 buttons.

When a certain function is selected or activated, your shortcut key may not support. Available function choices for shortcut: Blue Light Filter, Brightness, HDR, Contrast, PIP/PBP, Color Temp., Volume, Energy Saving, User Mode 1, User Mode 2.

## Specifications summary

<b>Panel Type</b>	TFT LCD
<b>Panel size</b>	27" (16:9, 68.47cm) wide screen
<b>Max. Resolution</b>	2560 x 1440
<b>Pixel pitch</b>	0.2331 mm x 0.2331 mm
<b>Brightness</b>	350 cd/m2 (Typ.), 400 cd/m2(Peak)
<b>Contrast Ratio (Typ.)</b>	1000:1
<b>Viewing angle (H/V) CR&gt;10</b>	178°/178°
<b>Display colors</b>	16.7 M

<b>Response time</b>	< 5 ms (GTG)
<b>Preset selection</b>	8 color preset modes
<b>Auto adjustment</b>	No
<b>Color temperature selection</b>	5 color temperatures
<b>Analog input</b>	No
<b>Digital input</b>	DisplayPort v1.4, HDMI 2.0×1, DisplayPort over USB Type-C
<b>Digital Output</b>	Yes, DisplayPort
<b>Earphone jack</b>	Yes
<b>Audio input</b>	No
<b>Speaker</b>	2Wx2(4Ω)
<b>USB 3.2 Gen 1 port</b>	1 x USB 3.2 Gen 1 Type-C 3 x USB 3.2 Gen 1 Type-A
<b>Colors</b>	Black
<b>Power LED</b>	White (On)/Amber (Standby)
<b>Tilt</b>	+23° ~ -5°
<b>Pivot</b>	+90° ~ -90°
<b>Swivel</b>	+30° ~ -30°
<b>Height Adjustment</b>	130 mm
<b>Kensington lock</b>	Yes
<b>AC input voltage</b>	AC: 100~240V
<b>Power consumption</b>	Power On: 16W**, Power Standby: ≤ 0.5 W Power Off mode: 0W (Hard switch)  Power Rating: DC/ 170W max.




<b>Temperature (Operating)</b>	0°C~40°C
<b>Temperature (Non- operating)</b>	-20°C~+60°C
<b>Dimension (W x H x D) without stand</b>	613.3mm x 363.4mm x 44.9mm
<b>Dimension (W x H x D) with stand</b>	613.3mm x 536.7mm x 197.2mm (highest) 613.3mm x 406.7mm x 197.2mm(lowest) 695mm x 421mm x 133mm (package)
<b>Weight (Esti.)</b>	6.6kg (Net); 4.9kg (Net, without stand); 9kg (Gross)


<b>Multi-languages</b>	22 languages (English, French, German, Italian, Spanish, Dutch, Portuguese, Russian, Czech, Croatian, Polish, Romanian, Hungarian, Turkish, Simplified Chinese, Traditional Chinese, Japanese, Korean, Thai, Indonesian, Persian, Ukrainian)
<b>Accessories</b>	Quick start guide, warranty card, power cord, HDMI cable, DisplayPort cable, USB C to C cable, color calibration testing report, ProArt welcome card
<b>Compliance and Standards</b>	cULus, FCC, ICES-3, EPEAT Gold, CB, CE, ErP, WEEE, ISO 9241-307, UkrSEPRO, EAC, BSMI, RCM, MEPS, VCCI, PSE, PC Recycle, J-MOSS, KC, KCC, KMEPS, PSB, ENERGY STAR®, TCO,  RoHs, CEC, Windows 10/11 WHQL, TÜV Flicker Free, TÜV Low Blue Light, CCC, CEL, Vietnam EE

- Specifications are subject to change without notice.
- Power consumption of On Mode as defined in Energy Star 8.0 version.

## Outline dimensions



# Troubleshooting (FAQ)

Problem	Possible Solution
Power LED is not ON	<ul style="list-style-type: none"> <li>Press the  button to check if the monitor is in the ON mode.</li> <li>Check if the power cord is properly connected to the monitor and the power outlet.</li> <li>Check if the power switch is ON.</li> </ul>
The power LED lights amber and there is no screen image	<ul style="list-style-type: none"> <li>Check if the monitor and the computer are in the ON mode.</li> <li>Make sure the signal cable is properly connected to the monitor and the computer.</li> <li>Inspect the signal cable and make sure none of the pins are bent.</li> <li>Connect the computer with another available monitor to check if the computer is properly working.</li> </ul>
Screen image is too light or dark	<ul style="list-style-type: none"> <li>Adjust the Contrast and Brightness settings via OSD.</li> </ul>
Screen image bounces or a wave pattern is present in the image	<ul style="list-style-type: none"> <li>Make sure the signal cable is properly connected to the monitor and the computer.</li> <li>Move electrical devices that may cause electrical interference.</li> </ul>
Screen image has color defects (white does not look white)	<ul style="list-style-type: none"> <li>Inspect the signal cable and make sure that none of the pins are bent.</li> <li>Perform All Reset via OSD.</li> <li>Adjust the R/G/B color settings or select the Color Temperature via OSD.</li> </ul>
No sound or sound is low	<ul style="list-style-type: none"> <li>Ensure that the HDMI/DisplayPort/USB Type C cable is properly connected to the monitor and the computer.</li> <li>Adjust the volume settings of both your monitor and HDMI/DisplayPort/USB Type C device.</li> <li>Ensure that the computer sound card driver is properly installed and activated.</li> </ul>

## Supported operating modes


<b>Input Timing Resolution</b>	<b>Horizontal Frequency (KHz)</b>	<b>Vertical Frequency (Hz)</b>	<b>Dot Clock Frequency (MHz)</b>
<b>640×480</b>	<b>31.47(N)</b>	<b>59.94(N)</b>	<b>25.18</b>
<b>640×480</b>	<b>37.5(N)</b>	<b>75.00(N)</b>	<b>31.5</b>
<b>800×600</b>	<b>37.88(P)</b>	<b>60.32(P)</b>	<b>40</b>
<b>800×600</b>	<b>46.86(P)</b>	<b>75.00(P)</b>	<b>49.5</b>
<b>1024×768</b>	<b>48.36(N)</b>	<b>60.00(N)</b>	<b>65</b>
<b>1024×768</b>	<b>60.02(N)</b>	<b>75.00(N)</b>	<b>78.75</b>
<b>1280×720</b>	<b>44.77(N)</b>	<b>60</b>	<b>74.5</b>
<b>1280×960</b>	<b>60.00(P)</b>	<b>60.00(N)</b>	<b>108</b>
<b>1280×1024</b>	<b>63.98(P)</b>	<b>60.02(P)</b>	<b>108</b>
<b>1600×1200</b>	<b>75.00(P)</b>	<b>60.00(P)</b>	<b>162</b>
<b>1920×1080</b>	<b>67.5(P)</b>	<b>60.00(P)</b>	<b>148.5</b>
<b>2560×1440</b>	<b>88.787(P)</b>	<b>59.951(N)</b>	<b>241.5</b>
<b>2560×1440</b>	<b>111.857(P)</b>	<b>74.971(N)</b>	<b>304.25</b>
<b>2560×1440</b>	<b>150.919(P)</b>	<b>99.946(N)</b>	<b>410</b>
<b>2560×1440</b>	<b>88.771(P)</b>	<b>59.94(N)</b>	<b>234.356</b>
<b>2560×1440</b>	<b>43.786(P)</b>	<b>29.97(N)</b>	<b>115.595</b>
<b>2560×1440</b>	<b>34.933(P)</b>	<b>23.976(N)</b>	<b>92.223</b>

- “P” / “N” stands for “Positive” / “Negative” polarity of incoming H-sync/V-sync (input timing).





When the monitor is operating in the video mode (ie, not displaying data), the following high-definition modes shall be supported in addition to standard-definition video.

Timing Name	Input Vert Freq (Hz)	Horizontal.Frequency.(KHz)	Output Vert Freq (Hz)
1920 × 1080p	24Hz	27	48Hz
	25Hz	28.125	50Hz
	30Hz	33.175	60Hz
	50Hz	56.25	50Hz
	59.94Hz	67.43	59.94Hz
	60Hz	67.5	60Hz
1920 × 1080i	50Hz	28.13	50Hz
	59.94Hz	33.72	59.94Hz
	60Hz	33.75	60Hz
1280 × 720p	50Hz	37.5	50Hz
	59.94Hz	44.95	59.94Hz
	60Hz	45	60Hz
720 × 576p	50Hz	31.25	50Hz
720 × 480p	59.94Hz	31.47	59.94Hz
	60Hz	31.5	60Hz
640 × 480p(VGA)	59.94Hz	31.47	59.94Hz
	60Hz	31.5	60Hz
720(1440) × 576i	50Hz	15.63	50Hz
720(1440) × 480i	59.94Hz	15.73	59.94Hz
	60Hz	15.75	60Hz

## Documents / Resources

	<p><a href="#">ASUS MH2741A Computer Monitor</a> [pdf] User Guide  90LM06Q0-B01M70, MH2741A, MH2741A Computer Monitor, MH2741A, Computer Monitor, Monitor</p>
---	---

## References

-  [TCO Certified - the world's leading sustainability certification for IT products](#)
-  [ASUS Global](#)
-  [Homepage | ENERGY STAR](#)
-  [Homepage | ENERGY STAR](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.