



# ASUS Rog Strix Scope NX Wireless Deluxe Mechanical Keyboard User Guide

[Home](#) » [Asus](#) » ASUS Rog Strix Scope NX Wireless Deluxe Mechanical Keyboard User Guide


## Contents [ [hide](#) ]

- 1 [ASUS Rog Strix Scope NX Wireless Deluxe Mechanical Keyboard](#)
- 2 [Package Contents](#)
- 3 [Keyboard features](#)
- 4 [Connecting your gaming keyboard](#)
  - 4.1 [Using the bundled cable](#)
  - 4.2 [Pairing Bluetooth mode for the first time](#)
  - 4.3 [Using RF wireless mode](#)
  - 4.4 [Pairing Bluetooth mode to additional host devices \(max. 3\)](#)
- 5 [Updating the firmware and customization](#)
- 6 [Battery Status](#)
- 7 [Key combinations](#)
- 8 [Switching between different paired host devices](#)
- 9 [Limitation of Liability](#)
  - 9.1 [RF exposure warning](#)
  - 9.2 [Federal Communications Commission Statement](#)
  - 9.3 [Simplified UKCA Declaration of Conformity:](#)
- 10 [Documents / Resources](#)
  - 10.1 [References](#)
- 11 [Related Posts](#)





## Package Contents




## Keyboard features

Top view (US layout for reference)

Rear view

1. Num Lock indicator
2. Caps Lock indicator

3. Scroll Lock indicator
4. Function Lock indicator
5. Win lock indicator
6. RGB indicator
7. Kickstand
8. Power switch
9. USB Type-C® port Magnetic dongle storage
10. Magnetic wrist rest



## Connecting your gaming keyboard

### Using the bundled cable

Connect the bundled USB Type-C® to Type-A cable to your gaming keyboard and a USB port on your computer

### Pairing Bluetooth mode for the first time

Set the connection switch to the Bluetooth mode.

### Using RF wireless mode

1. Connect the USB dongle to a USB port on your computer.
2. Set the connection switch to the RF 2.4G Wireless mode.

### Pairing Bluetooth mode to additional host devices (max. 3)

1. Set the connection switch to the Bluetooth mode.
2. Press and hold the FN + 7 for 3 seconds until the RGB indicator on your gaming keyboard starts to blink blue.  
Once your gaming keyboard has been successfully paired, the RGB indicator on your gaming keyboard will

light up blue for 3 seconds.

## Updating the firmware and customization

1. Connect your gaming keyboard using the bundled cable and the USB dongle to USB ports on your computer.
2. Download and install the Armoury Crate software from <https://rog.asus.com>
3. Follow the software instructions to update your gaming keyboard firmware.
4. Customize your gaming keyboard using Armoury Crate.

## Battery Status

The RGB indicator on your gaming keyboard will turn red (blinking) and the LEDs for all the other keys will switch off when the battery power is below 20% in wireless mode. You may charge your gaming keyboard by using the bundled USB cable.

**NOTE:** When charging the wireless gaming keyboard, the power output may vary according to the USB port you connect your gaming keyboard to.

## Key combinations

Function key <b>Stealth Mode: Minimize all windows and mute / Maximize all windows and unmute</b>
F12: Minimize all active windows and mute the system, or maximize all minimized windows and unmute the system. <b>NOTE:</b> This function is only available when the F5 – F12 keys are toggled to Media Function.
<b>On-the-fly Macro Recording</b>
Step 1 : Fn + Left-ALT to start recording Step 2 : Fn + Left-ALT to end recording Step 3 : Assign Macro Key
<b>Profile Switch</b>
Fn + 1 / 2 / 3 / 4 / 5 / 6* <b>6 is default</b>
<b>Light Effect Switch</b>
Fn + Right or Fn + Left
<b>Brightness Level</b>
Fn + Up Fn + Down
<b>Factory Default =</b>
Fn + Esc: Hold these two buttons until the LEDs blink green.

**NOTE:** When running AURA SYNC, the hot key related with the lighting effect will be disabled, for example: Profile switch, Lighting effects switch, Brightness level.

## Switching between different paired host devices

Hot Key	Function	Lighting effect color
Fn + 8/9/0	BLE paired device 1 (default)	8/9/0 key will remain lit up in white
<b>* The key that remains lit up in white can be turned off in Armoury Crate.</b>		

## Limitation of Liability

Circumstances may arise where because of a default on ASUS' part or other liability, you are entitled to recover damages from ASUS. In each such instance, regardless of the basis on which you are entitled to claim damages from ASUS, ASUS is liable for no more than damages for bodily injury (including death) and damage to real property and tangible personal property; or any other actual and direct damages resulted from omission or failure of performing legal duties under this Warranty Statement, up to the listed contract price of each product. ASUS will only be responsible for or indemnify you for loss, damages or claims based in contract, tort or infringement under this Warranty Statement.

This limit also applies to ASUS' suppliers and its reseller. It is the maximum for which ASUS, its suppliers, and your reseller are collectively responsible.

UNDER NO CIRCUMSTANCES IS ASUS LIABLE FOR ANY OF THE FOLLOWING: (1) THIRD-PARTY CLAIMS AGAINST YOU FOR DAMAGES; (2) LOSS OF, OR DAMAGE TO, YOUR RECORDS OR DATA; OR (3) SPECIAL, INCIDENTAL, OR INDIRECT DAMAGES OR FOR ANY ECONOMIC CONSEQUENTIAL DAMAGES (INCLUDING LOST PROFITS OR SAVINGS), EVEN IF ASUS, ITS SUPPLIERS OR YOUR RESELLER IS INFORMED OF THEIR POSSIBILITY.

## RF exposure warning

The equipment complies with FCC RF exposure limits set forth for an uncontrolled environment. The equipment must not be co-located or operating in conjunction with any other antenna or transmitter.

## Federal Communications Commission Statement

This device complies with Part 15 of the FCC Rules.

**Operation is subject to the following two conditions:**

- This device may not cause harmful interference.
- This device must accept any interference received including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with manufacturer's instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**CAUTION!** The use of shielded cables for connection of the monitor to the graphics card is required to assure compliance with FCC regulations. Changes or modifications to this unit not expressly approved by the party

responsible for compliance could void the user’s authority to operate this equipment.


**Simplified UKCA Declaration of Conformity:**

ASUSTek Computer Inc. hereby declares that this device is in compliance with the essential requirements and other relevant provisions of The Radio Equipment Regulations 2017 (S.I. 2017/1206). Full text of UKCA declaration of conformity is available at <https://www.asus.com/support/>.

**CE Mark Warning**

Manufacturer	ASUSTeK COMPUTER INC.
Address, City	1F., No. 15, Lide Rd., Beitou Dist., Taipei City 112
Authorized Representative in Europe	ASUS COMPUTER GmbH
Address	Harkortstrasse 21-23, 40880 Ratingen
Country	Germany
Authorized Representative in United Kingdom	ASUSTEK (UK) LIMITED
Address	1st Floor, Sackville House, 143-149 Fenchurch Street, London, E C3M 6BL, England
Country	United Kingdom

**Documents / Resources**

	<a href="#">ASUS Rog Strix Scope NX Wireless Deluxe Mechanical Keyboard</a> [pdf] User Guide Rog Strix Scope NX Wireless Deluxe Mechanical Keyboard, Rog Strix Scope NX, Wireless Deluxe Mechanical Keyboard, Deluxe Mechanical Keyboard, Mechanical Keyboard, Keyboard
---	--

**References**

- [ROG - Republic of Gamers Global | For Those Who Dare](#)
- [ASUS ROG Strix Scope NX Wireless Deluxe Mechanical Keyboard](#) | [ASUS ROG Strix Scope NX](#), [Wireless Deluxe Mechanical Keyboard](#), [Deluxe Mechanical Keyboard](#), [Mechanical Keyboard](#), [Keyboard](#)
- [Official Support | ASUS Global](#)
- [ASUS ROG Strix Scope NX](#)
- [Info-tri | Ministères Écologie Énergie Territoires](#)
- [ROG - Republic of Gamers Global | For Those Who Dare](#)
- [ROG - Republic of Gamers Global | For Those Who Dare](#)
- [Official Support | ASUS Global](#)