



ATOMIX 13131 Automatic Desktop Alarm Clock Instruction Manual

[Home](#) » [ATOMIX](#) » ATOMIX 13131 Automatic Desktop Alarm Clock Instruction Manual 

ATOMIX 13131 Automatic Desktop Alarm Clock



Contents

- [1 About the Atomic Clock](#)
- [2 Battery Installation](#)
- [3 Desktop Clock Initial Setup and Manual Setup](#)
- [4 Desktop Alarm Clock Setup](#)
- [5 Features & Specifications](#)
- [6 LIMITED WARRANTY- INTERNATIONAL](#)
- [7 Documents / Resources](#)
- [8 Related Posts](#)

About the Atomic Clock

The National Institute of Standard and Technology (NIST) in Fort Collins, Colorado broadcasts the time signal (WWVB at 60kHz AM radio signal) with an accuracy of 1 second per every 3,000 years. The signal will be able to cover over a distance up to 2,000 miles from the source. Like a typical AM radio, your Atomic will not be able to receive the WWVB signal in places surrounded by heavy concrete or metal panels. The reception of the time signal is also greatly affected by electrical or electronic interference. To get the best performance of the Atomic clock, please install the clock nearer to a window and change directions if one direction does not work.

Battery Installation

1. Turn unit over to remove battery compartment cover. Insert 2 "AA" alkaline batteries.
2. While the battery compartment cover is off press the "DST" button for 2 seconds to activate Daylight Savings Time. The "DST" icon will appear on the LCD display. In parts of Arizona and Indiana where Daylight Saving Time is not applicable do not turn on. Move on to step 3.
3. To choose the correct Time Zone continue to press and release the "DST" button until the correct time zone appears on the LCD display.
(P, M, C, E)
4. Close the battery compartment cover.



Desktop Clock Initial Setup and Manual Setup

1. Press the RCV button for 2 seconds. You will see the radio wave icon start to flash. Your Atomic Desktop Alarm Clock is searching for the signal. If the full tower icon does not appear and the signal is not automatically available enter the present time and date by following the manual setup. Once the correct time, day and date are set the atomic clock will verify the correct time 3 times within 24 hours.

2. Press the SET key for 2 seconds. The 12 / 24 Hr selection will start to flash. The clock defaults to 12 Hr mode, if you want to choose 24 Hr mode press the UP key once.
3. Press the SET key once to enter "Seconds". Press the UP key to change entry.
4. Press the SET key once to enter "Hour" selection. Press the UP key to change entry.
5. Press the SET key once to enter "Minute" selection. Press the UP key to change entry.
6. Press the SET key once to enter "Year" selection. Press the UP key to change entry.
7. Press the SET key once to enter "Month" selection. Press the UP key to change entry.
8. Press the SET key once to enter "Date" selection. Press the UP key to change entry.
9. The Day feature is programmed based on your previous entry. No adjustment is necessary.
10. The Atomic Desktop Clock will automatically read the time and will default to Fahrenheit. To change to Celsius press the UP C/F key to toggle between Fahrenheit and Celsius.

Your Desktop Atomic Alarm Clock has been set and will operate correctly. Within 24 hours the radio wave signal will be caught and the fill tower icon will appear.

Desktop Alarm Clock Setup

1. Press the MODE key once to move into the alarm clock setting.
2. Press the SET key for 2 seconds. The "Hour" selection start to flash. Press the UP C/F key to enter your selection.
3. Press the SET key to move to the "Minute" selection. Press the UP C/F key to enter your selection.
4. Press the SET key to confirm you selection.
5. After you have confirmed your selection and are still in the alarm mode, press the UP C/F key to turn the alarm on. An icon will appear in the upper left hand corner of the LCD display.
6. The alarm will sound. Hit the Snooze / Light button at the top of the clock to activate snooze. The backlight will appear for 3 seconds and the snooze function will repeat the alarm in 5 minutes.
7. To turn the alarm off, press the MODE key and press UP C/F. The alarm icon will disappear.

Features & Specifications

- WWVB Radio-Controlled Clock with 4 time zones (P, M, C, E)
- Perpetual calendar with Month, Date/Day of Week
- Daylight Saving Time
- Digital Thermometer with Range from 14 F – 122 F (-10 C – 50 C)
- 12 / 24 Hour Clock
- C / F selectable
- Alkaline Battery: 2 "AA"

LIMITED WARRANTY- INTERNATIONAL

Consumer may have more remedies at law than follows. Chaney Instrument Company warrants to the owner, this product to be free from defect in material and workmanship for one year from date of purchase. CHANEY INSTRUMENT SHALL NOT BE LIABLE FOR ANY INCIDENTAL, INDIRECT OR CONSEQUENTIAL DAMAGES, WHETHER ARISING IN CONTRACT OR

TORT. Chaney Instrument's obligation (at its option) is limited to repair or Replace this product. For in-warranty repair, s end clock, accompanied by Guarantee, bearing Dealer's name and date of purchase with \$5.00 to cover handling and postage, to:

Chaney Instrument Company 965 Wells Street Lake Geneva, Wisconsin 53147



www.chaneyinstrument.com

Tel: 877-22 1-1252

Made in China



Documents / Resources

<div><p>ATOMIX 13131 Automatic Desktop Alarm Clock Model Number: 13131</p><p>About the Alarm Clock The Atomix Alarm Clock is designed to be a reliable and accurate timepiece. It features a large, easy-to-read LCD display with a backlit screen. The clock is powered by a 3V lithium battery and has a built-in alarm. The clock is designed to be a reliable and accurate timepiece. It features a large, easy-to-read LCD display with a backlit screen. The clock is powered by a 3V lithium battery and has a built-in alarm.</p><p>Battery Installation 1. Turn over the clock to access the battery compartment cover. 2. Insert the battery compartment cover in the correct direction. The "ATOMIX" logo for the cover is visible on the inside of the cover. The "ATOMIX" logo will appear on the LCD display. To replace the battery, remove the cover and insert the new battery. The cover is not applicable to the cover. 3. Turn over the clock. The cover is now in place and the "ATOMIX" logo will appear on the LCD display. To replace the battery, remove the cover and insert the new battery. The cover is not applicable to the cover. 4. Check the battery compartment cover.</p></div>	<p>ATOMIX 13131 Automatic Desktop Alarm Clock [pdf] Instruction Manual 13131, Automatic Desktop Alarm Clock</p>
<div><p>ATOMIX 13131 Automatic Desktop Alarm Clock Model Number: 13131</p><p>About the Alarm Clock The Atomix Alarm Clock is designed to be a reliable and accurate timepiece. It features a large, easy-to-read LCD display with a backlit screen. The clock is powered by a 3V lithium battery and has a built-in alarm. The clock is designed to be a reliable and accurate timepiece. It features a large, easy-to-read LCD display with a backlit screen. The clock is powered by a 3V lithium battery and has a built-in alarm.</p><p>Battery Installation 1. Turn over the clock to access the battery compartment cover. 2. Insert the battery compartment cover in the correct direction. The "ATOMIX" logo for the cover is visible on the inside of the cover. The "ATOMIX" logo will appear on the LCD display. To replace the battery, remove the cover and insert the new battery. The cover is not applicable to the cover. 3. Turn over the clock. The cover is now in place and the "ATOMIX" logo will appear on the LCD display. To replace the battery, remove the cover and insert the new battery. The cover is not applicable to the cover. 4. Check the battery compartment cover.</p></div>	<p>ATOMIX 13131 Automatic Desktop Alarm Clock [pdf] Instruction Manual 13131, Automatic Desktop Alarm Clock</p>