



AVA OnCollab AT-C/AT-H SynCast Streamer User Guide

[Home](#) » [AVA](#) » AVA OnCollab AT-C/AT-H SynCast Streamer User Guide 



One Click Casting
OnCollab AT-C/AT-H Quick Start Guide
AVAOCATQSG V1.0
82445-00070-33010-T

Contents

- 1 OnCollab AT-C/AT-H SynCast Streamer
- 2 Pairing
- 3 Usage Instructions
- 4 LED Indicators
- 5 LED Indicators
- 6 Documents / Resources
 - 6.1 References

OnCollab AT-C/AT-H SynCast Streamer

Connections and Indicators

C. USB-C Connections


Connect AT-C to the USB-C port on the computer.



*The USB-C port must support DP signal output.

H. HDMI & USB-A Connections


Connect AT-H to the HDMI & USB-A port on the computer or another power source.



When using the AT-C/AT-H for the first time, please pair the unit with your OnCollab device.

Pairing

1. USB 3.0 Connections




Connect the AT-C/AT-H to the USB 3.0 port of the OnCollab device. The device will enter pairing mode.

2. Enter the Wifi password



After entering the password, the device will start pairing.

3. Pairing Successful



When the device has successfully paired, unplug the AT-C/AT-H.


Usage Instructions

1. Setup your OnCollab Device



Turn on and setup the OnCollab Device that has been paired with AT-C/AT-H

2. **USB-C/HDMI Connections**



Connect the AT-C to the USB-C port. Connect the AT-H to the HDMI & USB port

3. **Wait for the Light Indicator**




Wait until the large button emit a constant blue light before using it.


LED Indicators


LED Indicators


1 Large Button-Projection


 Blue

 Constant Light
Standby, ready for projection.

 Orange


 Pulsing Light
Projection in progress


 Orange


 Blinking Light
Moderator Control Activated


2 Small Button – Video Conference



 Blue

 Constant Light
Standby.


 Constant Light

 Orange
OnCollab camera detected

 Orange

 Pulsing Light 
OnCollab camera is in use.



 Green

 Constant Light
OnCollab speaker & microphone detected.


 Green

 Pulsing Light 
OnCollab speaker & microphone are in use.


 Red

 Constant Light 
OnCollab microphone is muted
Small and Large Button – Other Status

 Blue

 Pulsing Light
Establishing connection with Wi-Fi

 Blue

 Blinking Light
Searching for OnCollab devices.

 Yellow

 Blinking Light

No audio/video output from the computer's USB-C/HDMI port.

"If the connection cannot be established continuously, please check the network is normal or the password is entered correctly during pairing."

*If OnCollab devices cannot be found continuously, please check if the OnCollab device is connected to the correct network or repair it.

Federal Communication Commission Interference Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

RF exposure warning

This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provided with antenna installation instructions and transmitter operating conditions for satisfying RF exposure compliance.




Copyright 2024 Narvitech Corp.

All rights reserved. All trademarks and registered trademarks are the property of their respective owners and are used under the fair use doctrine. www.narvitech.com/AVA



OnCollab AT-C/AT-H
Product Registration

Documents / Resources

	<p>AVA OnCollab AT-C/AT-H SynCast Streamer [pdf] User Guide</p> <p>CT1292, 2AP48CT1292, OnCollab AT-C AT-H SynCast Streamer, OnCollab AT-C AT-H, SynCast Streamer, Streamer</p>
---	---

References

- [User Manual](#)

Manuals+. Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.