



Home » Avery » Avery PUCK001 BLE Tags for Asset Tracking User Manual 📆

Contents [hide]

- 1 Avery PUCK001 BLE Tags for Asset Tracking
- 2 Specifications
- 3 Product Usage Instructions
- 4 Instructions
- **5 FCC STATEMENT**
- 6 FAQS
- 7 Documents / Resources
 - 7.1 References



Avery PUCK001 BLE Tags for Asset Tracking



Specifications

• Protocol: BLE 5.0 Google Eddystone

• Service: RF frequency 2.4GHz

- Power Supply: Li battery, 3.2V CR2032
- Sensing Distance: 5m 10m
- RF frequency:2.4GHz

Product Usage Instructions

Important Safety Information

- Connect the equipment to an outlet on a circuit different from that of the receiver.
- Consult the dealer or an experienced radio/TV technician for help.
- The device has been evaluated to meet the general RF exposure requirements and can be used in portable exposure conditions without restriction.

Introduction

- This little beacon is a Bluetooth device according to the Google Eddystone protocol,
 which broadcasts a message frame every two seconds.
- And if there is no movement every 30 minutes, the signal broadcasting will stop. This
 means the tag is not with people.



RF Remote Advanced

• Keep this tag in a human being's pocket or insert it in a silicone wristband. When the people start moving, the sensor will activate the tag and send a signal out.

- To cooperate with the receiver, the software for positioning can determine where the people are located in the park.
- Of course, if the task g not moving in 30 minutes, it may mean some unexpected has happened.
- Using this BLE tag, the receiver can get the signal to track the human being or other facilities.

Instructions

- Card Type RF Remote
- 1 Static Colour
- Ultra Slim Design
- Very Smooth Effects
- Easy Remote Pairing

Installing

1. Power supply

This unit uses 3a .2v CR2032 battery for power supply.

2. Signal output

After powered, people don't need make any operation on the tag, the tag will send the signal out to the receiver.

Operation

Anybody could carry their beacon, while a Bluetooth wireless reader can get the message from the beacon to track it.

FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

 NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, under Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used according to the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet the general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

FAQS

Q: How often does the tag broadcast its message frame?

A: The tag broadcasts its message frame every two seconds.

Q: What happens if the tag does not detect any movement for 30 minutes?

A: If there is no movement detected for 30 minutes, the signal broadcasting will stop.

Q: What is the recommended power supply for the unit?

A: The unit requires a 3.2V CR2032 battery for power supply.

Documents / Resources



Avery PUCK001 BLE Tags for Asset Tracking [pdf] User Manual PUCK001 BLE Tags for Asset Tracking, PUCK001, BLE Tags for Asset Tracking, Asset Tracking, Tracking

References

- User Manual
- Avery
- Asset Tracking, AVERY, BLE Tags for Asset Tracking, PUCK001, PUCK001 BLE Tags for Asset Tracking, Tracking

Leave a comment

Your email address will not be published. Required fields are marked*

Comment*

Name

Email

Website

Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.