

BASSJAXX SP-0130 Dynamic Wireless Speaker Instruction Manual

[Home](#) » [BASSJAXX](#) » BASSJAXX SP-0130 Dynamic Wireless Speaker Instruction Manual 



**DYNAMIC
WIRELESS SPEAKER**

Instruction Manual


Thank you for purchasing the Dynamic Wireless Speaker. This manual provides more information about this wireless speaker, please read the instructions before using it.

BASSJAXX SP-0130 Dynamic Wireless Speaker - Featured Image

Contents

- [1 Product Overview](#)
- [2 Package Contents](#)
- [3 Power on/Off](#)
- [4 Charging your Wireless speaker](#)
- [5 Technical specification](#)
- [6 FAQ](#)
- [7 FCC STATEMENT](#)
- [8 Documents / Resources](#)
- [9 Related Posts](#)

Product Overview



Package Contents

Dynamic Wireless Speaker x 1
Micro USB Charging Cable x 1
Instruction Manual x 1

Power on/Off

Power on

Switch on the Power Button.

Power off

Switch off the Power Button.

Note: Always power off the speaker when not in use.

Pair Wireless speaker with your mobile device

1. Keep the distance between your wireless speaker and mobile phone (or other devices) within 32.8 Feet.
2. Open the silicon seal cover and switch on the wireless speaker.
3. Activate the Bluetooth function on your phone within range and select "BT IPX RATED SPK" from the list shown.

4. You will hear a beep sound when pairing is successful.

Reconnect Wireless speaker to your mobile device

When powered on, the wireless speaker will automatically connect with the last successfully paired device.

Charging your Wireless speaker



For your safety, please always use the appropriate 5V input charger/Adapter to charge the product. **DO NOT USE** Quick Charging USB Adapter to charge the product, as it might damage the product.

1. Use the Micro USB charging cable provided with this wireless speaker.
2. Connect the Micro USB plug to the Micro USB charging port on the speaker, then connect the USB plug to a USB port on a computer or wall adapter to begin charging.
3. The LED Indicator will turn red while charging and will turn off once fully charged.

NOTE:

- You must select a qualified charger from a regular manufacturer.
- You must charge the Wireless speaker if it has been not used for more than 12 months.



Technical specification

Driver Diameter: 52 mm
Bluetooth Range: 32.8 Feet
Impedance: 4 Ohms
Power Supply:
Charging Method: USB Charging
Li-Ion Battery 3.7V 300 mAh
Micro USB Charging Cable Included
Playtime: 2-2.5 Hours
Charging Time: 1.5-2 Hours

IPX4 Water Protection

FAQ

- **If the Wireless speaker cannot be paired with your device, please try the following:**

Ensure that your speaker is in pairing mode or reconnection mode. Ensure that the Bluetooth search function of your mobile device is activated.

- **If the Wireless speaker cannot be recharged:**

If you use a power outlet, ensure that the power supply is connected securely and the outlet works. If you use a

computer, ensure that it is connected and the USB port is powered.



Safety instructions for the lithium battery and charging the product

- The input voltage to the product is DC 5V 1A.
- In order to charge the product in a safe manner and reliable conditions, please only adopt a certified appropriate charger/ adapter for charging the product.
- Only charge the product at ambient temperatures between 10 deg °C/ 50 deg °F and 40 deg tr104 deg °F.
- Do not heat above 70 deg °C/193 deg °F, eg. Do not expose to sunlight or throw into fire. -Switch off the product after use.
- Please note that we won't take any responsibility for any wrong operation (eg. Voltage higher than 5V) as this may result in severe injury or loss of property, and we cannot control the operating process during the time the user using this product.
- In extreme cases, abuse or misuse of the Lithium battery packs can lead to explosions, heat generation, fire development, or smoke development.



CAUTION:

1. Do not fully submerge in water. This item is IPX4 resistance only.
2. Keep the device dry. Avoid dusty, and dirty environments. Using the device in these environments may damage the circuitry.
3. Do not use the device during thunderstorms to avoid any lightning-related damage or injury.
4. Do not attempt to disassemble or remanufacture the device, insert foreign objects into it, or immerse or expose it to water or other liquids. Doing so may lead to fire, explosion, or other hazards.
5. Keep the device away from excessive heat sources and direct sunlight. Do not place it on or in heating devices, such as microwave ovens, stoves, or radiators. The device may even explode in extreme overheating circumstances.

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 - This device may not cause harmful interference.
 - This device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class **B** digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning

the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.




FCC ID: 2ADM5-SP-0130

ITEM# SP-0130

Distributed by 1616 Holdings, Inc.
701 Market Street, Suite 200
Philadelphia, PA 19106
Made in China

Keep All Relevant Information For Future Reference

Documents / Resources

	BASSJAXX SP-0130 Dynamic Wireless Speaker [pdf] Instruction Manual SP-0130, SP0130, 2ADM5-SP-0130, 2ADM5SP0130, SP-0130, Dynamic Wireless Speaker
---	---