



## baykeep App For WiFi Camera User Guide

[Home](#) » [baykeep](#) » baykeep App For WiFi Camera User Guide 

**Baykeep App For WiFi Camera**



## Contents

- [1 Download App](#)
- [2 Account Login](#)
- [3 Add Device By Scanning Code](#)
- [4 FCC WARNING](#)
- [5 Add Device By AP Hotspot](#)
- [6 Features](#)
- [7 FAQs](#)
- [8 Documents / Resources](#)
  - [8.1 References](#)
- [9 Related Posts](#)

## Download App

Scan the QR code below to download the latest software APP, or directly search for “BoyKeep~ in the App Store and Goole Play to download



Boykeep




Scan to download

**Note:** iPhone requires iOS 10.0 or higher, Android phone requires Android 5.0 or higher



### **Account Login**

1. Enter your account and password, click the “Login” button
2. If it is the first time to use Boykeep, please register an account first



### Add Device By Scanning Code

1. Select the correct device model you want to add
2. Enter your Wi-Fi account and password, and choose to connect to 2.4G or SG WiFi signal according to the device model



1. Place the QR code on the phone screen 4-12 inches in front of the device, and move it back and forth slowly
2. When the device scans the QR code on the phone, the device will make a “beep beep” sound



1. Please wait patiently for 1-2 minutes, the device will connect to the network and bind to your account
2. If the device prompts "Network connection failed", please recheck the entered Wi-Fi account and password, and make sure they are correct



## FCC WARNING

This device complies with part 15 of the FCC Rules.  
Operation is subject to the following two conditions :

1. this device may not cause harmful interference, and
  2. this device must accept any interference received, including interference that may cause undesired operation .
- Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment .

**NOTE :** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules . These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates , uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation . If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/ TV technician for help.

To maintain compliance with FCC' s RF Exposure guidelines, This equipment should be installed and operated with minimum 20cm distance between the radiator and your body: Use only the supplied antenna .

## Add Device By AP Hotspot


1. Select the correct device model you want to add
2. Click “Go to Phone Settings”, connect to the Wi-Fi starting with “CAM\_AP”, and then back to BoyKeep



**Note:** During the process of adding device, please allow all permission requests, otherwise the process may fall

1. When the phone is connected to the hotspot of the device, then back to boykeep
2. Enter your home Wi-Fi account and password correctly
3. On phones with iOS 14 and above, BE SURE to select “OK” in the following dialog






1. Please wait patiently for 1-2 minutes, the device will connect to the network and bind to your account
2. If the device prompts "Network connection failed", please recheck the entered Wi-Fi account and password, and make sure they are correct



## Features



## FAQs

### 1. When adding a device, the device prompts “Network connection failed”

Make sure the entered Wi-Fi name and password are correct. Some devices only support 2.4G Wi-Fi network and do not support 5G signal. Please contact the supplier to confirm.

### 2. Device often appears offline

Replace a power adaptor, and place the device close to the router. It is recommended that there should be no solid walls, metal door frames, etc. between the two, so as not to affect the network signal strength.

### 3. A memory card is inserted into the device but can be recognized

The device supports a memory card up to 128GB. Put the memory card on the computer and format it into FAT32, and then insert the memory card into the device before power on.


## Notes

1. Please cut the power off when inserting/removing your SD card to ensure it can be recognized.
2. To improve the success rate of scanning QR code, please make sure there is no dust on the lens, adjust the smartphone screen brightness to high, tap the QR code to enlarge it, adjust the distance between the lens and screen, the optimal distance is 4-12 inches.
3. Do not use the device in any extreme weather environments such as extremely high, low temperatures, direct strong sunlight, or heavy rain for long periods of time. The suitable temperature for the product and accessories is -20 °C to 60 °C.

4. If you use a third-party charger, the recommended output voltage/current of the adaptor is DC 5V/2A.



## Documents / Resources

	<a href="#">baykeep baykeep App For WiFi Camera</a> [pdf] User Guide baykeep App For WiFi Camera, App For WiFi Camera, WiFi Camera, Camera
---	---

## References

- [User Manual](#)

### Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.