

Bitwave Pte EXO-COM Bluetooth Comm System Instruction Manual

Home » Bitwave Pte » Bitwave Pte EXO-COM Bluetooth Comm System Instruction Manual




Contents

- 1 Bitwave Pte EXO-COM Bluetooth Comm **System**
- 2 Overview
- 3 Device Installation(Controller)
- 4 Device Installation(Battery)
- 5 Device Installation(Non-Smart Version)
- 6 Start
- 7 Pair Device to App
- 8 Firmware Update
- 9 Reset
- 10 Battry Recharge
- 11 Intercom Group Pairing Setup The First set up
- 12 FCC Statement
- 13 Documents / Resources
 - 13.1 References
- **14 Related Posts**





Overview




- SCORPIONSPORTS.EU
- SCORPIONUSA.COM




Manual Address: https://scorpionsports.eu/

Device Installation(Controller)



- Push up the Locking Lever (1) to remove EXO-COM Controller Cover (2), and put Mic/Speaker Female Connector (3A) into the hole first, and then Battery Pack Male Connector (3B) referring to the above picture.
- Install the EXO-COM Controller (4), and make sure it is properly positioned by sitting on two bumps (5) at the bottom.
- Connect the mic/speaker's female connector (3A) to its male connector (3a).
- Reverse the process to remove the EXO-COM.


Device Installation(Battery)




Check the manual for proper installation. The installation process can be different depends on the model.


Device Installation(Non-Smart Version)

Check the manual for proper installation. The installation process can be different depends on the model.





Pair Device to App




- 1. Homepage
- 2. Device Connect





- 3. Device Information
- 4. Configuration






Firmware Update

- 1. Connect your EXO-COM controller to your PC.
- 2. Download firmware from BitWave website.
- 3. Install the new firmware through your PC.

Reset




Battry Recharge




Use included USB-C type cable to recharge the battery. LED turns green if the charge is done

Activate Phone Pairing



Hold UP+DOWN 2 sec.





Pick up Incoming call



End / Reject Incoming call




Hold POWER 2 sec.


Swap call



Last number Redial



Music



Activate Siri/Google



Press QUICK ACCESS once, wait for tone

Manual Download

https://scorpionsports.eu/

Warranty Contact

https://uclear.eu/en/



Intercom Group Pairing Setup The First set up

- 1. Power ON State
- 2. Press and hold QUICK ACCESS for 5 secs until LED blinks purple. blinking purple before next step.






3. Press POWER on any EXO-COM device to initiate pairing process. The units will blink green once they are connected.




4. The last unit to pair continues to blink purple for 15 secs before system ends the pairing process. Optional: Press POWER once on the last unit blinking purple to end pairing manually.




Intercom Control ON/OFF


Intercom Connect




Intercom Disconnect



Intercom Pairing(other brand) Setup







wait until LED turn green

If the LED is **green**, you are succesfully connected. If the LED is **purple**, go back to step 1.

FCC Statement

- 1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 - 1. This device may not cause harmful interference.
 - 2. This device must accept any interference received, including interference that may cause undesired operation.
- 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

SAR Information Statement

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radiofrequency (RF) energy set by the Federal Communications Commission of the U.S. Government. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluations of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age and health. The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate or SAR. The SAR limit set by the FCC is 1.6 W/kg. * Tests for SAR are conducted with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output. Before a phone model is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the limit established by the government adopted a requirement for safe exposure. The tests are performed in positions and locations (e.g., at the ear and worn on the body) as required by the FCC for each model. The highest SAR value for this device when

tested for use at the head is 0.286W/Kg and the maximum scaled SAR in extremity

SAR is 0.056W/Kg While there may be differences between the SAR levels of various phones and at various positions, they all meet the government requirement for safe exposure. The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of http://www.fcc.gov/oet/fccid after searching on

FCC ID: NMC-XCOM Additional information on Specific Absorption Rates (SAR) can be found on the Cellular Telecommunications Industry Asso-ciation (CTIA) web-site at http://www.wow-com.com. In the United States and Canada, the SAR limit for mobile phones used by the public is 1.6 watts/kg (W/kg) averaged over one gram of tissue. The standard incorporates a substantial margin of safety to give additional protection for the public and to account for any variations in measurements.

Documents / Resources



Bitwave Pte EXO-COM Bluetooth Comm System [pdf] Instruction Manual XCOM, NMC-XCOM, NMCXCOM, EXO-COM Bluetooth Comm System, Bluetooth Comm System

References

- 5 ScorpionExo: Premium Motorcycle Helmets and Riding Gear
- F© Federal Communications Commission | The United States of America
- © CTIA Home
- Security Security Security
- Bluetooth + MESH intercoms from UCLEAR for motorbike and other sports, office and industry

Manuals+,