blink 13FT Weather Resistant Power Adapter





blink 13FT Weather Resistant Power Adapter Instruction Manual

Home » blink » blink 13FT Weather Resistant Power Adapter Instruction Manual



Contents

- 1 blink 13FT Weather Resistant Power **Adapter**
- **2 IMPORTANT PRODUCT INFORMATION**
- **3 PRODUCT SPECIFICATION**
- 4 Documents / Resources
 - 4.1 References
- **5 Related Posts**



blink 13FT Weather Resistant Power Adapter



IMPORTANT PRODUCT INFORMATION

SAFETY INFORMATION

READ ALL SAFETY INFORMATION BEFORE USING THE DEVICE. FAILURE TO FOLLOW THESE SAFETY INSTRUCTIONS COULD RESULT IN FIRE, ELECTRIC SHOCK, OR OTHER INJURY OR DAMAGE.

DANGER — TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, FOLLOW THESE INSTRUCTIONS CAREFULLY.

- DO NOT force the adapter into a power outlet.
- DO NOT expose the adapter, metal connectors, or cable to liquids.
- If the adapter or cable appears damaged, discontinue use immediately.
- Be sure to hold the plug, not the cable, when plugging in or out. Grabbing the cable may damage the wire or cause problem.
- DO NOT install when it is raining.
- DO NOT install on a hot surface or metal surface (one that stores heat).
- Ensure the cable is securely fastened along its length and be aware of hazards from a weed whacker, hedge trimmer, or similar equipment.
- DO NOT expose the adapter to corrosive materials.
- Use only with compatible Blink devices. For device compatibility, please see the detail page for your accessory on https://support.blinkforhome.com/indoor-outdoor-accessories.

WARNING: Strangulation Hazard. Children have strangled in cables. Keep out of reach of young children. WARNING: Small parts contained in your device and its accessories may present a choking hazard to small children

WARNING: Risk of Electric Shock.

Your adapter is raintight and meets IP67 test conditions under IEC 60529, and can withstand outdoor use and contact with water under certain conditions. When used with compatible Blink devices, refer to the IP rating of the device into which the adapter is plugged. Do not plug the power adapter into an outdoor socket without first ensuring it has appropriate weather resistance for outdoor use. Always ensure socket is easily accessible and located near the Blink device that it is powering. Install only to a covered Class A GFCI electrical socket that has an enclosure that is weatherproof with the attachment plug cap inserted or removed.

Not for use with electrical sockets that are weatherproof only when the socket is covered (attachment plug cap

not inserted and electrical socket cover closed).

- Your adapter is not intended for underwater use and may experience temporary effects from exposure to water.
 Do not intentionally immerse your adapter in water. Do not spill any food, oil, lotion, or other abrasive substances on your adapter.
- Do not expose your adapter to pressurized water, high velocity water, or extremely humid conditions (such as a steam room). Do not expose your adapter to salt water or other conductive liquids. To protect against electric shock, do not place cord, plug, or adapter in water or other liquids. If your adapter gets wet from immersion in water or high pressure water, carefully disconnect all cables without getting your hands wet and wait for them to dry completely before powering it on again. Do not attempt to dry your adapter with an external heat source, such as a microwave oven or a hair dryer. To avoid risk of electric shock, do not touch your adapter or any wires connected to your device during a lightning storm while your device is powered.
- If your adapter is dropped or otherwise appears damaged, discontinue use immediately, as the waterproofing of the adapter may be compromised.

Other Safety Considerations

Your device does not have an on/off button. If you wish to stop power from flowing into your device, unplug the power cord. Do not plug multiple electric devices into the same wall socket. Overloading a socket can cause it to overheat and may result in a fire

CAUTION: When mounting this device in elevated locations, use precautions to ensure that the device does not fall and harm bystanders.

PRODUCT SPECIFICATION

• Model Number: BAH0410U

• Adapter Made By: Dongguan Aohai Technology Co. Ltd.

Input Rating: 100-240Vac, 50/60Hz, 0.35W

Output Rating: 5.0Vdc, 2.0A, 10.0W

• Average Active Efficiency: 82.5% @115Vac

No-load Power Consumption: 0.032W @115Vac

• Operating Temperature Range: -20°C to 50°C (-4°F to 122°F)

FOR USERS IN THE UNITED STATES

Device Name: Weather Resistant Power Adapter

Model: BAH0410U

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. Responsible Party and Party issuing Supplier's Declaration of Conformity: Amazon.com Services LLC, 410 Terry Avenue North, Seattle, WA 98109, U.S.A. www.blinkforhome.com/contact-us

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this

equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- Caution, pursuant to Section 15.21 of the FCC rules, user changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FOR USERS IN CANADA

CAN ICES-3(B) RECYCLING YOUR DEVICE PROPERLY

In some areas, the disposal of certain electronic devices is regulated. Make sure you dispose of, or recycle, your device in accordance with your local laws and regulations. For information about recycling your device, go to www.amazon.com/devicesupport.

Additional Safety and Compliance Information

For additional safety, compliance, recycling and other important information regarding your device, please refer to the Legal and Compliance section of the About Blink menu in the Settings in your app or on the Blink website at https://blinkforhome.com/safety-and-compliance

TERMS AND POLICIES

By purchasing or using the product, you agree to the Terms of Service found at https://blinkforhome.com/terms-of-service

LIMITED WARRANTY

For information on our warranty and any other applicable policy, visit https://blinkforhome.com/blink-terms-warranties-and-notices

ADDITIONAL INFORMATION

You can find the Customer Service contact information and other applicable terms and Device information (including in other languages) at https://support.blinkforhome.com/

Documents / Resources



blink 13FT Weather Resistant Power Adapter [pdf] Instruction Manual 13FT Weather Resistant Power Adapter, Weather Resistant Power Adapter, Resistant Power Adapter, Power Adapter, Adapter

References

- a Amazon.com
- a amazon.com/
- <u>a Amazon Digital Services and Device Support Amazon Customer Service</u>
- D Contact Blink Blink Smart Security

- **b** Terms and Conditions Blink Smart Security
- **b** Terms of Service US Blink Smart Security
- **b** Blink Support
- **b** Accessories Blink Support
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.