

blink RC1 XbotGo Remote Controller User Manual

Home » blink » blink RC1 XbotGo Remote Controller User Manual

Contents

- 1 blink RC1 XbotGo Remote Controller
- **2 Product Information**
- **3 Remote Controller Specifications**
- 4 Quick Start Guide
- 5 XbotGo RC1 Remote Controller
- **6 Buttons and Functions**
 - **6.1 Camera Function**
 - **6.2 Photo Function**
 - **6.3 Steering Function**
 - **6.4 Mark Function**
- 7 Battery
- 8 Documents / Resources
 - 8.1 References
- 9 Related Posts



blink RC1 XbotGo Remote Controller



Product Information

Remote Controller Specifications

Model: XbotGo Remote ControllerBattery Model: [battery model]

• Signal Coverage Range: [signal coverage range]

• **Temperature:** [temperature range]

Quick Start Guide

- 1. Open the battery compartment cover, then remove the insulating plastic sheet from the bottom of the battery and close the battery compartment cover.
- 2. Press and hold the power button for [duration] seconds to turn on/off the remote controller.
- 3. After turning on, press the function selection button to switch functions.
- 4. If the controller is powered on, the phone connection indicator flashes red.
- 5. To exceed the signal range (meters), the red menu indicator light and the circular ring light on the remote control will flash, indicating that the remote controller has been disconnected from the APP. If it returns to the reception range in less than a minute, the remote controller's blue light will turn on, and the connection will be automatically restored.
- 6. Sleep mode and Shutdown: The remote controller enters the dormant state without any operation. In the dormant state, press any button on the remote control to enter the connected state. After sleeping for more than five minutes, the remote control will automatically shut down. Press the power button and then close the device again after turning on to reconnect.

Note:

The disconnection of the remote controller during use will not affect the APP running on the phone. If the APP cannot find the remote controller during use, you can reset the remote controller by pressing the power button for [duration] seconds, then perform the pairing again.

Buttons and Functions

Before you use it, get familiar with the remote controller.

- A. Power Button
- B. Function Selection Button
- C. Confirm Button
- **D.** Directional Buttons (Circular Disk)
- E. Battery Compartment

Camera Function

- A beep sound will appear, indicating entry into camera mode.
- Two consecutive beep-beep sounds indicate that the camera is paused or

A blue mask will prompt on the screen for [duration] seconds and will automatically disappear after [duration] seconds. At this point, it is in camera mode, and you can check the status with corresponding operational commands.

Photo Function

Steering Function

Mark Function (Available only during camera function mode)

Manually mark the highlight moments during the game. It will produce a highlight video of the game automatically online and upload it to the cloud. Pressing the confirm button on the remote controller, XbotGo APP will record video segments before and after the marked moment. When the marking button is pressed, the blue circular ring light will flash, indicating successful marking. Highlights can be viewed in XbotGo App/Cloud Management/Cloud Drive.

FAQ

- Q: How do I turn on/off the remote controller?
 - A: Press and hold the power button for [duration] seconds to turn on/off the remote controller.
- Q: How do I switch functions on the remote controller?
 - A: After turning it on, press the function selection button to switch functions.
- Q: How do I reconnect the remote controller if it gets disconnected?
 - A: If the remote controller gets disconnected from the APP, make sure it is within the signal range. If it returns to the reception range in less than a minute, the connection will be automatically restored. If not, press the power button for [duration] seconds to reset the remote controller and perform the pairing again.
- Q: How long does the remote controller stay in sleep mode?
 - A: The remote controller enters sleep mode after five minutes of inactivity. Press any button on the remote control to wake it up and enter the connected state.
- Q: Can I use the remote controller without affecting the APP running on my phone?

A: Yes, the disconnection of the remote controller during use will not affect the APP running on the phone.

We sincerely thank you for choosing XbotGo!

To better use this product, please carefully read the instructions before use and keep this manual for future reference. If you

have any questions, feel free to contact us. Our professionals will be happy to answer your questions and help. We wish you a

pleasant experience.

Warning:


Please read all safety warnings and instructions carefully. Failure to comply may result in fire, electric shock, or other serious injuries. Please keep all warnings and instructions for future reference.

Environmental Protection Instructions:


- Comply with the waste disposal laws and regulations of relevant countries. Electronic devices should not be disposed of as household waste. Devices, accessories, and packaging should be recyclable.
- Do not litter electronic waste at will.

Remote Controller Specifications

Model:	XbotGo RC1
Battery Model:	CR2032
Signal Coverage Range:	10m
Temperature:	-5°C ~ 60°C 23°F ~ 140°F



- A. Open the battery compartment cover, then remove the insulating plastic sheet from the bottom of the battery and close the battery compartment cover.
- B. Press and hold the power button for 3 seconds to turn on/off the remote controller.
- C. After turning it on, press the function selection button to switch functions.
- **D.** Bluetooth pairing is required before the first use.
 - Press and hold the remote controller's power button. After the remote controller is powered on, the phone connection indicator flashes red.



Open the XbotGo APP on your phone and select XbotR-XXXX in the XbotGo APP for pairing. After the
connection is established, the phone connection indicator on the remote controller will turn into a solid
blue.

• E. Exceed the signal range (10 meters):

The red menu indicator light and the circular ring light on the remote control are flashing, indicating that the remote controller has been disconnected from the APP. If it returns to the reception range in less than 1 minute, the remote controller's blue light will turn on, and the connection will be automatically restored.




• F. Sleep mode and Shutdown:

The 3S remote controller enters the dormant state without any operation. In the dormant state, press any button on the remote control to enter the connected state. After sleeping for more than five minutes, the remote control will automatically shut down, press the power button, and then close the device again after turning on to reconnect.

Note:

The disconnection of the remote controller during use will not affect the APP running on the phone. If the APP cannot find the remote controller during use, you can reset the remote controller by pressing the power button for 3 seconds, then perform the pairing again.

XbotGo RC1 Remote Controller



- A. Power Button
- B. Function Selection Button
- C. Confirm Button
- **D.** Directional Buttons (Circular Disk)
- E. Battery Compartment

Buttons and Functions

Before you use it, get familiar with the remote controller.

Camera Function

Press the Function Selection button to switch to camera mode; press the confirm button in camera mode to control the shooting states.

• On the remote controller:

- A. A "beep" sound will appear, indicating entry into camera mode.
- B. Two consecutive "beep-beep" sounds indicate that the camera is paused or not activated at this time.


• On the APP side:

A blue mask will prompt on the screen for 3 seconds and will automatically disappear after 3 seconds. At this point, it is in camera mode, and you can check the status with corresponding operational commands.




Photo Function

- Press the Function Selection button to switch to the photo mode;
- In photo mode, press the confirm button to take photos.



Steering Function

- Press the Function Selection button to switch to the steering mode;
- Press the up, down, left, and right directional buttons to rotate the gimbal in the corresponding direction.




Mark Function

(Available only during camera function mode)

Manually mark the highlight moments during the game. It will for generating produce a highlight video of the game automatically online and upload it to the cloud.

Pressing the confirm button on the remote controller, the XbotGo APP will record video segments before and after the marked moment. When the marking button is pressed, the blue circular ring light will flash, indicating successful marking. Highlights can be viewed in the XbotGo App/Cloud Management/Cloud Drive.



Note

If the remote controller's red breathing light flashes, the buzzer alerts, or if the APP displays errors or command execution failures, please follow the prompts on the APP side for operation.



Battery

The remote controller is equipped with a CR2032 button battery.

Notes

For optimal product performance:

- Please do not use different types of batteries.
- If you do not intend to use the device for more than two months, please do not leave the battery in the remote controller.

Battery Disposal:


• Do not dispose of batteries as unsorted municipal waste. Please refer to local regulations for proper battery disposal.




Notes on Remote Controller

- The remote controller must be used within a range of 10 meters from the device.
- When the remote control signal is received, the App will provide pairing prompts.

Documents / Resources





References

• User Manual

Manuals+, Privacy Policy