

BONTEMPI®

**49 1010
Wireless
Speaker
with
Microphone**



BONTEMPI 49 1010 Wireless Speaker with Microphone Owner's Manual

[Home](#) » [BONTEMPI](#) » BONTEMPI 49 1010 Wireless Speaker with Microphone Owner's Manual 

Contents


- [1 BONTEMPI 49 1010 Wireless Speaker with Microphone](#)
- [2 PRODUCT FUNCTION](#)
- [3 TWS FUNCTION](#)
- [4 POWER SUPPLY](#)
- [5 WASTE DISPOSAL STANDARDS](#)
- [6 DISPOSING OF ELECTRICAL APPLIANCES](#)
- [7 CONTACT INFORMATION](#)
- [8 Documents / Resources](#)
 - [8.1 References](#)
- [9 Related Posts](#)


BONTEMPI®


BONTEMPI 49 1010 Wireless Speaker with Microphone



PRODUCT FUNCTION






1. **Switch:** Wireless/ USB Flash drive/Micro-SD/FM Radio/ Light effects
2. Manual FM RADIO station scan • Volume and playlist sequence
3. Automatic FM RADIO station scan • Play/Pause • TWS (double click on the button): allows you to connect two speakers of the same model to the same smartphone or other wireless source
4. Socket for USB flash drive (max 32Gb) (not included)
5. Micro SD card (max 32Gb) slot
6. USB Type-C socket for charging cable 5V  1A (cable included)
7. Socket for microphone
8. Switching On/Off


TWS FUNCTION

1. Connect with your smartphone or other wireless source (Bontempi491010)
2. Double-click on the TWS button of the first speaker
3. Double-click on the TWS button of the second speaker
4. The same music is now played on both speakers



TWS FUNCTION


1. Connect with your smartphone or other wireless source (Bontempi491010)
2. Double click on the TWS button of the first speaker
3. Double click on the TWS button of the second speaker
4. The same music is now played on both speakers




Stream the same music to both speakers

POWER SUPPLY

This product is powered by a built-in lithium battery that can be charged with the USB Type-C cable included in the box. To charge the battery, insert one end of the cable into the USB Type-C socket 6 and the other end into the **USB socket**: – of a 100-240V~ mains power supply unit that has an output with the following characteristics:

Vdc=5V  1=1A; – a PC; – a Power bank.



WARNING: All batteries or transformers with safety insulation must be checked regularly for faults in cable, wire, plug insulation, or other parts. This instrument is only to be connected to equipment bearing either of the following symbols:



NOTE: Rating plate information was located at the bottom enclosure of the apparatus.

WASTE DISPOSAL STANDARDS

For information regarding the disposal of the items mentioned here below, please refer to the Council Administration office regarding specialized waste collection centers.

1. BATTERY DISPOSAL:

- At the end of the service life of the product, the battery contained in it must be disposed of separately from general undifferentiated waste.



2. PACKAGING DISPOSAL:

- Take the paper, cardboard, and corrugated board to the appropriate waste collection centers. Plastic material must be placed in the relevant collection containers.



- The symbols indicating the various types of plastic are:



Key for the different types of plastic materials:

- PET** = Polyethylene terephthalate
- PE** = Polyethylene, code 02 for PE-HD, 04 for PE-LD
- PVC** = Polyvinyl chloride
- PP** = Polypropylene
- PS** = Polystyrene, Polystyrene foam
- 0** = Other polymers (ABS, Laminates, etc.)

DISPOSING OF ELECTRICAL APPLIANCES

- The wheeled bin symbol with a cross indicates that the product must not be disposed of in the domestic waste at the end of its useful life.
- Instead, it should be taken to your nearest designated collection point or recycling facility.
- Alternatively, check with your retailer and return the product when buying a replacement, on a one-to-one basis, or free of charge in case the size is smaller than 25 cm.
- Appropriate disposal promotes the recycling of parts and materials, as well as helping to protect the environment and human health.
- Under current legislation, strict penalties are enforced against those disposing of products illegally.
- For more information about the collection of special waste, contact your Local Authority.



Hereby, iCom S.p.A. declares that the radio equipment type Wireless "Amplifier 49_1010" complies with Directive 2014/53/EU. The full text of the EU Declaration of Conformity is available at the following internet address:

http://www.icomtoys.it/CE-Declaration/DoC_491010.pdf. ICOM S.p.A. reserves all rights to modify the specifications of this product without notice. Read and keep this manual for future reference.


ATTENTION: Do not use alcohol, solvents, or similar chemical substances for cleaning. Use a soft cloth dampened in a bland solution of water and neutral detergent.

CONTACT INFORMATION

- ICOM S.p.A.
- **Sede Legale:** Via Caduti del Lavoro, 4 – 60131 Ancona – Italy
- **Sede Amministrativa:** Viale Don Bosco, 35 – 62018 Potenza Picena (MC) – Italy
- www.bontempi.com.
- e-mail: info@bontempi.com.



Documents / Resources

	<p>BONTEMPI 49 1010 Wireless Speaker with Microphone [pdf] Owner's Manual 49 1010 Wireless Speaker with Microphone, 49 1010, Wireless Speaker with Microphone, Speaker with Microphone, Microphone</p>
---	--

References

- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.