

## BOOX

BOOX Go  
10.3 Series  
4.6mm  
Monochrome  
ePaper  
Notepad



# BOOX Go 10.3 Series 4.6mm Monochrome ePaper Notepad User Guide


[Home](#) » [BOOX](#) » **BOOX Go 10.3 Series 4.6mm Monochrome ePaper Notepad User Guide** 

## Contents

- [1 BOOX Go 10.3 Series 4.6mm Monochrome ePaper Notepad](#)
- [2 Product Usage Instructions](#)
- [3 Speaker Setup](#)
- [4 Quick Start Guide](#)
- [5 SAFETY](#)
- [6 FCC Statement](#)
- [7 Documents / Resources](#)
  - [7.1 References](#)
- [8 Related Posts](#)

# BOOX

**BOOX Go 10.3 Series 4.6mm Monochrome ePaper Notepad**



### Product Specifications:

- Model: #009(P4FSJFT)
- Speaker Type: Wired
- Compatibility: Universal
- Color: Black

### Product Usage Instructions

#### 1. Speaker Setup:

Connect the speaker to your device using the provided cable.

#### 2. Power On/Off:

Use the power button to turn the speaker on or off.

#### 3. Adjusting Volume:

Rotate the volume knob to adjust the volume levels according to your preference.

#### 4. Using the Stylus:

The included stylus can be used for touch screen devices. Use it to navigate or interact with your device.

### Frequently Asked Questions (FAQ):

#### • Q: How do I charge the speaker?

A: The speaker is powered via the connected cable and does not require separate charging.


#### • Q: Is the stylus compatible with all devices?

A: The stylus is designed to work with most touch screen devices, but compatibility may vary.

### Speaker Setup

1. power
2. USB C Port
3. Mic to Speaker

#### 4. Indicator:




- a. BOOX Device
- b. Warranty Card
- c. C Cable
- d. Stylus Pen
- e. CJSB

#### Quick Start Guide

- **Turn on the device:** Hold down the power button for 2—3 second.
- **Charging:** When the battery is low or the device can not be turned on, please connect your BOOX with a PC or an Adaptor to charge it. When the device is charging, the indicator shows red. When the battery is fully charged, the indicator turns blue.
- **Firmware update:** Download the update packages to the root directory of the local storage, or get OT A updates on the

To force shutdown, please hold the power button for about 15 seconds. You can read the full version of the User Manual on the official BOOX website: <https://www.boox.com/downloads/>

## SAFETY



## FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**Caution:** Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.


**This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:**

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

### Specific Absorption Rate (SAR) information:

This Device meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health. FCC RF Exposure Information and Statement the SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: Device has also been tested against this SAR limit. This device was tested for typical body-worn operations with the back of the device kept 0mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain an 0mm separation distance between the user's body and the back of the device. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

Documents / Resources

	<a href="#">BOOX Go 10.3 Series 4.6mm Monochrome ePaper Notepad</a> [pdf] User Guide XR3-BOOXGO103, XR3BOOXGO103, booxgo103, Go 10.3 Series 4.6mm Monochrome ePaper Notepad, Go 10.3 Series, 4.6mm Monochrome ePaper Notepad, Monochrome ePaper Notepad, ePaper Notepad, Notepad
---	---

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.