

Both

Both Lighting
Dry Ice Fog
Machine



Both Lighting Dry Ice Fog Machine User Manual

[Home](#) » [Both Lighting](#) » Both Lighting Dry Ice Fog Machine User Manual 

Contents

- [1 Both Lighting Dry Ice Fog Machine](#)
- [2 Operation](#)
- [3 Technical Parameters](#)
- [4 FAQ](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)
- [6 Related Posts](#)

Both

Both Lighting Dry Ice Fog Machine



Thank you for purchasing our product! Please kindly read the manual carefully and operate the machine strictly to it for better operating and your safety, and in case of any bodily injury or damage to the unit.

Operation

1. Open the upper cover of the machine, pour water into the water tank about 8L. The water should reach just to the bottom of the basket when the basket is fully raised. The red heating light will come on when there is sufficient water.
2. Preset the temperature switch to 70-80 °C.
3. Power the unit on ,The RED light(heating) on the panel lights up. If there is not enough water, this light will not turn on.
4. Waiting for the water to get hot. About 15Mins till the GREEN light on the panel lights up.
5. When the GREEN light is on, we open the upper cover , add about 3kg of dry ice to the dry ice basket, and then close the upper cover quickly.
6. Put down the lifting handle that controls the dry ice basket, and a large amount of smoke will be sprayed out from the smoke outlet immediately. The lifting handle has 2 adjustable water levels. Put it at the bottom to spray the maximum amount of smoke. When such a large amount of smoke is not required, you can put it in the first gear, which can save dry ice.

Warning

1. The input of the power supply must be connected to the ground, otherwise, the leakage protection won't work.
2. Enough water must be poured into the water tank before electrification, otherwise, the machine won't work because of water-shortage protection.
3. After each use, drain the water in the water tank.
4. Because the temperature of dry ice is very low, be careful every time you touch dry ice, and use thick cotton gloves or other shelter to touch dry ice! If you touch the skin directly for a long time, it may cause cell freezing

and similar slight or extremely serious frostbite.

Technical Parameters

- POWER:220V 3500W / 110V 2000W
- Voltage: 110V 60HZ / 220V 50HZ
- Control: Manual
- Supplies: Columnar dry ice
- Preheating time:220V 15Mins 110V 25Mins Electronic temperature control 70°C~80°C
- water consumption 8L
- Maximum continuous output time 2-3minutes Cover area: about 150 square feet
- Weight: 7.8kg
- SIZE 42*36*40cm
- Packing Size:49*45*46.5CM Flay case
size 50*43*55CM
- Packing Weight: 12.3kg Flay case
- weight 21kg

FAQ


- **Q: What should I do if the red heating light does not turn on?**

A: Ensure there is enough water in the tank. If the light still does not turn on, check for any blockages in the water flow and make sure all connections are secure.

- **Q: How often should I clean the machine?**

A: It is recommended to clean the machine after every use to prevent any buildup that can affect its performance.

Documents / Resources

<p>Dry Ice Fog Machine User Manual</p>  <p>How often should I clean the machine after every use to prevent any buildup that can affect its performance.</p>	<p>Both Lighting Dry Ice Fog Machine [pdf] User Manual Dry Ice Fog Machine, Dry Ice, Fog Machine, Machine</p>
--	---

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.