



BRESSER 7030110 Translucidus WT Window Thermometer Instruction Manual

[Home](#) » [BRESSER](#) » BRESSER 7030110 Translucidus WT Window Thermometer Instruction Manual 

BRESSER 7030110 Translucidus WT Window Thermometer

 **BRESSER**



25.6 °C

MAX

29 °C

MIN

20 °C

Contents

- 1 [Validity note](#)
- 2 [General Information](#)
- 3 [General Warnings](#)
- 4 [Scope of delivery](#)
- 5 [Parts overview](#)
- 6 [Power Supply](#)
- 7 [Install the Thermometer](#)
- 8 [Operation](#)
- 9 [MAX/MIN recording](#)
- 10 [Technical data](#)
- 11 [EC Declaration of Conformity](#)
- 12 [Disposal](#)
- 13 [Warranty](#)
- 14 [Customer Support](#)
- 15 [Documents / Resources](#)
 - 15.1 [References](#)
- 16 [Related Posts](#)

Validity note

This documentation is valid for the products with the following article numbers: 7030110 Manual version: 0324

Manual designation:

Manual_7030110_Window-Termometer-Translucidus-WT_de-en-fr-nl-es-it_BRESSER_v032024a Always provide information when requesting service.

General Information



About this Instruction Manual These operating instructions are to be considered a component of the device. Read the safety instructions and the instruction manual carefully before using this device. Keep these instruction manual in a safe place for future reference. If the device is sold or passed on, the instruction manual must be passed on to any subsequent owner/user of the product.



DANGER!

You will find this symbol before every section of text that deals with the risk of minor to severe injuries resulting from improper use.



ATTENTION!

You will find this symbol in front of every section of text which deals with the risk of damage to property or the environment.

General Warnings



DANGER

This device contains electronic components which operate via a power source (power supply and/or batteries). Only use the device as described in the manual, or you run the risk of an electric shock.

Keep batteries out of the reach of children! Make sure you insert the batteries correctly. Empty or damaged

batteries could cause burns if they come into contact with the skin. If necessary, wear adequate gloves for protection.

! ATTENTION

Do not disassemble the device. In the event of a defect, please contact your dealer. The dealer will contact the Service Centre and can send the device in to be repaired, if necessary. Do not expose the device to temperatures above 60°C.

Do not expose the device to high temperatures. Use only the supplied power supply or the recommended batteries. Do not short-circuit the device or batteries or throw them into a fire! Excessive heat or improper handling could trigger a short-circuit, a fire or an explosion.


Use only the recommended batteries. Always replace weak or empty batteries with a new, complete set of batteries at full capacity. Do not use batteries from different brands or with different capacities. The batteries should be removed from the unit if it has not been used for a long time.

Scope of delivery

Window Thermometer 1x CR-2032 Battery

Parts overview

1. Temperature in display
2. Max temperature record
3. Min temperature record
4. Battery cover
5. °C/°F button



Power Supply


1. Open the battery compartment door.
2. Remove the plastic strip between the battery compartment and the button cell (CR2032).
3. Reinsert the battery compartment cover.

Install the Thermometer

To mount the thermometer, you can attach it to a window, mirror, or any clean and smooth, non-porous surface. Please note that suction cups will not stick to wood or plaster. Here are the steps to attach the thermometer accurately:

1. Clean the surface thoroughly to remove any oils or dust.
2. Press the suction cup firmly that is attached to the thermometer's housing, ensuring it forms a tight bond with the surface you're mounting it on.

Operation

1. Once the battery is installed, the main unit will start displaying the interior measurement information.
2. Press the  button to select the temperature unit in °C or °F.
3. Press and hold the / button for approx. 3 seconds to clear the Max and Min temperature record.

MAX/MIN recording

The device has a function to record the maximum and minimum temperature values. Once it is installed with a battery, it starts recording these values when the temperature and humidity are displayed normally. Every 24 hours, the previous records will be cleared and the device will start recording again.

Technical data

Measurement

Temperature measuring unit: °C / °F

Temperature display range: -20 – 60°C

Resolution for temperature: 0.1°C 1*CR2032 Battery (incl.)

EC Declaration of Conformity

CE Bresser GmbH hereby declares that the radio equipment type with item number 7030110 is in compliance with Directive 2014/53/EU. The full text of the EC Declaration of Conformity is available at the following web address: www.bresser.de/download/7030110/CE/7030110_CE.pdf

Disposal



Dispose of the packaging materials properly, according to their type, such as paper or cardboard. Contact your local waste-disposal service or environmental authority for information on the proper disposal.



Do not dispose of electronic devices in the household garbage! As per Directive 2002/96/EC of the European Parliament on waste electrical and electronic equipment and its adaptation into German law, used electronic devices must be collected separately and recycled in an environmentally friendly manner.

In accordance with the regulations concerning batteries and rechargeable batteries, disposing of them in the normal household waste is explicitly forbidden. Please make sure to dispose of your used batteries as required by law — at a local collection point or in the retail market. Disposal in domestic waste violates the Battery Directive.

Batteries that contain toxins are marked with a sign and a chemical symbol. “Cd” = cadmium, “Hg” = mercury, “Pb” = lead

1. battery contains cadmium
2. battery contains mercury
3. battery contains lead



Cd¹



Hg²



Pb³

Warranty

The regular warranty period is 2 years and starts on the day of purchase. To benefit from an extended voluntary warranty period as indicated on the gift box, registration on our website is required.

You can consult the full guarantee terms as well as information on extending the guarantee period and details of our services at www.bresser.de/warranty_terms.

Please contact the service centre first for any questions regarding the product or claims, preferably by e-mail.

E-Mail: service@bresseruk.com

Telephone*: +441342837098

BRESSER UK Ltd.

Suite 3G, Eden House
Enterprise Way
Edenbridge, Kent TN8 6HF
Great Britain

Number charged at local rates in the UK (the amount you will be charged per phone call will depend on the tariff of your phone provider); calls from abroad will involve higher costs

Customer Support

Visit our website via the following QR Code or web link to find further information on this product or the available translations of these instructions.



www.bresser.de/P7030110



WARRANTY



www.bresser.de/warranty_terms

Bresser GmbH
Gutenbergstraße 2
46414 Rhede · Germany
www.bresser.de





@BresserEurope



Documents / Resources

	<p>BRESSER 7030110 Translucidus WT Window Thermometer [pdf] Instruction Manual 7030110, 7030110 Translucidus WT Window Thermometer, Translucidus WT Window Thermometer, Window Thermometer, Thermometer</p>
--	---

References

-  [Bresser](#) | [Startseite](#) | [Expand Your Horizon mit BRESSER](#)
-  [Bresser](#) | [Startseite](#) | [Expand Your Horizon mit BRESSER](#)
- [User Manual](#)

[Manuals+](#) [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.