



BRESSER 7030110 Window Thermometer Translucidus WT Instruction Manual

[Home](#) » [BRESSER](#) » BRESSER 7030110 Window Thermometer Translucidus WT Instruction Manual 

Contents

- [1 BRESSER 7030110 Window Thermometer Translucidus WT](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 WARRANTY](#)
- [5 Validity note](#)
- [6 General Information](#)
- [7 General Warnings](#)
- [8 Scope of delivery](#)
- [9 Parts overview](#)
- [10 Power Supply](#)
- [11 Operation](#)
- [12 Technical data](#)
- [13 EC Declaration of Conformity](#)
- [14 Warranty](#)
- [15 Documents / Resources](#)
 - [15.1 References](#)
- [16 Related Posts](#)



BRESSER 7030110 Window Thermometer Translucidus WT



Product Information

Specifications

- Product Name: Window Thermometer Translucidus WT
- Art. No.: 7030110
- Power Source: CR-2032 Button Cell

Product Usage Instructions

Installation

1. Open the battery compartment located at the back of the thermometer.
2. Insert the CR-2032 button cell into the battery compartment ensuring the correct polarity.
3. Securely close the battery compartment cover.
4. Choose a suitable location on your window to mount the thermometer.
5. Use adhesive or screws to attach the thermometer securely in place.

Operation

Once installed, the thermometer will display the current temperature along with the maximum and minimum recorded values.

Press the designated buttons to switch between viewing the current temperature, maximum, and minimum values.

MAX/MIN Recordings

The thermometer automatically records the maximum and minimum temperatures since the last reset. To reset the recorded values, press and hold the reset button for a few seconds.

General Maintenance

Keep the thermometer clean by wiping it with a damp cloth when needed.

FAQ

- **Q: How do I reset the recorded maximum and minimum temperatures?**

Always provide information when requesting service.

General Information

About this Instruction Manual

These operating instructions are to be considered a component of the device. Read the safety instructions and the instruction manual carefully before using this device.

Keep this instruction manual in a safe place for future reference. If the device is sold or passed on, the instruction manual must be passed on to any subsequent owner/user of the product.



DANGER!

You will find this symbol before every section of text that deals with the risk of minor to severe injuries resulting from improper use.



ATTENTION!

You will find this symbol in front of every section of text which deals with the risk of damage to property or the environment.

General Warnings

DANGER!

This device contains electronic components which operate via a power source (power supply and/or batteries). Only use the device as described in the manual, or you run the risk of an electric shock.

Keep batteries out of the reach of children! Make sure you insert the batteries correctly. Empty or damaged batteries could cause burns if they come into contact with the skin. If necessary, wear adequate gloves for protection.

ATTENTION!


Do not disassemble the device. In the event of a defect, please contact your dealer. The dealer will contact the Service Centre and can send the device in to be repaired, if necessary. Do not expose the device to temperatures above 60°C.

Do not expose the device to high temperatures. Use only the supplied power supply or the recommended batteries. Do not short-circuit the device or batteries or throw them into a fire! Excessive heat or improper handling could trigger a short-circuit, a fire or an explosion.

Use only the recommended batteries. Always replace weak or empty batteries with a new, complete set of batteries at full capacity. Do not use batteries from different brands or with different capacities. The batteries should be removed from the unit if it has not been used for a long time.

Scope of delivery

- Window Thermometer
- 1x CR-2032 Battery



Parts overview

1. Temperature in display
2. Max temperature record
3. Min temperature record
4. Battery cover

5.  button

Power Supply

1. Open the battery compartment door.
2. Remove the plastic strip between the battery compartment and the button cell (CR2032).
3. Reinsert the battery compartment cover.

Install the Thermometer

To mount the thermometer, you can attach it to a window, mirror, or any clean and smooth, non-porous surface. Please note that suction cups will not stick to wood or plaster. Here are the steps to attach the thermometer accurately:

1. Clean the surface thoroughly to remove any oils or dust.
2. Press the suction cup firmly that is attached to the thermometer's housing, ensuring it forms a tight bond with the surface you're mounting it on.

Operation

1. Once the battery is installed, the main unit will start displaying the interior measurement information.



2. Press the button to select the temperature unit in °C or °F.
3. Press and hold the / button for approx. 3 seconds to clear the Max and Min temperature record.

MAX/MIN recording

The device has a function to record the maximum and minimum temperature values. Once it is installed with a battery, it starts recording these values when the temperature and humidity are displayed normally. Every 24 hours, the previous records will be cleared and the device will start recording again.

Technical data

Measurement

- Temperature measuring unit: °C / °F
- Temperature display range: -20 – 60°C
- Resolution for temperature: 0.1°C
- 1*CR2032 Battery (incl.)

EC Declaration of Conformity

Bresser GmbH has issued a “Declaration of Conformity” in accordance with applicable guidelines and corresponding standards. The full text of the EU declaration of conformity is available at the following internet address: www.bresser.de/download/7030110/CE/7030110_CE.pdf

DISPOSAL




Dispose of the packaging materials properly, according to their type, such as paper or card-board. Contact your local waste-disposal service or environmental authority for information on the proper disposal.



Do not dispose of electronic devices in the household garbage! As per Directive 2002/96/EC of the European Parliament on waste electrical and electronic equipment and its adaptation into German law, used electronic devices must be collected separately and recycled in an environmentally friendly manner. In accordance with the regulations concerning batteries and rechargeable batteries, disposing of them in the normal household waste is explicitly forbidden. Please make sure to dispose of your used batteries as required by law — at a local collection point or in the retail market. Disposal in domestic waste violates the Battery Directive. Batteries that contain toxins are marked with a sign and a chemical symbol. “Cd” = cadmium, “Hg” = mercury, “Pb” = lead.

1. battery contains cadmium
2. battery contains mercury
3. battery contains lead



Warranty

The regular warranty period is 2 years and starts on the day of purchase. To benefit from an extended voluntary warranty period as indicated on the gift box, registration on our website is required. You can consult the full guarantee terms as well as information on extending the guarantee period and details of our services at www.bresser.de/warranty_terms.

Service

Please contact the service centre first for any questions regarding the product or claims, preferably by e-mail.

E-Mail: service@bresseruk.com

Telephone*: +44 1342 837 098

BRESSER UK Ltd.

Suite 3G, Eden House
Enterprise Way
Edenbridge, Kent TN8 6HF
Great Britain

*Number charged at local rates in the UK (the amount you will be charged per phone call will depend on the tariff of your phone provider); calls from abroad will involve higher costs

Bresser GmbH Gutenbergstraße 2
46414 Rhede · Germany
www.bresser.de
@BresserEurope

Bresser UK Ltd.

Suite 3G, Eden House
Enterprise Way
Edenbridge, Kent TN8 6HF
Great Britain

Documents / Resources



[BRESSER 7030110 Window Thermometer Translucidus WT](#) [pdf] Instruction Manual
7030110, 7030110 Window Thermometer Translucidus WT, 7030110, Window Thermometer Tr
anslucidus WT, Thermometer Translucidus WT, Translucidus WT

References

- [Bresser | Startseite | Expand Your Horizon mit BRESSER](#)
- [User Manual](#)

Manuals+. Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.