## **BTOS LB01 Sage Button**



# **BTOS LB01 Sage Button User Manual**

Home » BTOS » BTOS LB01 Sage Button User Manual

## **Contents**

- 1 BTOS LB01 Sage Button
- **2 Product Information**
- 3 Product Usage Instructions
- 4 Maintenance
- 5 FAQ
- **6 Operation**
- **7 FCC STATEMENT**
- **8 CONTACT**
- 9 Documents / Resources
  - 9.1 References

**BTOS** 

**BTOS LB01 Sage Button** 



## **Product Information**

# **Specifications**

• Model: LB01 - Sage Button

• Manufacturer: Suzhou BTOS Electronics Co., Ltd

• Address: A-401, Building1, LiandongU T-Park, No.269, Xingfeng Road, Xukou, Suzhou, China

• Email: <u>btos\_sales@btos-china.com</u>.

# **Product Usage Instructions**

## Unboxing

• Carefully remove the product from the packaging.

# **Battery Installation**

• Locate the battery compartment at the bottom of the product and insert the required batteries.

## **Activation**

• To activate the item, press the button to turn on the lights.

## **Battery Replacement**

• If the lights do not respond, replace the batteries with new ones.

## **Maintenance**

Avoid disturbing moving parts to prevent damage to your item.

## **FAQ**

- Q: Is the device safe for portable use?
- **A:** Yes, the device has been evaluated to meet general RF exposure requirements and can be used in portable exposure conditions without restrictions.

# Operation

- 1. Carefully remove the product from the packaging.
- 2. The battery compartment is at the bottom of the product.
- 3. To activate the item, press the button, and turn on the lights.
- 4. Replace the batteries if the lights do not respond.
- 5. Do not disturb moving parts as it may damage your item

#### **IMPORTANT!**

Read the user manual carefully before using the product and save it for future use. If you follow these instructions, you will enjoy the product for a long time.

- Repairs to electrical devices may only be carried out by authorized service personnel. Improper repair can put the user and the device in danger.
- Do not push objects into any openings on the device as damage to the device and/or electric shock may occur.
- Do not use the device for anything other than what it is intended for.
- The LED lights cannot be replaced and must not be unscrewed.
- Before first use; open the battery door on the underside of the device. Make sure the polarity is correct (see battery cover). Batteries that are not inserted properly can cause damage to the product.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
- Do not mix old and new batteries. Replace all batteries in a set at the same time.
- · Rechargeable batteries are not recommended for this product.
- Remove the battery if the device is not to be used for a long period.
- Used batteries can be harmful to the environment. Do not throw them away with normal garbage. Remove the old battery and dispose of it according to local guidelines.
- Never dispose of batteries over an open fire. They can explode or leak.

#### **FCC STATEMENT**

#### **FCC Caution**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and,
- 2. this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, under part

15 of the FCC Rules.

These limits are designed to protect reasonably against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used under the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. Suppose this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on. In that case, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF warning for Portable device: The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

#### CONTACT

## Suzhou BTOS Electronics Co., Ltd

- A-401, Building1, LiandongU T-Park,
- · No.269, Xingfeng Road,
- · Xukou, Suzhou, China
- btos sales@btos-china.com.
- btos-china.com.

#### **Documents / Resources**



BTOS LB01 Sage Button [pdf] User Manual LB01 Sage Button, LB01, Sage Button, Button

## References

User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.